

20-COMM-K CANopen Adapter

Firmware 1.xxx



User Manual



Important User Information

Solid state equipment has operational characteristics differing from those of electromechanical equipment. *Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls* (Publication SGI-1.1 available from your local Rockwell Automation sales office or online at <http://www.rockwellautomation.com/literature>) describes some important differences between solid state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc. is prohibited.

Throughout this manual, when necessary we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.

Important: Identifies information that is critical for successful application and understanding of the product.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequences.



Shock Hazard labels may be located on or inside the equipment (e.g., drive or motor) to alert people that dangerous voltage may be present.



Burn Hazard labels may be located on or inside the equipment (e.g., drive or motor) to alert people that surfaces may be at dangerous temperatures.

PowerFlex, DriveExplorer, DriveExecutive, DPI, DriveTools SP, and ControlFLASH, are either trademarks or registered trademarks of Rockwell Automation, Inc.
CANopen is a trademark of the CANopen Vendor Association.

Summary of Changes

The information below summarizes the changes made to this manual since its last release (January 2005):

Description of Changes	Page
Reformatted document from half size (5.5 x 8.5 in.) to full size (8.5 x 11 in.)	Throughout manual
Added SMC Flex to compatible products list.	1-2
Revised Figures 2.2 and 2.3 to show PowerFlex 700H/S Frames 9 and larger. Added ground tab details in Figure 2.3.	2-5 and 2-6
Added "Flash Updating the Adapter" section.	3-10

Preface	About This Manual	
	Related Documentation	P-1
	Rockwell Automation Support	P-2
	Conventions Used in This Manual	P-2
Chapter 1	Getting Started	
	Components	1-1
	Features	1-2
	Compatible Products	1-2
	Required Equipment	1-3
	Safety Precautions	1-4
	Quick Start	1-5
	Status Indicators	1-6
Chapter 2	Installing the Adapter	
	Preparing for an Installation	2-1
	Commissioning the Adapter	2-1
	Connecting the Adapter to the Drive	2-4
	Connecting the Adapter to the Network	2-7
	Applying Power	2-8
Chapter 3	Configuring the Adapter	
	Configuration Tools	3-1
	Using the PowerFlex 7-Class HIM	3-2
	Setting the Node Address	3-3
	Setting the Data Rate	3-3
	Setting the I/O Configuration	3-4
	Selecting COS, Cyclic or RTR I/O Data Exchange	3-5
	Setting a Fault Action	3-7
	Resetting the Adapter	3-9
	Viewing the Adapter Status Using Parameters	3-10
	Flash Updating the Adapter	3-10
Chapter 4	Configuring the CANopen Network	
	Network Management (NMT)	4-1
	CANopen Object Dictionary	4-3
	CANopen Network Configuration	4-4
Chapter 5	Using I/O Messaging	
	About Process Data Objects	5-1
	Understanding the I/O Image	5-4
	Using Logic Command/Status	5-6
	Using Reference/Feedback	5-6
	Using Datalinks	5-8
	Transmit PDO Mapping	5-9
	Receive PDO Mapping	5-10

Chapter 6	Using Service Data Objects	
	About Service Data Objects	6-1
	Running Service Data Objects	6-2
	CANopen DPI Parameter Access	6-2
	CANopen DPI Full Parameter Access	6-3
Chapter 7	Troubleshooting	
	Understanding the Status Indicators	7-1
	PORT Status Indicator	7-2
	MOD Status Indicator	7-2
	NET A (CAN RUN) Status Indicator	7-3
	NET B (CAN ERR) Status Indicator	7-3
	Viewing Adapter Diagnostic Items	7-4
	Viewing and Clearing Events	7-5
Appendix A	Specifications	
	Communications	A-1
	Electrical	A-1
	Mechanical	A-1
	Environmental	A-1
	Regulatory Compliance	A-2
Appendix B	Adapter Parameters	
	About Parameter Numbers	B-1
	Parameter List	B-1
Appendix C	CANopen Objects	
	CANopen Object Tables	C-1
	Emergency Object	C-4
Appendix D	Logic Command/Status Words	
	PowerFlex 7-Class Drives (except PowerFlex 700S)	D-1
	PowerFlex 700S Drives	D-3
Appendix E	CANopen Network Example	
	Example Network	E-1
	Configuring the Network Nodes	E-2
	Configuring the Communications	E-8
	Configuring the PLC Variables and Linking	E-9
	Configuring the PDOs, SDOs, and SYNC	E-16
	Downloading Configuration	E-20
	PLC Program	E-22
Appendix F	Logic Controller Program Example	
	Configuring the Drive/ Adapter	F-1
	Network Variables File	F-2
	Program Code and Program Run	F-3
	SDO Access Example	F-4

Glossary

Index

About This Manual

Topic	Page
Related Documentation	P-1
Rockwell Automation Support	P-2
Conventions Used in This Manual	P-2

Related Documentation

For:	Refer to:	Publication
DriveExplorer™	http://www.ab.com/drives/driveexplorer , and DriveExplorer online help (installed with the software)	—
DriveTools™ SP (includes DriveExecutive™)	http://www.ab.com/drives/drivetools , and DriveExecutive online help (installed with the software)	—
PowerFlex 7-Class HIM	HIM Quick Reference	20HIM-QR001
PowerFlex® 70/70EC Drive	PowerFlex 70 User Manual PowerFlex 70/700 Reference Manual PowerFlex 70EC/700VC Reference Manual	20A-UM001 PFLEX-RM001 PFLEX-RM004
PowerFlex® 700/700VC Drive PowerFlex® 700 Series B Drive	PowerFlex 700 User Manual PowerFlex 700 Series B User Manual PowerFlex 70/700 Reference Manual PowerFlex 70EC/700VC Reference Manual	20B-UM001 20B-UM002 PFLEX-RM001 PFLEX-RM004
PowerFlex® 700H Drive	PowerFlex 700H Installation Instructions PowerFlex 700H Programming Manual	PFLEX-IN006 20C-PM001
PowerFlex® 700S Drive (Frames 1 through 6)	PowerFlex 700S with Phase I Control User Manual PowerFlex 700S with Phase II Control User Manual PowerFlex 700S Reference Manual	20D-UM001 20D-UM006 PFLEX-RM002
PowerFlex® 700S Drive (Frames 9 and higher)	PowerFlex 700S Installation Instructions PowerFlex 700S with Phase I Control User Manual PowerFlex 700S with Phase II Control User Manual PowerFlex 700S Reference Manual	PFLEX-IN006 20D-UM001 20D-UM006 PFLEX-RM002

Above Rockwell Automation documentation can be obtained online at <http://literature.rockwellautomation.com>. To order paper copies of technical documentation, contact your local Rockwell Automation distributor or sales representative.

CANopen documentation can be obtained online at <http://www.can-cia.com/>.

To find your local Rockwell Automation distributor or sales representative, visit www.rockwellautomation.com/locations.

For information such as firmware updates or answers to drive-related questions, go to the Drives Service & Support web site at www.ab.com/support/abdrives and click on the “Downloads” or “Knowledgebase” link.

Rockwell Automation Support

Rockwell Automation, Inc. offers support services worldwide, with over 75 sales/support offices, over 500 authorized distributors, and over 250 authorized systems integrators located through the United States alone. In addition, Rockwell Automation, Inc. representatives are in every major country in the world.

Local Product Support

Contact your local Rockwell Automation, Inc. representative for:

- Sales and order support
- Product technical training
- Warranty support
- Support service agreements

Technical Product Assistance

For technical assistance, please review the information in [Chapter 7, Troubleshooting](#), first. If you still have problems, then access the Allen-Bradley Technical Support web site at www.ab.com/support/abdrives or contact Rockwell Automation, Inc.

Conventions Used in This Manual

This manual provides information about the adapter and using it with PowerFlex 7-Class (Architecture-Class) drives. The adapter can also be used with other products that support a DPI™ adapter, such as the SMC™ Flex. Refer to the documentation for your product for specific information about how it works with the adapter.

The following conventions are used throughout this manual:

- Parameter names are shown in the format **Parameter xx - [*]**. The xx represents the parameter number. The * represents the parameter name—for example **Parameter 01 - [DPI Port]**.
- Menu commands are shown in bold type face and follow the format **Menu > Command**. For example, if you read “Select **File > Open**,” you should click the **File** menu and then click the **Open** command.
- The firmware release is displayed as FRN X.xxx. The “FRN” signifies Firmware Release Number. The “X” is the major release number. The “xxx” is the minor update number.
- CANopen is an open protocol with many different vendors of software and hardware. In this manual, the following tools were used: IXXAT CANopen Configuration Studio (version 1.4), Mauell CoDeSys AA programming software and the Mauell Telmatic ME-series of PLC. Different versions of the software may differ in appearance and procedures.


Getting Started

The adapter is intended for installation into a PowerFlex 7-Class drive and is used for network communication. The adapter can also be used with other Allen-Bradley products supporting DPI™.

Topic	Page
Components	1-1
Features	1-2
Compatible Products	1-2
Required Equipment	1-3
Safety Precautions	1-4
Quick Start	1-5
Status Indicators	1-6

Components

Figure 1.1 Components of the Adapter



Item	Part	Description
1	Status Indicators	Four LEDs that indicate the status of the DPI, the adapter, and network connection. Refer to Chapter 7, Troubleshooting .
2	DPI Connector	A 20-pin, single-row shrouded male header. An Internal Interface cable is connected to this connector and a connector on the drive.
3	CANopen Connector	A 9-pin, male D-sub connector for the network cable.
4	Node Address Switches	Two rotary switches to set the node address. Refer to Setting the Node Address Switches on page 2-2 .
5	Data Rate Switch	Switch to set the network data rate at which the adapter communicates. Refer to Setting the Data Rate on page 2-3 .

Features

The features of the adapter include:

- Typical mounting in a PowerFlex 7-Class (Architecture Class) drive.
- Captive screws to secure and ground the adapter to the drive.
- Compatibility with various configuration tools to configure the adapter and connected drive. The tools include the PowerFlex 7-Class HIM on the drive, and drive-configuration software such as DriveExplorer (version 2.01 or higher) or DriveExecutive (version 3.01 or higher).
- Switches to set a node address and network data rate before applying power to the PowerFlex drive. Alternately, you can disable the switches and use adapter parameters to configure these functions.
- Status indicators that report the status of the drive communications, the adapter, and network. They are visible when the drive cover is open or closed.
- Parameter-configurable I/O (Logic Command/Reference and up to four pairs of Datalinks) to meet application requirements.
- Support for Service Data Object (SDO) messages.
- Implementation of the CANopen DS301 specification.
- User-defined fault actions to determine how the adapter and connected drive respond to I/O messaging communication disruptions.
- Multiple data exchange methods (Cyclic, Change of State, and Remote Transmission Request) to transmit data between the network and adapter.
- Faulted node recovery support. You can configure a device even when it is faulted on the network if you have a configuration tool that uses faulted node recovery and have set the data rate switch to “PGM” (Program). The adapter then uses parameter settings for the data rate and node address instead of the switch settings.

Compatible Products

DPI is a second generation peripheral communication interface and a functional enhancement to SCANport. The adapter is compatible with Allen-Bradley PowerFlex 7-Class drives and other products that support DPI. At the time of publication, compatible products include:

- PowerFlex 70 drives
- PowerFlex 700 drives
- PowerFlex 700H drives
- PowerFlex 700S drives
- SMC™ Flex

Required Equipment

Equipment Shipped with the Adapter

When you unpack the adapter, verify that the package includes:

- One adapter
- A 2.54 cm (1 in.) and a 15.24 cm (6 in.) Internal Interface cable (only one cable is needed to connect the adapter to the drive)
- One *PowerFlex 7-Class DPI (Drive Peripheral Interface) Network Communication Adapter Installation Instructions* (publication 20COMM-IN004)

User-Supplied Equipment

To install and configure the adapter, you must supply:

- A small flathead screwdriver
- CANopen cable with 9-pin D-Sub female connector – thin cable with an outside diameter of 7 mm (0.27 in.) is recommended
- Configuration tool, such as:
 - PowerFlex 7-Class HIM (20-HIM-xx)
 - DriveExplorer (version 4.01 or higher)
 - DriveExecutive stand-alone software (version 3.01 or higher) or bundled with the DriveTools SP suite (version 1.01 or higher)
 - CANopen Configuration Studio IXXAT (version 1.4 or higher)
 - PowerFlex 1203-USB or 1203-SSS Serial Converter (version 3.001 or higher)
- Computer with a CANopen network configuration tool (for example, IXXAT tinCAN)

Safety Precautions

Please read the following safety precautions carefully.



ATTENTION: Risk of injury or death exists. The PowerFlex drive may contain high voltages that can cause injury or death. Remove all power from the PowerFlex drive, and then verify power has been discharged before installing or removing an adapter.



ATTENTION: Risk of injury or equipment damage exists. Only personnel familiar with drive and power products and the associated machinery should plan or implement the installation, start up, configuration, and subsequent maintenance of the product using an adapter. Failure to comply may result in injury and/or equipment damage.



ATTENTION: Risk of equipment damage exists. The adapter contains ESD (Electrostatic Discharge) sensitive parts that can be damaged if you do not follow ESD control procedures. Static control precautions are required when handling the adapter. If you are unfamiliar with static control procedures, refer to *Guarding Against Electrostatic Damage* (publication 8000-4.5.2).



ATTENTION: Risk of injury or equipment damage exists. If the adapter is transmitting control I/O to the drive, the drive may fault when you reset the adapter. Determine how your drive will respond before resetting an adapter.



ATTENTION: Risk of injury or equipment damage exists. **Parameter 10 - [Comm Flt Action]** and **11 - [Idle Flt Action]** let you determine the action of the adapter and connected drive if communications are disrupted. By default, these parameters fault the drive. You can set these parameters so that the drive continues to run. Precautions should be taken to ensure that the setting of these parameters do not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable or a faulted controller).



ATTENTION: Risk of injury or equipment damage exists. When a system is configured for the first time, there may be unintended or incorrect machine motion. Disconnect the motor from the machine or process during initial system testing.



ATTENTION: Risk of injury or equipment damage exists. The examples in this publication are intended solely for purposes of example. There are many variables and requirements with any application. Rockwell Automation, Inc. does not assume responsibility or liability (to include intellectual property liability) for actual use of the examples shown in this publication.



ATTENTION: Risk of injury or equipment damage exists. DPI or SCANport host products must not be directly connected together via 1202 cables. Unpredictable behavior due to timing and other internal procedures can result if two or more devices are connected in this manner.

Quick Start


This section is provided to help experienced users quickly start using the adapter. If you are unsure how to complete a step, refer to the referenced chapter.

Step	Action	Refer to...
1	Review the safety precautions for the adapter.	Throughout This Manual
2	Verify that the PowerFlex drive is properly installed.	Drive User Manual
3	Install the adapter. Verify that the PowerFlex drive is not powered. Then, connect the adapter to the network using a network cable and to the drive using the Internal Interface cable. Use the captive screws to secure and ground the adapter to the drive.	<i>PowerFlex 7-Class DPI Network Communication Adapter Installation Instructions</i> (publication 20COMM-IN004) and Chapter 2, Installing the Adapter
4	Commission the adapter. Set a unique node address and the appropriate data rate using the adapter switches. If desired, you can disable the switches and use adapter parameters instead.	Chapter 2, Installing the Adapter
5	Apply power to the adapter. A. The adapter receives power from the drive. Verify that the adapter is installed correctly and then apply power to the drive. The status indicators should be green. If they flash red, there is a problem. Refer to Chapter 7, Troubleshooting . B. Configure/verify key drive parameters.	Chapter 2, Installing the Adapter
6	Configure the adapter for your application. Set adapter parameters for the following functions as required by your application: <ul style="list-style-type: none"> • Node address and data rate (if Data Rate switch is set to "PGM") • I/O configuration • Change of State, Cyclic or RTR I/O data exchange • Fault actions 	Chapter 3, Configuring the Adapter
7	Configure the CANopen network. Use a tool of CANopen Network Management master such as CANopen Configuration Studio IXXAT to configure the CANopen network. Make sure to: <ul style="list-style-type: none"> • Install the EDS file. • Create configuration and device connections. • Save your CANopen configuration. 	Chapter 4, Configuring the CANopen Network Appendix E, CANopen Network Example
8	Create a programmable logic controller program. Use a programming tool such as CoDeSys Programming Software for the Maelle PLC to create a logic program that enables you to: <ul style="list-style-type: none"> • Control the adapter and connected drive. • Monitor or configure the drive using Service Data Objects. 	Chapter 5, Using I/O Messaging Chapter 6, Using Service Data Objects

Status Indicators

The adapter uses four status indicators to report its operating status. They can be viewed on the adapter or through the drive cover ([Figure 1.2](#)).

Figure 1.2 Status Indicators (location on drive may vary)



Item	Name
①	PORT
②	MOD
③	NET A (CAN RUN)
④	NET B (CAN ERR)

After installing the adapter and applying power to the drive, refer to [Start-Up Status Indications on page 2-8](#) for possible start-up status indications and their descriptions.

Installing the Adapter

This chapter provides instructions for installing the adapter in a PowerFlex 7-Class drive.

Topic	Page
Preparing for an Installation	2-1
Commissioning the Adapter	2-1
Connecting the Adapter to the Drive	2-4
Connecting the Adapter to the Network	2-7
Applying Power	2-8

Preparing for an Installation Before installing the adapter, verify that you have all required equipment. Refer to [Required Equipment on page 1-3](#).

Commissioning the Adapter To commission the adapter, you must set a unique node address and the data rate that is used by the network.

Important: New settings are recognized only when power is applied to the adapter. If you change a setting, cycle power to the drive.




ATTENTION: Risk of equipment damage exists. The adapter contains ESD (Electrostatic Discharge) sensitive parts that can be damaged if you do not follow ESD control procedures. Static control precautions are required when handling the adapter. If you are unfamiliar with static control procedures, refer to *Guarding Against Electrostatic Damage* (publication 8000-4.5.2).

Setting the Node Address Switches

Set the adapter Node Address switches ([Figure 2.1](#)) by rotating the switches to the desired value for each digit.

Important: Each node on the network must have a unique address. Set the node address before power is applied because the adapter uses the node address it detects when it first receives power. To change a node address, you must set the new value and then remove and reapply power to (or reset) the adapter.

Figure 2.1 Setting Adapter Node Address Switches




Setting	Description
00...99	<p>Node address used by the adapter if switches are enabled. The default switch setting is 01. Node address 01 is also the default address used by all uncommissioned devices. We recommend that you do not use this address as the final adapter address.</p> <p>The Node Address switches are checked during start-up and, if the address needs to be changed, the power must be cycled for the change to take effect.</p> <p>Important: If both Node Address switches are set to "0," the adapter uses the Parameter 03 - [COPN Addr Cfg] setting for the node address. With this parameter, the node address can be set from 1...127. This parameter is readable/writable over the network, and its default setting is 1. Refer to Setting the Node Address on page 3-3.</p>

The Node Address switch settings can be verified by viewing **Parameter 04 - [COPN Addr Actual]** using a PowerFlex 7-Class HIM, DriveExplorer software, or DriveExecutive software.

Setting the Data Rate

Set the adapter Data Rate switch ([Figure 2.2](#)) by rotating the switch to the desired setting.

Figure 2.2 Setting Adapter Data Rate Switch



Setting	Description
10Kbps, 20Kbps, 50Kbps, 125Kbps, 250Kbps, 500Kbps, 800Kbps or 1Mbps	Sets the adapter to the respective data rate. The default switch setting is 500Kbps.
PGM	The adapter uses the setting of Parameter 05 - [COPN Rate Cfg] for the data rate. This parameter is readable/writable over the network, and its default setting is 500Kbps. Refer to Setting the Data Rate on page 3-3 .

The Data Rate switch setting can be verified by viewing **Parameter 06 - [COPN Rate Actual]** using a PowerFlex 7-Class HIM, DriveExplorer software, or DriveExecutive software.

Connecting the Adapter to the Drive




ATTENTION: Risk of injury or death exists. The PowerFlex drive may contain high voltages that can cause injury or death. Remove power from the drive, and then verify power has been discharged before installing or removing the adapter.

1. Remove power from the drive.
2. Use static control precautions.
3. Remove the drive cover or open the drive door.
4. Connect the Internal Interface cable to the DPI port on the drive and then to the DPI connector on the adapter (see [Figure 2.3](#)).
5. Secure and ground the adapter to the drive (see [Figure 2.4](#)) by doing the following:
 - On a PowerFlex 70 drive, fold the Internal Interface cable behind the adapter and mount the adapter on the drive using the four captive screws.
 - On a PowerFlex 700, PowerFlex 700H or PowerFlex 700S drive, mount the adapter on the drive using the four captive screws.


Important: Tighten all screws to properly ground the adapter. Recommended torque is 0.9 N•m (8.0 lb•in).

Figure 2.3 DPI Ports and Internal Interface Cables



Item	Description
❶	15.24 cm (6 in.) Internal Interface cable
❷	DPI Connector
❸	CANopen network cable
❹	2.54 cm (1 in.) Internal Interface cable

Figure 2.4 Mounting and Grounding the Adapter



Connecting the Adapter to the Network




ATTENTION: Risk of injury or death exists. The PowerFlex drive may contain high voltages that can cause injury or death. Remove power from the drive, and then verify power has been discharged before installing or removing the adapter.

1. Remove power from the network and drive.
2. Use static control precautions.
3. Connect one end of a CANopen cable to the network. A CANopen cable with an outside diameter of 6.9 mm (0.27 in.) is recommended.

Important: Maximum cable length depends on the data rate. For details, refer to [Data Rate](#) in the Glossary.

4. Route the other end of the CANopen cable through the bottom of the PowerFlex drive ([Figure 2.4](#)) and connect a 9-pin D-Sub plug to the CANopen cable. See [Figure 2.5](#) and its related table for wiring connection details.

Figure 2.5 Connecting 9-Pin D-Sub Plug to CANopen Cable



Pin	Name	Function
2	CAN_L	CAN low bus line
3	CAN_GND	CAN ground
5	CAN_SHLD	CAN shield
6	GND	Ground (not used)
7	CAN_H	CAN high bus line

5. Connect a 120 Ohm bus termination resistor at both ends of the CAN-bus cable (at the first and last node, if several adapters are connected to the CAN-bus). The termination should be made in the connectors and is not included on the adapter. (See [Figure 2.5](#).)
6. Connect the CANopen cable plug to the mating adapter receptacle, and secure it with the two screws.

Applying Power



ATTENTION: Risk of equipment damage, injury, or death exists. Unpredictable operation may occur if you fail to verify that parameter settings are compatible with your application. Verify that settings are compatible with your application before applying power to the drive.

1. Install the drive cover or close the drive door. The status indicators can be viewed on the front of the drive.
2. Ensure that the adapter has a unique node address on the network and is set at the correct data rate. If a new address or data rate is needed, reset its switches (see [Setting the Node Address Switches on page 2-2](#) or [Setting the Data Rate on page 2-3](#)).
3. Apply power to the network.
4. Apply power to the drive. The adapter receives its power from the connected drive. When you apply power to the adapter for the first time, the status indicators should be green after an initialization. If an indicator is red, there is a problem. Refer to [Chapter 7, Troubleshooting](#).
5. If the Data Rate switch is set to “PGM” or the Node Address switches are set to “00,” use a configuration tool to set the data rate and node address parameters in the adapter (see [Setting the Data Rate on page 3-3](#) or [Setting the Node Address on page 3-3](#)).

Start-Up Status Indications

After power has been applied, the status indicators for the drive and communications adapter can be viewed on the front of the drive ([Figure 2.6](#)). Possible start-up status indications are shown in [Table 2.A](#).

Figure 2.6 Drive and Adapter Status Indicators (location on drive may vary)




Table 2.A Drive and Adapter Start-Up Status Indications

Item	Name	Color	State ⁽¹⁾	Description
Drive STS Indicator				
1	STS (Status)	Green	Flashing	Drive ready but not running, and no faults are present.
			Steady	Drive running, no faults are present.
		Yellow	Flashing, Drive Stopped	An inhibit condition exists – the drive cannot be started. Check drive Parameter 214 - [Start Inhibits].
			Flashing, Drive Running	An intermittent type 1 alarm condition is occurring. Check drive Parameter 211 - [Drive Alarm 1].
			Steady, Drive Running	A continuous type 1 alarm condition exists. Check drive Parameter 211 - [Drive Alarm 1].
		Red	Flashing	A fault has occurred.
Steady	A non-resettable fault has occurred.			
Adapter Status Indicators				
2	PORT	Green	Flashing	Normal Operation. The adapter is establishing a connection to the drive. It will turn steady green or red.
			Steady	Normal Operation. The adapter is properly connected and communicating with the drive.
	MOD	Green	Flashing	Normal Operation. The adapter is operating but is not transferring I/O data.
			Steady	Normal Operation. The adapter is operating and transferring I/O data.
	NET A (CAN RUN)	Green	Flashing	Normal Operation. The adapter is properly connected but is not communicating with any devices on the network.
			Steady	Normal Operation. The adapter is properly connected and communicating on the network.
	NET B (CAN ERR)	Green	Off	Normal Operation. No error.
			Steady	Normal Operation. The CAN controller is bus off.

⁽¹⁾ If all status indicators are off, the adapter is not receiving power. Refer back to instructions in this chapter on installing the adapter. If any other conditions occur, see [Chapter 7, Troubleshooting](#).

Configuring/Verifying Key Drive Parameters

The PowerFlex 7-Class drive can be separately configured for the control and Reference functions in various combinations. For example, you could set the drive to have its control come from a peripheral or terminal block with the Reference coming from the network. Or you could set the drive to have its control come from the network with the Reference coming from another peripheral or terminal block. Or you could set the drive to have both its control and Reference come from the network.

The following steps in this section assume that the drive will receive the Logic Command and Reference from the network.

1. Use drive Parameter 090 - [Speed Ref A Sel] to set the drive speed Reference to “22” (DPI Port 5).
2. If hard-wired discrete digital inputs are not used to control the drive, verify that unused digital input drive Parameters 361 - [Dig In1 Sel] and 362 - [Dig In2 Sel] are set to “0” (Not Used).

3. Verify that drive Parameter 213 - [Speed Ref Source] is reporting that the source of the Reference to the drive is “22” (DPI Port 5). This ensures that any Reference commanded from the network can be monitored by using drive Parameter 002 - [Commanded Speed]. If a problem occurs, this verification step provides the diagnostic capability to determine whether the drive/adapter or the network is the cause.

Configuring the Adapter

This chapter provides instructions and information for setting the parameters to configure the adapter.

Topic	Page
Configuration Tools	3-1
Using the PowerFlex 7-Class HIM	3-2
Setting the Node Address	3-3
Setting the Data Rate	3-3
Setting the I/O Configuration	3-4
Selecting COS, Cyclic or RTR I/O Data Exchange	3-5
Setting a Fault Action	3-7
Resetting the Adapter	3-9
Viewing the Adapter Status Using Parameters	3-10
Flash Updating the Adapter	3-10

For a list of parameters, refer to [Appendix B, Adapter Parameters](#). For definitions of terms in this chapter, refer to the [Glossary](#).

Configuration Tools

The adapter stores parameters and other information in its own non-volatile memory. You must, therefore, access the adapter to view and edit its parameters. The following tools can be used to access the adapter parameters:

Tool	Refer to...
PowerFlex HIM	page 3-2
DriveExplorer Software (version 4.01 or higher)	http://www.ab.com/drives/driveexplorer , or DriveExplorer online help (installed with the software)
DriveExecutive Software (version 3.01 or higher)	http://www.ab.com/drives/drivetools , or DriveExecutive online help (installed with the software)




TIP: Service Data Objects can also be used to configure an adapter and drive. Refer to [Chapter 6, Using Service Data Objects](#).




Using the PowerFlex 7-Class HIM

If your drive has either an LED or LCD HIM (Human Interface Module), it can be used to access parameters in the adapter as shown below. It is recommended that you read through the steps for your HIM before performing the sequence. For additional information, refer to your PowerFlex Drive User Manual or the *PowerFlex 7-Class HIM Quick Reference* (publication 20HIM-QR001).

Using an LED HIM

Step	Example Screens
<ol style="list-style-type: none"> 1. Press the ALT key and then the Device Sel (Sel) key to display the Device Screen. 2. Press the ▲ or ▼ key to scroll to the adapter. Letters represent files in the drive, and numbers represent ports. The adapter is usually connected to port 5. 3. Press the ↵ (Enter) key to enter your selection. A parameter database is constructed, and then the first parameter is displayed. 4. Edit the parameters using the same techniques that you use to edit drive parameters. 	

Using an LCD HIM

Step	Example Screens
<ol style="list-style-type: none"> 1. In the main menu, press the ▲ or ▼ key to scroll to Device Select. 2. Press the ↵ (Enter) key to enter your selection. 3. Press the ▲ or ▼ key to scroll to the adapter (20-COMM-K). 4. Press the ↵ (Enter) key to select the adapter. A parameter database is constructed, and then the main menu for the adapter is displayed. 5. Edit the parameters using the same techniques that you use to edit drive parameters. 	  

NOTE: All configuration procedures throughout this chapter use the PowerFlex 7-Class LCD HIM to access parameters in the adapter and show example LCD HIM screens.

Setting the Node Address

The node address is normally set by the adapter Node Address switches ([Figure 2.1](#)), and is unique to each node on the network. If both switches are set to “0,” the value of **Parameter 03 - [COPN Addr Cfg]** determines the node address.

1. Set the value of **Parameter 03 - [COPN Addr Cfg]** to a unique node address.

Figure 3.1 Example COPN Node Addr Cfg LCD HIM Screen

Port 5 Device 20-COMM-K	Default = 1
Parameter #: 03 COPN Addr Cfg 01	
1 <> 127	

2. Reset the adapter (see [Resetting the Adapter on page 3-9](#)).

Setting the Data Rate

The data rate is normally set by the adapter Data Rate switch ([Figure 2.2](#)), and must be the same for each node on the network. If the Data Rate switch is set to “PGM” (Program), the value of **Parameter 05 - [COPN Rate Cfg]** determines the data rate. Your application may require a different setting.

1. Set the value of **Parameter 05 - [COPN Rate Cfg]** to the data rate at which your network is operating.

Figure 3.2 Example COPN Rate Cfg LCD HIM Screen

Port 5 Device 20-COMM-K	Value	Data Rate
Parameter #: 05 COPN Rate Cfg 5	0	10 Kbps
500K	1	20 Kbps
	2	50 Kbps
	3	125 Kbps
	4	250 Kbps
	5	500 Kbps (default)
	6	1000 Kbps

2. Reset the adapter (see [Resetting the Adapter on page 3-9](#)).

Setting the I/O Configuration

The I/O configuration determines the data that is sent to and from the drive. Logic Command/Status, Reference/Feedback, and Datalinks may be enabled or disabled. A “1” enables the I/O. A “0” disables the I/O.

1. Set the bits in **Parameter 12 - [DPI I/O Cfg]**.

Figure 3.3 Example DPI I/O Cfg LCD HIM Screen

Port 5 Device 20-COMM-K	Bit	Description
Parameter #: 12 DPI I/O Cfg x x x x x x x x x x 0 0 0 0 1	0	Logic Command/Reference (Default)
Cmd/Ref b00	1	Datalink A
	2	Datalink B
	3	Datalink C
	4	Datalink D
	5...15	Not Used

Bit 0 is the right-most bit. In [Figure 3.3](#), it is highlighted and equals “1.”

2. If Logic Command/Reference is enabled, configure the parameters in the drive to accept the Logic Command and Reference from the adapter. For example, set Parameter 90 - [Speed Ref A Sel] in a PowerFlex 70 or 700 drive to “22” (DPI Port 5) so that the drive uses the Reference from the adapter. Also, verify that the mask parameters (for example, Parameter 276 - [Logic Mask]) in the drive are configured to receive the desired logic from the adapter. Refer to the documentation for your drive for details.
3. If you enabled one or more Datalinks, configure parameters in the drive to determine the source and destination of data in the Datalink(s). For example, configure the Datalinks in PowerFlex 70 and 700 drives by setting Parameters 300 - [Data In A1] through 317 - [Data Out D2]. Also, ensure that the Modbus/TCP adapter is the only adapter using the enabled Datalink(s).
4. Reset the adapter (see [Resetting the Adapter on page 3-9](#)).

The adapter is ready to receive I/O.

Selecting COS, Cyclic or RTR I/O Data Exchange

The data exchange (sometimes called allocation) is the method that the adapter uses to exchange real-time data on the CANopen network. The real-time data is transferred using a PDO (Process Data Object). The adapter can be configured to use one of the following data exchange types:

- COS (Change of State)
- Cyclic
- RTR (Remote Transmission Request)

Each PDO can have a different type of data exchange, but COS can only be selected for PDO1 (Status/Feedback word).

COS data exchange must be configured to set both the I/O configuration and COS parameters in the adapter. Cyclic and RTR data exchanges are configured in the PLC, so you only need to set the I/O configuration in the adapter. No adapter parameters need to be adjusted.

For more details, refer to [Chapter 5, Using I/O Messaging](#).

Using COS (Change of State) Data Exchange

COS means that a PDO is sent whenever the CANopen device has changed its state (for example, a value has changed).

1. Using the CANopen configuration tool, set the transmission mode of the TPDO1 (Transmit PDO) of the adapter to “0” (synchronous) or “254” (asynchronous).
2. Set **Parameter 24 - [PDO1 Trigger]** to “0” (COS).

Figure 3.4 Example DPO1 Trigger LCD HIM Screen

Port 5 Device 20-COMM-K	Value	Trigger
Parameter #: 24 PDO1 Trigger	0	COS (Default)
0	1	Cyclic
COS		

3. Set Bit 0 (the Logic Command/Reference bit) in **Parameter 12 - [DPI I/O Config]** to “1” (Enabled).

Figure 3.5 Example I/O Configuration LCD HIM Screen

Port 5 Device 20-COMM-K	Parameter #: 12 DPI I/O Cfg
1	xxxxxxx0000 1
Cmd/Ref	b00

- Set **Parameter 25 - [COS Status Mask]** for the bits in the Logic Status word that should be checked for changes. The bit definitions for the Status Mask will depend on the drive to which the adapter is connected. Refer to [Appendix D](#) or the drive documentation.

Figure 3.6 Example COS Status Mask LCD HIM Screen

Port 5 Device
20-COMM-K
Parameter #: 25
COS Status Mask
x x x x x x x x x x 0 0 0 0 1
Bit 0 b00

Value	Description
0	Ignore this logic bit. (Default)
1	Use this logic bit.

- Set **Parameter 26 - [COS Fdbk Change]** for the amount of change to the Feedback that is required to trigger a Change of State message.

Figure 3.7 Example COS Fdbk Change LCD HIM Screen

Port 5 Device
20-COMM-K
Parameter #: 26
COS Fdbk Change
1
1 <> 4294967295

Default = 1

Using Cyclic Data Exchange

With cyclic data exchange, a PDO is sent periodically.

- With the CANopen configuration tool, set the transmission mode of the TPDO1 (Transmit PDO) of the adapter to “0” (synchronous) or “254” (asynchronous).
- Set **Parameter 24 - [PDO1 Trigger]** to “1” (Cyclic).

Figure 3.8 Example DPO1 Trigger LCD HIM Screen

Port 5 Device
20-COMM-K
Parameter #: 24
PDO1 Trigger
1
Cyclic

Value	Trigger
0	COS (Default)
1	Cyclic

- Set **Parameter 27 - [Cyclic Interval]** for the desired time interval between two transmissions.

Figure 3.9 Example Cyclic Interval LCD HIM Screen

Port 5 Device
20-COMM-K
Parameter #: 27
Cyc Interval
0.02
0.02 <> 655.35

Default = 0.02 s

This cyclic data exchange is only possible for the PDO1. However, there is another possibility to implement cyclic data exchange for each PDO1:

1. Using the CANopen configuration tool, set the transmission mode of the TPDO (Transmit PDO) of the adapter to a value between “1” and “240.”
2. Using the CANopen configuration tool, set the *communication cycle period* to a desired value. The cyclic interval is calculated by multiplying the *transmission type* by the *communication cycle period*.
3. No adapter parameter needs to be adjusted.

Using RTR (Remote Transmission Request)

PDOs can be remotely requested by transmitting a CAN remote frame from the requesting PDO consumer. The corresponding PDO producer responds to this remote frame.

1. Using the CANopen configuration tool, set the transmission type of the TPDO (Transmit PDO) of the adapter to “252” (synchronous) or “253” (asynchronous).
2. No adapter parameter needs to be adjusted.

Setting a Fault Action

By default, when I/O communications are disrupted (for example, a cable is disconnected) or the controller is idle (in program mode or faulted), the drive responds by faulting if it is using I/O from the network. You can configure a different response to:

- Disrupted I/O communication using **Parameter 10 - [Comm Flt Action]**
- An idle controller using **Parameter 11 - [Idle Flt Action]**




ATTENTION: Risk of injury or equipment damage exists. **Parameters 10 - [Comm Flt Action]** and **11 - [Idle Flt Action]** let you determine the action of the adapter and connected drive if I/O communications are disrupted or the controller is idle. By default, these parameters fault the drive. You can set these parameters so that the drive continues to run. Precautions should be taken to ensure that the settings of these parameters do not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable or faulted controller).

Changing the Fault Action

Set the values of **Parameters 10 - [Comm Flt Action]** and **11 - [Idle Flt Action]** to the desired response:

Value	Action	Description
0	Fault	The drive is faulted and stopped. (Default)
1	Stop	The drive is stopped, but not faulted.
2	Zero Data	The drive is sent 0 for output data. This does not command a stop.
3	Hold Last	The drive continues in its present state.
4	Send Flt Cfg	The drive is sent the data that you set in the fault configuration parameters (Parameters 14 - [Flt Cfg Logic] through 23 - [Flt Cfg D2 In]).

Figure 3.10 Example Fault Action LCD HIM Screens



Changes to these parameters take effect immediately. A reset is not required.

Setting the Fault Configuration Parameters

If you set **Parameter 10 - [Comm Flt Action]** or **11 - [Idle Flt Action]** to “Send Flt Cfg,” the values in the following parameters are sent to the drive after an I/O communications fault and/or idle fault occurs. You must set these parameters to values required by your application.

Parameter	Description
14 - [Flt Cfg Logic]	A 16-bit value sent to the drive for Logic Command.
15 - [Flt Cfg Ref]	A 32-bit value (0...4294967295) sent to the drive as a Reference or Datalink.
16 - [Flt Cfg x1 In] through 23 - [Flt Cfg x2 In]	Important: If the drive uses a 16-bit Reference or 16-bit Datalinks, the most significant word of the value must be set to zero (0) or a fault will occur.

Changes to these parameters take effect immediately. A reset is not required.

Resetting the Adapter

Changes to switch settings and some adapter parameters require that you reset the adapter before the new settings take effect. You can reset the adapter by cycling power to the drive or by using **Parameter 09 - [Reset Module]**.



ATTENTION: Risk of injury or equipment damage exists. If the adapter is transmitting control I/O to the drive, the drive may fault when you reset the adapter. Determine how your drive will respond before resetting a connected adapter.

Set **Parameter 09 - [Reset Module]** to “1” (Reset Module).

Figure 3.11 Example Reset Module LCD HIM Screen

Port 5 Device	20-COMM-K
Parameter #: 09	Reset Module
	1
	Reset Module

Value	Description
0	Ready (Default)
1	Reset Module
2	Set Defaults

When you enter “1” (Reset Module), the adapter will be immediately reset. When you enter “2” (Set Defaults), the adapter will set all adapter parameters to their factory-default values. After performing a Set Defaults, enter “1” (Reset Module) so that the new values take effect. The value of this parameter will be restored to “0” (Ready) after the adapter is reset.

Viewing the Adapter Status Using Parameters

The following parameters provide information about the status of the adapter. You can view these parameters at any time.

Parameter	Description																														
04 - [COPN Addr Act]	<p>The node address used by the adapter. This will be one of the following values:</p> <ul style="list-style-type: none"> The address set by the rotary switches. The value of Parameter 03 - [COPN Addr Cfg] if the switches have been set to "0." An old address of the switches or parameter if they have been changed and the adapter has not been reset. 																														
06 - [COPN Rate Act]	<p>The data rate used by the adapter. This will be one of the following values:</p> <ul style="list-style-type: none"> The data rate set by the rotary switch. The value of Parameter 05 - [COPN Rate Cfg] if the switch has been set to "PGM." An old data rate of the switch or parameter if it has been changed and the adapter has not been reset. 																														
07 - [Ref/Fdbk Size]	The size of the Reference/Feedback. It will either be 16 bits or 32 bits. It is set in the drive and the adapter automatically uses the correct size.																														
08 - [Datalink Size]	The size of the Datalinks. It will either be 16 bits or 32 bits. It is set in the drive and the adapter automatically uses the correct size.																														
13 - [DPI I/O Act]	<p>The Reference/Feedback and Datalinks used by the adapter. This value is the same as Parameter 12 - [DPI I/O Cfg] unless the parameter was changed and the adapter was not reset.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Bit Definition</th> <th>Not Used</th> <th>Not Used</th> <th>Not Used</th> <th>Datalink D</th> <th>Datalink C</th> <th>Datalink B</th> <th>Datalink A</th> <th>Cmd/Ref</th> <th></th> </tr> </thead> <tbody> <tr> <td>Default</td> <td>x</td> <td>x</td> <td>x</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>0 = I/O disabled</td> </tr> <tr> <td>Bit</td> <td>7</td> <td>6</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> <td>0</td> <td>1 = I/O enabled</td> </tr> </tbody> </table>	Bit Definition	Not Used	Not Used	Not Used	Datalink D	Datalink C	Datalink B	Datalink A	Cmd/Ref		Default	x	x	x	0	0	0	0	1	0 = I/O disabled	Bit	7	6	5	4	3	2	1	0	1 = I/O enabled
Bit Definition	Not Used	Not Used	Not Used	Datalink D	Datalink C	Datalink B	Datalink A	Cmd/Ref																							
Default	x	x	x	0	0	0	0	1	0 = I/O disabled																						
Bit	7	6	5	4	3	2	1	0	1 = I/O enabled																						

Flash Updating the Adapter

The adapter can be flash updated over the network or serially through a direct connection from a computer to the drive using a 1203-USB or 1203-SSS serial converter.

When flashing over the network, you can use the Allen-Bradley software tool ControlFLASH, the built-in flash capability of DriveExplorer Lite or Full, or the built-in flash capability of DriveExecutive.

When flashing through a direct serial connection from a computer to a drive, you can use the same Allen-Bradley software tools described above, or you can use HyperTerminal set to the X-modem protocol.

To obtain a flash update for this adapter, go to <http://www.ab.com/support/abdrives/webupdate>. This site contains all firmware update files and associated Release Notes that describe firmware update enhancements/anomalies, how to determine the existing firmware version, and how to flash update using DriveExplorer, DriveExecutive, ControlFLASH or HyperTerminal.

Configuring the CANopen Network

This chapter provides information about configuring a CANopen network to communicate with the adapter and its connected PowerFlex 7-Class drive.

To configure the CANopen network, a variety of configuration tools of CANopen Network Management (NMT) masters are available from several manufactures, which help you to manage and configure CANopen devices and systems.

Appendix E gives an example how to configure the CANopen network by using the IXXAT CANopen Configuration Studio with the *Mauell CoDeSys AA* programming software and the *Mauell Telematic ME* series of PLC.


Topic	Page
Network Management (NMT)	4-1
CANopen Object Dictionary	4-3
CANopen Network Configuration	4-4

Network Management (NMT) The Network Management (NMT) is used to control the status of all nodes in the CANopen network. It uses a master/slave hierarchy and requires a device with master functionality responsible for detecting, starting, and monitoring the node states. Within any NMT slave there has to be implemented the NMT slave state machine, where the Pre-Operational state allows device configuration to take place.

Based on the DS301 specification, the 20-COMM-K uses the standard CANopen network management state machine. [Figure 4.1](#) shows the NMT slave state machine, and the corresponding different transitions. There are four main states defined:

- Initialization state
- Pre-Operational state
- Operational state
- Stopped state

Figure 4.1 The NMT Slave State Machine



The numbers in [Figure 4.1](#) correspond to the numbers within the parenthesis in the following state descriptions.

Initialization State

The CANopen adapter enters the Initialization state automatically after power-up and after a reset command. After the initialization is done, the adapter enters into the Pre-Operational state (12).

Pre-Operational State

In the Pre-Operational state, the adapter can be configured and parameterized, and allocation via SDO is possible but PDO communication is not allowed in this state. After this state is attained, the node can be switched to the Operational state when receiving a Start_Remote_Node message (6) from an NMT master.

Operational State

All communication objects are active in the Operational state. This means there is PDO communication, SDO communication, synchronization, and error control, and emergency messages allowed. The adapter will enter the Stopped state when receiving a Stop_Remote_Node message (7).

Stopped State

All communications, except NMT and heartbeat for error control, are stopped when the adapter is switched into the Stopped state. The adapter can be switched back to the Pre-Operational state by receiving a “Enter_PRE-OPERATIONAL_State” message.

A Reset_Node message (10) from an NMT master will reset the adapter. A Reset_Communication message (11) will reset the CANopen communication parameters within the adapter.

CANopen Object Dictionary

On CANopen, the interface between the application and CAN is achieved by an Object Dictionary. The Object Dictionary is unique for any CANopen device and represents complete access to the application in terms of the communication parameters, the application data, and the configuration parameters.

To configure the CANopen network it is necessary to access the Object Dictionary. However, some configuration tools allow network configuration directly on the application level and hide all CANopen configuration data, such as PDO mapping, or the assignment of CAN identifier.

To gain access to the Object Dictionary, Process Data Objects (PDOs) and Service Data Objects (SDOs) are used.

Index	Description
0000h	Reserved
0001h - 025Fh	Data types
0260h - 0FFFh	Reserved
1000h - 1FFFh	Communication profile area
2000h - 5FFFh	Manufacturer specific area
6000h - 9FFFh	Device profile specific area
A000h - BFFFh	Interface profile specific area
C000h - FFFFh	Reserved

Refer to [Table C.A](#) (Communication Profile Area) and [Table C.B](#) (Manufacturer Specific Area) for more information about CANopen objects.

CANopen Network Configuration

Network Node Configuration

With help of the configuration tool, set up a CANopen network with a specific baud rate. Select the required devices (for example, a PLC, input modules, output modules, and PowerFlex drives with 20-COMM-K adapters), add them to the network, and assign a unique node ID for each device.

EDS File

An EDS file is needed for each device on the CANopen network. Go to the Rockwell Automation web site at www.rockwellautomation.com/resources/eds to download EDS files. Save EDS files to an appropriate location on your computer.

SDO Configuration

Service Data Objects (SDOs) are used to establish a peer-to-peer connection between two CANopen devices.

SDOs use asynchronous data transmission with acknowledge. The SDOs are used to access all CANopen objects ([Appendix C](#)) in the adapter, and required for adapter configuration/parameterization. Access to an individual Object is made with a multiplexer via the Index and Sub-index of the Object Dictionary.

This type of connection is based on a Client/Server-based mechanism. Configure the PLC as SDO server and install the SDO channels to the other devices (SDO clients).

PDO Configuration

Process Data Objects (PDOs) are used to transmit the real-time data using the producer/consumer communication model. The PDOs are transmitted without any protocol “overhead” and without confirmation. The PDO object is used for the I/O communication.

There are basically two types of PDOs, depending on the transmission direction:

- TPDOs (Transmit PDOs) are used to transfer data from the communication adapter.
- RPDOs (Receive PDOs) are used to transfer data to the communication adapter.

The PDOs are defined via the CANopen Object Dictionary, whereby pre-defined PDOs can be selected (Default PDO mapping). The mapping can also be changed if desired. The PDO mapping is made during configuration with the help of SDOs.

Besides the PDO mapping to determine which data are available (mapped) in the selected PDO, the communication parameters that define the PDO communication behavior need to be set. This includes the transmission mode (synchronous or asynchronous) and the triggering mode which can be Change of State (COS), Cyclic or Remote Transmission Request (RTR).

SYNC Configuration

The synchronization object (SYNC) is used to synchronize the devices. There has to be a device in the network that is regarded as the SYNC producer. Usually, the PLC is configured as the SYNC message producer. The Communication Cycle Period (time between two SYNC messages) can be set to a desired value.

The SYNC object is used to synchronize PDO communication, trigger the transmission of a PDO, or perform the action on the last received PDO.

Node/Life Guarding

Node/Life Guarding is used for error control to check that any CANopen device is working properly. The mechanism used for guarding is based on the master/slave relationship. The NMT master guards all of its NMT slaves cyclically (cycle time = *Guard Time*) by using an RTR frame. Any CANopen slave responds to this RTR frame to guarantee that the application program is running (Node Guarding).

Simultaneously, if a slave does not receive an RTR frame from the NMT master within a specified time (*Guard Time x Life Time Factor*), the slave knows that the NMT master must have failed. This mechanism is called Life Guarding.

Adjust the *Guard Time* and the *Life Time Factor* to desired values.

Emergency EMCY

The emergency object is used to send fault information from the communication adapter to the CANopen network.

The emergency object is triggered by a fault event from the drive or the communication adapter itself. An emergency object is transmitted only once per error event.

Saving and Downloading the Configuration

After configuration and parameterization, save all parameters and download to devices separately. For the download, the adapter must be set in the Pre-Operational state.

Notes:

Using I/O Messaging

This chapter provides information and examples that explain how to use I/O Messaging to control a PowerFlex 7-Class drive.

Topic	Page
About Process Data Objects	5-1
Understanding the I/O Image	5-4
Using Logic Command/Status	5-6
Using Reference/Feedback	5-6
Using Datalinks	5-8
Transmit PDO Mapping	5-9
Receive PDO Mapping	5-10



ATTENTION: Hazard of injury or equipment damage exists. The examples in this publication are intended solely for purposes of example. There are many variables and requirements with any application. Rockwell Automation does not assume responsibility or liability (to include intellectual property liability) for actual use of the examples shown in this publication.

About Process Data Objects

On CANopen, **Process Data Objects (PDOs)** are used to transfer the real-time data which controls the PowerFlex drive and sets its Reference. PDOs can also be used to transfer data to and from Datalinks. A PDO message has high priority on the CAN bus. Each PDO has a unique CAN identifier, and the maximum length of a PDO message is 8 bytes.

PDO mapping and configuration are made with help of SDOs.

RPDO: SDO 1400 - 1403h (1st - 4th RPDO communication parameter)
SDO 1600 - 1603h (1st - 4th RPDO mapping parameter)

TPDO: SDO 1800 - 1803h (1st - 4th TPDO communication parameter)
SDO 1A00 - 1A03h (1st - 4th TPDO mapping parameter)

The adapter provides many options for configuring and using I/O, including:

- Configuring the size of I/O by enabling or disabling the Logic Command/Reference and Datalinks
- Using a Change of State, Cyclic or RTR data exchange method

PDO Transmission Types

The transmission type (or data exchange type) parameter of a PDO specifies the transmission mode and the triggering mode.

The transmission modes are:

- Synchronous transmission
- Asynchronous transmission

The adapter supports three PDO triggering modes:


- COS (Change of State)
- Cyclic
- Remote Transmission Request (RTR)

The triggering mode is only relevant for TPDOs. For RPDOs, only the transmission mode is important. To configure the PDOs, the adapter parameters have to be adjusted and other settings made using a CANopen configuration tool (for example, IXXAT CANopen Configuration Studio).

PDO Transmission Modes

To synchronize devices, a synchronization object (SYNC object) is transmitted periodically by a synchronization application (SYNC Master). [Figure 5.1](#) shows the principle of synchronous and asynchronous transmission. The time between two SYNC objects is the *Communication Cycle Period*.

Figure 5.1 Synchronous and Asynchronous Transmission



Synchronous TPDO: The data for Synchronous TPDOs are sampled at the moment the SYNC object is received. For COS and cyclic transmission, the TPDOs are sent immediately after sampling (therefore, after the SYNC object). For RTR transmission, the TPDOs are sent after the receipt of the request message.

Asynchronous TPDO: Asynchronous TPDOs are transmitted without any correlation to a SYNC. The data for asynchronous TPDOs are sampled continuously.

Synchronous RPDO: The data of synchronous RPDOs is passed to the application when the next SYNC object occurs, independently of the transmission rate specified by the transmission type.

Asynchronous RPDO: The data of asynchronous RPDOs is passed directly to the application.

PDO Triggering Modes

The adapter supports three PDO triggering modes:

- Change of State (COS)

Triggering mode COS means that the PDO is sent when a device-specific event occurs (for example, a value has changed). COS can only be selected for the TPDO1- Logic Status/Feedback (**Parameter 24 - [PDO1 Trigger]** is set to “0”).

COS with transmission mode *asynchronous* can be configured by setting the transmission type of the TPDO1 to “254” using a CANopen configuration tool. For COS with transmission mode *synchronous*, the transmission type must be set to “0.”

Adapter Parameters 25 and 26 control the COS behavior. **Parameter 25 - [COS Status Mask]** defines which bits in the Logic Status word are checked for changes, and **Parameter 26 - [COS Fdbk Change]** specifies how much the Feedback word can change before it is considered a change of state.

- Cyclic

PDOs with the cyclic triggering mode are sent periodically with a specific interval. For the transmission types 0 (synchronous) cyclic transmission and 254 (asynchronous), **Parameter 24 - [PDO1 Trigger]** is set to “1” (Cyclic) and **Parameter 27 - [Cycle Interval]** defines this interval. This is only possible for the PDO1.

A synchronous cyclic transmission can also be implemented by setting the transmission type to a value between 1 and 240. Then, the cyclic interval is calculated as follows:

$$\text{Cyclic Interval} = \text{Transmission Type} \times \text{Communication Cycle Period}$$

- Remote Transmission Request (RTR)

The transmission of a PDO is initiated on receipt of a Remote Transmission Request initiated by any other device (PDO consumer). The transmission can be either synchronous or asynchronous.

Table 5.A TPDO Summary

Triggering Mode	Transmission Mode	Param. 24 - [PDO1 Trigger]	Transmission Type ^{(1) (2)}	Transmission Type Name
COS	Synchronous	COS	0 ⁽³⁾	Synchronous acyclic
	Asynchronous	COS	254 ⁽³⁾	Asynchronous (Manuf. Event)
Cyclic	Synchronous	—	1...240	Synchronous cyclic
	Synchronous	Cyclic	0 ⁽³⁾	Synchronous acyclic
	Asynchronous	Cyclic	254 ⁽³⁾	Asynchronous (Manuf. Event)
RTR only	Synchronous	—	252	Synchronous RTR only
	Asynchronous	—	253	Asynchronous RTR only

⁽¹⁾ Transmission types 241...251 are reserved.

⁽²⁾ The transmission type 255 - Asynchronous (Profile Event) is not used in this implementation.

⁽³⁾ If transmission type 0 or 254 (COS and cyclic) is selected for TPDOs other than TPDO1, the TPDO will only be transmitted on Remote Transmission Request.

Table 5.B RPDO Summary

Transmission Mode	Behavior	Transmission Type ⁽¹⁾	Name
Synchronous	Data is passed to application after next SYNC.	0	Synchronous acyclic
		0...240	Synchronous cyclic
Asynchronous	Data is passed to application immediately.	254	Asynchronous (Manuf. Event)
		255	Asynchronous (Profile Event)

⁽¹⁾ The transmission types 252 and 253 are not possible for RPDOs.

Understanding the I/O Image

The CANopen specification requires that the terms *input* and *output* be defined from CANopen network's point of view. Therefore, Output I/O is data that is output from the CANopen network and consumed by the CANopen adapter. Input I/O is status data that is produced by the adapter and consumed as input by the CANopen network. The I/O image table will vary based on:

- Size (either 16-bit or 32-bit) of the Reference/Feedback words and Datalink words used by the drive. To determine the size of the Reference/Feedback and Datalinks, view adapter **Parameters 07 - [Ref/Fdbk Size]** and **08 - [Datalink Size]**. For information to access parameters, see
- Configuration of I/O (**Parameter 12 - [DPI I/O Config]**) in the adapter. If any I/O is not enabled, the image table is truncated. The image table always uses consecutive words starting at word 0.

The controller I/O image changes depending on the size of the drive's Reference/Feedback and Datalinks. [Table 5.C](#), [Table 5.D](#), and [Table 5.E](#) show the I/O image when using various PowerFlex 7-Class drives.

Table 5.C I/O Image for PowerFlex 70/700/700H Drives and SMC Flex (16-bit Reference/Feedback and 16-bit Datalinks)

Word	Output I/O	Word	Input I/O
0	Logic Command	0	Logic Status
1	Reference	1	Feedback
2	Datalink In A1	2	Datalink Out A1
3	Datalink In A2	3	Datalink Out A2
4	Datalink In B1	4	Datalink Out B1
5	Datalink In B2	5	Datalink Out B2
6	Datalink In C1	6	Datalink Out C1
7	Datalink In C2	7	Datalink Out C2
8	Datalink In D1	8	Datalink Out D1
9	Datalink In D2	9	Datalink Out D2

Table 5.D I/O Image for PowerFlex 700 VC Drives (16-bit Reference/Feedback and 32-bit Datalinks)

Word	Output I/O	Word	Input I/O
0	Logic Command	0	Logic Status
1	Reference	1	Feedback
2	Datalink In A1 (LSW)	2	Datalink Out A1 (LSW)
3	Datalink In A1 (MSW)	3	Datalink Out A1 (MSW)
4	Datalink In A2 (LSW)	4	Datalink Out A2 (LSW)
5	Datalink In A2 (MSW)	5	Datalink Out A2 (MSW)
6	Datalink In B1 (LSW)	6	Datalink Out B1 (LSW)
7	Datalink In B1 (MSW)	7	Datalink Out B1 (MSW)
8	Datalink In B2 (LSW)	8	Datalink Out B2 (LSW)
9	Datalink In B2 (MSW)	9	Datalink Out B2 (MSW)
10	Datalink In C1 (LSW)	10	Datalink Out C1 (LSW)
11	Datalink In C1 (MSW)	11	Datalink Out C1 (MSW)
12	Datalink In C2 (LSW)	12	Datalink Out C2 (LSW)
13	Datalink In C2 (MSW)	13	Datalink Out C2 (MSW)
14	Datalink In D1 (LSW)	14	Datalink Out D1 (LSW)
15	Datalink In D1 (MSW)	15	Datalink Out D1 (MSW)
16	Datalink In D2 (LSW)	16	Datalink Out D2 (LSW)
17	Datalink In D2 (MSW)	17	Datalink Out D2 (MSW)

LSW = Least Significant Word (Bits 15...0); MSW = Most Significant Word (Bits 31...16)

**Table 5.E I/O Image for PowerFlex 700S Drives
(32-bit Reference/Feedback and 32-bit Datalinks)**

Word	Output I/O	Word	Input I/O
0	Logic Command	0	Logic Status
1	Not Used	1	Not Used
2	Reference (LSW)	2	Feedback (LSW)
3	Reference (MSW)	3	Feedback (MSW)
4	Datalink In A1 (LSW)	4	Datalink Out A1 (LSW)
5	Datalink In A1 (MSW)	5	Datalink Out A1 (MSW)
6	Datalink In A2 (LSW)	6	Datalink Out A2 (LSW)
7	Datalink In A2 (MSW)	7	Datalink Out A2 (MSW)
8	Datalink In B1 (LSW)	8	Datalink Out B1 (LSW)
9	Datalink In B1 (MSW)	9	Datalink Out B1 (MSW)
10	Datalink In B2 (LSW)	10	Datalink Out B2 (LSW)
11	Datalink In B2 (MSW)	11	Datalink Out B2 (MSW)
12	Datalink In C1 (LSW)	12	Datalink Out C1 (LSW)
13	Datalink In C1 (MSW)	13	Datalink Out C1 (MSW)
14	Datalink In C2 (LSW)	14	Datalink Out C2 (LSW)
15	Datalink In C2 (MSW)	15	Datalink Out C2 (MSW)
16	Datalink In D1 (LSW)	16	Datalink Out D1 (LSW)
17	Datalink In D1 (MSW)	17	Datalink Out D1 (MSW)
18	Datalink In D2 (LSW)	18	Datalink Out D2 (LSW)
19	Datalink In D2 (MSW)	19	Datalink Out D2 (MSW)

LSW = Least Significant Word (Bits 15...0); MSW = Most Significant Word (Bits 31...16)

Using Logic Command/ Status

The *Logic Command* is a 16-bit word of control produced by the CANopen network and consumed by the adapter. The *Logic Status* is a 16-bit word of status produced by the adapter and consumed by the CANopen network.

This manual contains the bit definitions for most compatible products available at the time of publication in [Appendix D, Logic Command/Status Words](#). For other products, refer to their documentation.

Using Reference/Feedback

The *Reference* is produced by the controller and consumed by the adapter. The *Feedback* is produced by the adapter and consumed by the controller. The size of the Reference/Feedback is determined by the drive and displayed using adapter **Parameter 07 - [Ref/Fdbk Size]**.

Size	Valid Values
16-bit	-32768 to 32767
32-bit	-2147483648 to 2147483647

The Reference value is a scaled engineering value; it is NOT in Hertz or RPM. The Reference uses a “32767” scale. The “32767” endpoint of the scale is equal to the value of parameter 55 - [Maximum Freq], which has a default value of 130 Hz. For all PowerFlex 70/700 drives, default scaling is 0...15123 which is equal to 0...60.0 Hz. This is based on the formula shown below. Reference scaling is limited by drive parameter 82 - [Maximum Speed]. If the default value of 60 Hz. for parameter 82 - [Maximum Speed] is changed, the speed Reference scaling also changes. To determine Reference scaling, use:

(Parameter 82 / Parameter 55) * 32767 = Scaling

Using parameter 82 and 55 default values, speed Reference scaling is:

$$(60 \text{ Hz} / 130 \text{ Hz}) * 32767 = 15123$$


Therefore, 0...15123 = 0...60.0 Hz.

If parameter 82 - [Maximum Speed] is changed to 90 Hz, then:

$$(90 \text{ Hz} / 130 \text{ Hz}) * 32767 = 22685$$

Therefore, 0...22685 = 0...90.0 Hz.

A graphic representation of this Reference scaling is shown below:



For PowerFlex 70 EC drives (firmware v2.xxx or higher) or PowerFlex 700 VC drives (firmware v3.xxx or higher), parameter 298 - [DPI Ref Select] was added to simplify scaling for the speed Reference. When parameter 298 - [DPI Ref Select] is set to its default “0” (Max Freq), the speed Reference scaling is as shown above. However, when parameter 298 - [DPI Ref Select] is set to “1” (Max Speed), the speed Reference scaling is equal to parameter 82 - [Max Speed]:

Parameter 82 = Scaling

Therefore, 0...32767 = 0...60.0 Hz.

If parameter 82 - [Maximum Speed] is changed to 90 Hz, then:

$$90 \text{ Hz} = 32767$$

Speed Feedback uses the same scaling as the speed Reference.

► **TIP:** For PowerFlex 700 VC drives (firmware v3.xxx or higher), Parameter 299 - [DPI Fdbk Select] enables you to select the feedback data coming from the drive over DPI. The default is “Speed Fdbk” in Hz or RPM determined by Parameter 079 - [Speed Units]. The data selection for Parameter 299 is also displayed on the 1st line of the HIM and on DriveExplorer and DriveExecutive screens in the drive status area of the screen.

For Reference/Feedback details about other DPI drives, refer to their respective User Manuals.

Using Datalinks

A Datalink is a mechanism used by PowerFlex drives to transfer data to and from the controller. Datalinks allow a drive parameter value to be read or written without using an SDO explicit message. When enabled, each Datalink occupies two 16-bit or 32-bit words in both the input and output image. Use adapter **Parameter 08 - [Datalink Size]** to determine whether the drive uses 16-bit or 32-bit words for Datalinks.

Rules for Using Datalinks

- Each set of Datalink parameters in a PowerFlex drive can be used by only one adapter. If more than one adapter is connected to a single drive, multiple adapters cannot use the same Datalink.
- Parameter settings in the drive determine the data passed through the Datalink mechanism. Refer to the documentation for your drive.
- When you use a Datalink to change a value, the value is NOT written to the Non-Volatile Storage (NVS). The value is stored in volatile memory and lost when the drive loses power. Thus, use Datalinks when you need to change a value of a parameter frequently.

Using 16-Bit Datalinks to Read/Write 32-Bit Parameters

This subsection only pertains to PowerFlex 70 (SC or EC), PowerFlex 700 (SC), and PowerFlex 700H drives which use 16-bit Datalinks. To read or write a 32-bit parameter using 16-bit Datalinks, typically both Datalinks of a pair (A, B, C, D) are set to the same 32-bit parameter. For example, to read Parameter 10 - [Elapsed Run Time] in a PowerFlex 70 drive, both Datalink A1 Out and Datalink A2 Out are set to “10.” Datalink A1 Out will contain the least significant word (LSW) and Datalink A2 Out will contain the most significant word (MSW).

32-bit data is stored in binary as follows:

MSW	2^{31} through 2^{16}
LSW	2^{15} through 2^0

In this example, the Parameter 10 - [Elapsed Run Time] value of 6553.9 Hrs is read as “6553.9” in Datalink A1 Out and Datalink A2 Out.

Datalink	Word	Parameter	Data (Hex)
A1 Out	LSW	10	0003
A2 Out	MSW	10	0001

Conversion Example:

Parameter 010 - [Elapsed Run Time] = 6553.9 Hrs
 MSW = $0001_{\text{hex}} = 0001_{\text{binary}} = 2^{16} = 65536$
 LSW = $0003_{\text{hex}} = 3$
 Engineering Value = $65536 + 3 = 65539$
 Parameter 10 Displayed Value = 6553.9 Hrs

Regardless of the Datalink combination, Datalink x1 Out will always contain the LSW and Datalink x2 Out will always contain the MSW. In the following example, the PowerFlex 70 drive Parameter 242 - [Power Up Marker] contains a value of 88.4541 hours.

Datalink	Word	Parameter	Data (Hex)
A2 Out	MSW	242	000D
B1 Out	LSW	242	7F3D

Conversion Example:

Parameter 242 - [Power Up Marker] = 88.4541 hours
 MSW = $000D_{\text{hex}} = 1101_{\text{binary}} = 2^{19} + 2^{18} + 2^{16} = 851968$
 LSW = $7F3D_{\text{hex}} = 32573$
 Engineering Value = $851968 + 32573 = 884541$
 Parameter 242 Displayed Value = 88.4541 Hrs

Transmit PDO Mapping

The Transmit PDOs have a default mapping as shown in [Table 5.F](#). The mapping can be changed if desired. Since every PDO can contain up to eight bytes of data, it is possible to map, for example, Datalink A1, A2, C1, and C2 to the same PDO number when using a drive with 16-bit Datalinks.

Table 5.F Default TPDO Mapping

TPDO#	Default Mapping	Enabled	Remap	Initial Transmission Type ⁽¹⁾
1	Product Logic Status (0x2201) +Feedback 16-bit (0x2204)	Yes	No	254 (Asynchronous, COS)
2	Datalink A1 Out 16-bit (0x2216) +Datalink A2 Out 16-bit (0x2218)	No	Yes	253 (Asynchronous, RTR)
3	Datalink B1 Out 16-bit (0x221A) +Datalink B2 Out 16-bit (0x221C)	No	Yes	253 (Asynchronous, RTR)
4	Datalink C1 Out 16-bit (0x221E) +Datalink C2 Out 16-bit (0x2220)	No	Yes	253 (Asynchronous, RTR)
5	Datalink D1 Out 16-bit (0x2222) +Datalink D2 Out 16-bit (0x2224)	No	Yes	253 (Asynchronous, RTR)

⁽¹⁾ [Table 5.H](#) shows the transmission types for the PDO.

Important: For a 32-bit drive, PDO mapping must be changed from their default values.



TIP: If a 32-bit drive parameter is mapped to a Datalink pair, it is not recommended to map part of the pair (that is, A1 or A2) to two different PDOs since this can give data inconsistency.

Receive PDO Mapping

The Receive PDOs have a default mapping as shown in [Table 5.G](#). The mapping can be changed if desired. Since every PDO can contain up to eight bytes of data, it is possible to map, for example, Datalink A1, A2, C1, and C2 to the same PDO number when using a drive with 16-bit Datalinks.

Table 5.G Default Receive PDO Mapping

TPDO #	Default Mapping	Enabled	Remap	Initial Transmission Type ⁽¹⁾
1	Product Logic Command (0x2200) +Reference 16-bit (0x2202)	Yes	No	254 (Asynchronous)
2	Datalink A1 In 16-bit (0x2206) +Datalink A2 In 16-bit (0x2208)	No	Yes	254
3	Datalink B1 In 16-bit (0x220A) +Datalink B2 In 16-bit (0x220C)	No	Yes	254
4	Datalink C1 In 16-bit (0x220E) +Datalink C2 Out 16-bit (0x2210)	No	Yes	254
5	Datalink D1 In 16-bit (0x2212) +Datalink D2 In 16-bit (0x2214)	No	Yes	254

⁽¹⁾ [Table 5.H](#) shows the transmission types for the PDO. For RPDOs, only the transmission is important (synchronous or asynchronous).



TIP: If a 32-bit drive parameter is mapped to a Datalink pair, it is not recommended to map part of the pair (that is, A1 or A2) to two different PDOs since this can give data inconsistency.

Table 5.H PDO Transmission Types

Transmission Type ⁽¹⁾	PDO Transmission				
	Cyclic	Acyclic	Synchronous	Asynchronous	RTR Only
0		✓	✓		
1...240	✓		✓		
241...251	Reserved				
252			✓		✓
253				✓	✓
254				✓	
255				✓	

⁽¹⁾ Transmission type 255 is not used in this application.

Using Service Data Objects

This chapter provides information and examples that explain how to use Service Data Objects (SDOs) to configure and monitor the adapter and connected PowerFlex 7-Class drive.

Topic	Page
About Service Data Objects	6-1
Running Service Data Objects	6-2
CANopen DPI Parameter Access	6-2
CANopen DPI Full Parameter Access	6-3



ATTENTION: Risk of injury or equipment damage exists. The examples in this publication are intended solely for purposes of example. There are many variables and requirements with any application. Rockwell Automation, Inc. does not assume responsibility or liability (to include intellectual property liability) for actual use of the examples shown in this publication.



ATTENTION: Risk of equipment damage exists. If Explicit Messages are programmed to write parameter data to Non-Volatile Storage (NVS) frequently, the NVS will quickly exceed its life cycle and cause the drive to malfunction. Do not create a program that frequently uses Explicit Messages to write parameter data to NVS. Datalinks do not write to NVS and should be used for frequently changed parameters.

About Service Data Objects

Service Data Objects (SDOs) use asynchronous data transmission and are used to access objects without mapping them to an I/O (PDO) connection. With SDOs, you can configure and monitor a slave device's parameters on the CANopen network.


SDO data transmission is much slower, working around the process data channels, to read/write parameters to a drive. This handles one parameter at a time and the user has access to all CANopen objects in the adapter. SDO messages can transfer more than 8-bytes, which is the PDO limit.

Running Service Data Objects

There are five basic events in the Service Data Objects process. The details of each step will vary depending on the type of controller. Refer to the documentation for your controller.

Important: There must be a request message and a response message for all SDOs, whether you are reading or writing data.

Figure 6.1 Service Data Objects Process



Event	Description
1	You format the required data and set up a PLC program to send an SDO request to the CANopen network adapter (download).
2	The CANopen network adapter transmits the SDO Request to the slave device over the network.
3	The slave device transmits the SDO Response back to the CANopen network. The data is stored in the CANopen network buffer.
4	The controller retrieves the SDO Response from the CANopen network's buffer (upload).
5	The SDO is complete.

CANopen DPI Parameter Access

An adapter parameter can be accessed by using the CANopen objects 0x2228 and 0x2229. The parameter request is written to object 0x2228. When the acknowledgement is received, the response to the message is placed in object 0x2229 and the response can be read.

Table 6.A Data Description for Object 0x2228 DPI Parameter Send

Sub Index	Meaning	Type
1	Parameter Access (00 = read, 01 = write byte, 02 = write word, 03 = write 32-bit word)	Byte
2	DPI Port (0...6)	Byte
3	Parameter Number	16-bit Word
4	Parameter value (for writing)	32-bit Word

Table 6.B Data Description for Object 0x2229 DPI Parameter Receive

Sub Index	Meaning	Type
1	Response Status: 0 = No Error 1 = Write only 2 = Value out of range 3 = Parameter does not exist 4 = Other error	Byte
2	Parameter value	32-bit Word

CANopen DPI Parameter Access Communication Example

This example describes how to read adapter **Parameter 1 - [DPI Port]**:

1. Fill out the data structure for CANopen object 0x2228 (DPI Parameter Send) as follows, filling in sub index 1 last.

Sub Index	Value
1	0x00 (Read)
2	0x05 (DPI Port 5)
3	0x01 (Parameter)

2. Send the message by writing to sub index 1.
3. Wait for the acknowledgement.
4. Read the response in object 0x2229 (DPI Parameter Receive).

Sub Index	Value
1	0x00 (Service OK)
2	0x00000005 (Parameter value)

CANopen DPI Full Parameter Access

With the CANopen objects 0x2226 and 0x2227, all DPI objects can be accessed. The request is written to object 0x2226. When the acknowledgment is received, the response to the message is placed in object 0x2227 and the response can be read.

The DPI full object access supports messages up to 96 data bytes. That is, all explicit DPI messages (except flash download) are able to be transmitted/received.

Table 6.C Data Description for Object 0x2226 DPI Object Send

Sub Index	Meaning	Type
1	Service (0x00 = Get Attribute, 0x04 = Set Attribute)	Byte
2	DPI Port (0...6)	Byte
3	Class	Byte
4	Instance	16-bit Word
5	Attribute	Byte
6	Length of request data in bytes (Count starts at sub index 7)	Byte
7	Data (First byte)	Byte
⋮	⋮	⋮
102	Data (Last byte)	Byte

Table 6.D Data Description for Object 0x2227 DPI Object Receive

Sub Index	Meaning	Type
1	Service (0x00 = OK, 0xFF = Error)	Byte
2	Length of response data in bytes (Count starts at sub index 3)	Byte
3	Data (First byte) / Error Status Value	Byte
⋮	⋮	⋮
98	Data (Last byte)	Byte

CANopen DPI Full Access Communication Example

This example describes how to read adapter **Parameter 1 - [DPI Port]**:

1. Fill out the data structure for CANopen object 0x2226 (DPI Object Send) as follows, filling in sub index 1 last.

Sub Index	Value
1	0x00 (Service Get Attribute)
2	0x05 (DPI Port 5)
3	0x03 (Parameter Class)
4	0x0001 (Instance, Parameter 01)
5	0x09 (Attribute - Parameter value)
6	0x00 (Number of bytes that follows)

2. Send the message by writing to sub index 1.
3. Wait for the acknowledgement.
4. Read the response in CANopen object 0x2227 (DPI Object Receive).

Sub Index	Value
1	0x00 (Service OK)
2	0x01 (Length of response data in bytes; count starts at sub index 3)
3	0x05 (Attribute value)

Troubleshooting


This chapter provides information for diagnosing and troubleshooting potential problems with the adapter and network.

Topic	Page
Understanding the Status Indicators	7-1
PORT Status Indicator	7-2
MOD Status Indicator	7-2
NET A (CAN RUN) Status Indicator	7-3
NET B (CAN ERR) Status Indicator	7-3
Viewing Adapter Diagnostic Items	7-4
Viewing and Clearing Events	7-5

Understanding the Status Indicators

The adapter has four status indicators. They can be viewed on the adapter or through the drive cover. See [Figure 7.1](#).

Figure 7.1 Status Indicators (location on drive may vary)



Item	Status Indicator	Description	Page
①	PORT	DPI Connection Status	7-2
②	MOD	Adapter Status	7-2
③	NET A (CAN RUN)	CANopen Run Status	7-3
④	NET B (CAN ERR)	CANopen Error Status	7-3

PORT Status Indicator

This red/green bicolor LED indicates the status of the adapter's connection to the drive as shown in the table below.

Status	Cause	Corrective Action
Off	The adapter is not powered or is not properly connected to the drive.	<ul style="list-style-type: none"> Securely connect the adapter to the drive using the Internal Interface (ribbon) cable. Apply power to the drive.
Flashing Red	The adapter is not receiving a ping message from the drive.	<ul style="list-style-type: none"> Verify that cables are securely connected and not damaged. Replace cables if necessary. Cycle power to the drive.
Steady Red	<p>The drive has refused an I/O connection from the adapter.</p> <p>Another DPI peripheral is using the same DPI port as the adapter.</p>	<p>Important: Cycle power to the drive after making any of the following corrections:</p> <ul style="list-style-type: none"> Verify that all DPI cables on the drive are securely connected and not damaged. Replace cables if necessary. Verify that the DPI drive supports Datalinks. Configure the adapter to use a Datalink that is not already being used by another peripheral.
Steady Orange	The adapter is connected to a product that does not support Allen-Bradley DPI communications.	Connect the adapter to a product that supports Allen-Bradley DPI communications (for example, a PowerFlex 7-Class drive).
Flashing Green	The adapter is establishing an I/O connection to the drive or [DPI I/O Cfg] is configured for all I/O disabled.	<ul style="list-style-type: none"> No action required. This indicator will turn steady green or steady red. Verify Parameter 12 - [DPI I/O Cfg] settings. Normal behavior if no DPI I/O is enabled.
Steady Green	The adapter is properly connected and is communicating with the drive.	No action required.

MOD Status Indicator

This red/green bicolor LED indicates the status of the adapter as shown in the table below.

Status	Cause	Corrective Action
Off	The adapter is not powered or is not properly connected to the drive.	<ul style="list-style-type: none"> Securely connect the adapter to the drive using the Internal Interface (ribbon) cable. Apply power to the drive.
Flashing Red	<p>The adapter has failed the firmware test or the Node Address switch setting is invalid.</p> <p>Bad CRC of adapter parameters or the adapter is being flash upgraded.</p>	<ul style="list-style-type: none"> Clear faults in the adapter. Cycle power to the drive. If cycling power does not correct the problem, the adapter parameter settings may have been corrupted. Reset defaults and reconfigure the adapter. If resetting defaults does not correct the problem, flash the adapter with the latest firmware release.
Steady Red	The adapter has failed the power-on diagnostics test (hardware failure).	<ul style="list-style-type: none"> Cycle power to the drive. Replace the adapter.
Flashing Green	The adapter is operational, but is not transferring I/O data. Normal operation, device in stopped state or pre-operational state.	<ul style="list-style-type: none"> Place the PLC in RUN mode. Program the controller to recognize and transmit I/O to the adapter. Configure the adapter for the program in the controller. Normal behavior if no DPI I/O is enabled.
Steady Green	The adapter is operational and transferring I/O data.	No action required.

NET A (CAN RUN) Status Indicator

This green LED indicates the status of the network connection as shown in the table below.

Status	Cause	Corrective Actions
Off	The adapter and/or network is not powered or the adapter is not properly connected to the network.	<ul style="list-style-type: none"> Securely connect the adapter to the drive using the Internal Interface (ribbon) cable and to the network using a CANopen cable. Correctly connect the CANopen cable to the CANopen 9-pin plug. Apply power to the drive.
Single Flash ⁽¹⁾ Green	The device is in stopped mode.	Place the PLC in RUN mode.
Flashing Green (about 2.5 Hz)	The adapter is properly connected, but is not communicating with any devices on the network.	<ul style="list-style-type: none"> Place the controller in RUN mode. Program the controller to recognize the adapter and transmit I/O. Configure the adapter for the program in the controller.
Steady Green	The adapter is properly connected and communicating on the network.	No action required.

⁽¹⁾ Single flash is one short flash (about 200 ms) followed by a long off phase (about 1000 ms).

NET B (CAN ERR) Status Indicator

This green LED indicates the status of the adapter transmitting on the network as shown in the table below.

Status	Cause	Corrective Actions
Off	No error.	No action required.
Single Flash ⁽¹⁾ Green	At least one of the error counters of the CAN controller has reached or exceeded the warning error (too many error frames).	<ul style="list-style-type: none"> Check controller configuration and connections to the adapter. Cycle power to the drive and the network.
Double Flash ⁽²⁾ Green	A guard event has occurred.	<p>The drive is not responding to the controller within the specified Guard time.</p> <ul style="list-style-type: none"> Check controller configuration and connections to the adapter. Cycle power to the drive and the network.
Steady Green	The CAN controller is bus off.	<ul style="list-style-type: none"> Check network hardware and connections for wiring problems. Check for duplicate node addresses.

⁽¹⁾ Single flash is one short flash (about 200 ms) followed by a long off phase (about 1000 ms).

⁽²⁾ Double flash is two short flashes (about 200 ms each) separated by an off phase (about 200 ms), and then followed by a long off phase (about 1000 ms).

Viewing Adapter Diagnostic Items

If you encounter unexpected communications problems, the adapter’s diagnostic items may help you or Rockwell Automation personnel troubleshoot the problem. Adapter diagnostic items can be viewed using an LCD PowerFlex 7-Class HIM (Diagnostics/Device Items), DriveExplorer software (version 4.01 or higher), or DriveExecutive software (version 3.01 or higher).

Using the HIM to View Adapter Diagnostic Items








Step	Example Screen
<ol style="list-style-type: none"> 1. Access parameters in the adapter. Refer to Using the PowerFlex 7-Class HIM on page 3-2. 2. Press the  or  key to scroll to Diagnostics. 3. Press the  (Enter) key to display the Diagnostics menu in the adapter. 4. Repeat steps 2 and 3 to enter the Device Items option. 5. Press the  or  key to scroll through the items. 	 

Table 7.A Adapter Diagnostic Items

No.	Name	Description
1	Common Logic Cmd	The present value of the Common Logic Command being transmitted to the drive by this adapter.
2	Product Logic Cmd	The present value of the Product Logic Command being transmitted to the drive by this adapter.
3	Reference	The present value of the Reference being transmitted to the drive by this adapter. If the drive indicates a 16-bit Reference size, the Reference value appears in the least significant 16 bits of this diagnostic item, and the most significant 16 bits of this diagnostic item are zero (0).
4	Common Logic Sts	The present value of the Common Logic Status being received from the drive by this adapter.
5	Product Logic Sts	The present value of the Product Logic Status being received from the drive by this adapter.
6	Feedback	The present value of the Feedback being received from the drive by this adapter. If the drive indicates a 16-bit Feedback size, the Feedback value appears in the least significant 16 bits of this diagnostic item, and the most significant 16 bits of this diagnostic item are zero (0).
7	Datalink A1 In	The present value of respective Datalink In being transmitted to the drive by this adapter. If not using a Datalink, this parameter should have a value of zero. If the drive indicates a 16-bit Datalink size, the Datalink value appears in the least significant 16 bits of this diagnostic item, and the most significant 16 bits of this diagnostic item are zero (0).
8	Datalink A2 In	
9	Datalink B1 In	
10	Datalink B2 In	
11	Datalink C1 In	
12	Datalink C2 In	
13	Datalink D1 In	
14	Datalink D2 In	
15	Datalink A1 Out	The present value of respective Datalink Out being received from the drive by this adapter. If the drive indicates a 16-bit datalink size, the value appears in the least significant 16 bits of this diagnostic item, and the most significant 16 bits of this diagnostic item are zero (0).
16	Datalink A2 Out	
17	Datalink B1 Out	
18	Datalink B2 Out	
19	Datalink C1 Out	
20	Datalink C2 Out	
21	Datalink D1 Out	
22	Datalink D2 Out	
23	Field Flash Cnt	Number of times the adapter has been flash updated. (This value is set to zero before the adapter is shipped.)
24	DPI Rx Errors	The present value of the DPI CAN Receive error counter.
25	DPI Tx Errors	The present value of the DPI CAN Transmit error counter.
26	COPN Rx Errors	The present value of the COPN CAN Receive error counter.
27	COPN Tx Errors	The present value of the COPN CAN Transmit error counter.

Viewing and Clearing Events













The adapter has an event queue to record significant events that occur in the operation of the adapter. When such an event occurs, an entry is put into the event queue. You can view the event queue using an LCD PowerFlex 7-Class HIM, DriveExplorer (4.01 or higher) software, or DriveExecutive (3.01 or higher) software.

The event queue can contain up to 32 entries. Eventually the event queue will become full, since its contents are retained through adapter resets. At that point, a new entry replaces the oldest entry. Only an event queue clear operation or adapter power cycle will clear the event queue contents.

Resetting the adapter to defaults has no effect on the event queue.

The adapter event queue is mapped to the CANopen objects 0x2101...0x2108. Event 1 in the event queue is object 0x2101, event 2 is object 0x2102, etc.

Using the HIM to View and Clear Events

Step	Example Screen
<p>Viewing Events</p> <ol style="list-style-type: none"> 1. Access parameters in the adapter. Refer to Using the PowerFlex 7-Class HIM on page 3-2. 2. Press the  or  key to scroll to Diagnostics. 3. Press the  (Enter) key to display the Diagnostics menu in the adapter. 4. Repeat steps 2 and 3 to enter the Events option and then View Event Queue option. 5. Press the  or  key to scroll through events. The most recent event is Event 1. <p>Clearing Events</p> <ol style="list-style-type: none"> 1. Access parameters in the adapter. Refer to Using the PowerFlex 7-Class HIM on page 3-2. 2. Press the  or  key to scroll to Diagnostics. 3. Press the  (Enter) key to display the Diagnostics menu in the adapter. 4. Repeat steps 2 and 3 to enter the Events option and then the Clear Event option or Clr Event Queue option. A message will pop up to confirm that you want to clear the message or queue. 5. Press the  (Enter) key to confirm your request. If Clr Event Queue was selected, all event queue entries will then display "No Event." 	 <p>Main Menu: Diagnostics Parameter Device Select</p>  <p>Event Q: 1 E3 Ping Time Flt</p>  <p>Dgn: Events View Event Queue Clear Event Clr Event Queue</p>

Events

Many events in the event queue occur under normal operation. If you encounter unexpected communications problems, the events may help you or Allen-Bradley personnel troubleshoot the problem. The following events may appear in the event queue:

Table 7.B Adapter Events

Code	Event	Description
1	No Event	Empty event queue entry.
2	DPI Bus Off Flt ⁽¹⁾	A bus-off condition was detected on DPI. This event may be caused by loose or broken cables or by noise.
3	Ping Time Flt ⁽¹⁾	A ping message was not received on DPI within the specified time.
4	Port ID Flt ⁽¹⁾	The adapter is not connected to a correct port on a DPI product.
5	Port Change Flt ⁽¹⁾	The DPI port changed after start up.
6	Host Sent Reset ⁽¹⁾	The drive sent a reset event message.
7	EEPROM Sum Flt ⁽²⁾	The EEPROM in the adapter is corrupt.
8	Online @ 125kbps	The adapter detected that the drive is communicating at 125 kbps.
9	Online @ 500kbps	The adapter detected that the drive is communicating at 500 kbps.
10	Bad Host Flt ⁽³⁾	The adapter was connected to an incompatible product.
11	Dup Port Flt ⁽⁴⁾	Another peripheral with the same port number is already in use.
12	Type 0 Login	The adapter has logged in for Type 0 control.
13	Type 0 Time Flt ⁽¹⁾	The adapter has not received a Type 0 status message within the specified time.
14	DL Login	The adapter has logged into a Datalink.
15	DL Reject Flt ⁽⁵⁾	The drive rejected an attempt to log in to a Datalink because the Datalink is not supported or is used by another peripheral.
16	DL Time Flt ⁽¹⁾	The adapter has not received a Datalink message within the specified time.
17	Control Disabled	The adapter has sent a "Soft Control Disable" command to the drive.
18	Control Enabled	The adapter has sent a "Soft Control Enable" command to the drive.
19	Message Timeout ⁽⁶⁾	A Client-Server message sent by the adapter was not completed within 1 sec.
20	DPI Fault Msg	
21	DPI Fault Clear	A fault was cleared in the adapter.
22	Normal Startup	The adapter successfully started up.
23	NET Comm Flt ⁽⁷⁾	The adapter detected a communications fault on the network.
24	Flt Cfg Error ⁽⁸⁾	The adapter detected a 32-bit fault configuration reference when the drive supports only a 16-bit reference, or the adapter detected a 32-bit fault configuration Datalink value when the drive supports only 16-bit Datalinks.
25	COPN Guard Err ⁽⁷⁾	The node has not been guarded by an NMT master with the <i>Guard Time x LifeTime Factor</i> period. (Enabled if <i>Guard Time</i> <> 0.)
26	COPN Operational	The adapter has received a "Start_Remote_Node" message from the bus.
27	COPN Stopped ⁽⁹⁾	The adapter has received a "Stop_Remote_Node" message from the bus.
28	COPN Pre-Oper ⁽⁹⁾	The adapter has received a "Enter_PRE-OPERATIONAL_State" message from the bus.
29	COPN Reset Comm ⁽¹⁰⁾	The adapter has received a "Reset_Communication" message from the bus.
30	COPN Reset Node ⁽¹⁾	The adapter has received a "Reset_Node" message from the bus.
31	Lang CRC Bad	The language text memory segment is corrupt.

Adapter Actions Upon Events:

- (1) The adapter is reset.
- (2) The adapter awaits a reconfiguration and a reset.
- (3) The adapter is locked in the state where the PORT status indicator is steady orange and waits a reset.
- (4) The adapter is locked in a fault state and awaits reset.
- (5) As many I/O connections as possible are completed. The adapter waits a reconfiguration and a reset.
- (6) An event is logged. (Client-Server is not used for control, so it does not need to be a fault.)
- (7) The communication fault action specified in **Parameter 10 - [Comm Flt Action]** is performed.
- (8) The drive is forced to fault and, thereafter, only "No Operation" commands are sent to the drive until the fault configuration data has been corrected.
- (9) The idle fault action specified in **Parameter 11 - [Idle Flt Action]** is performed.
- (10) The communication fault action specified in **Parameter 10 - [Comm Flt Action]** is performed and the CANopen communication parameters are set to their default values.

Specifications

Appendix A presents the specifications for the adapter.

Topic	Page
Communications	A-1
Electrical	A-1
Mechanical	A-1
Environmental	A-1
Regulatory Compliance	A-2

Communications

Network Protocol Data Rates	CANopen (per CANopen DS301 specification) 10 Kbps, 20 Kbps, 50 Kbps, 125 Kbps, 250 Kbps, 500 Kbps, 800 Kbps or 1 Mbps
Drive Protocol Data Rates	DPI 125 Kbps or 500 Kbps

Electrical

Consumption Grounding	500 mA at 5 VDC supplied by the drive Grounding according to CAN specification is established via two mounting holes in the PCB when connected to the drive.
--------------------------	--

Mechanical

Dimensions Height Length Width	19 mm (0.75 inches) 86 mm (3.39 inches) 78.5 mm (3.09 inches)
Weight	85 g (3 oz.)

Environmental

Temperature Operating Storage	-10...50°C (14...122°F) -40...85°C (-40...185°F)
Relative Humidity	5...95% non-condensing
Atmosphere	Important: The adapter must not be installed in an area where the ambient atmosphere contains volatile or corrosive gas, vapors or dust. If the adapter is not going to be installed for a period of time, it must be stored in an area where it will not be exposed to a corrosive atmosphere.

Regulatory Compliance

Certification	Specification
UL	UL508C
cUL	CAN / CSA C22.2 No. 14-M91
CE	EN50178 and EN61800-3
CTick	EN61800-3

NOTE: This is a product of category C2 according to IEC 61800-3. In a domestic environment this product may cause radio interference in which case supplementary mitigation measures may be required.

Adapter Parameters

Appendix B provides information about the adapter parameters.

Topic	Page
About Parameter Numbers	B-1
Parameter List	B-1



About Parameter Numbers

The parameters in the adapter are numbered consecutively. However, depending on which configuration tool you use, they may have different numbers.

Configuration Tool	Numbering Scheme
<ul style="list-style-type: none"> HIM DriveExplorer DriveExecutive 	The adapter parameters begin with parameter 01. For example, Parameter 01 - [DPI Port] is parameter 01 as indicated by this manual.

Parameter List

Parameter No.	Name and Description	Details
01	[DPI Port] Displays the port to which the adapter is connected. This will usually be port 5.	Default: 5 Minimum: 0 Maximum: 7 Type: Read Only
02	[DPI Data Rate] Displays the data rate used by the drive. This data rate is set in the drive and the adapter detects it.	Default: 0 = 125 kbps Values: 0 = 125 kbps 1 = 500 kbps Type: Read Only
03	[COPN Addr Cfg] Sets the CANopen node address used by the adapter if the Node Address switches (Figure 2.1) are both set to "0."	Default: 1 Minimum: 1 Maximum: 127 Type: Read/Write Reset Required: Yes
04	[COPN Addr Act] Displays the CANopen node address actually used by the adapter.	Default: 0 Minimum: 0 Maximum: 255 Type: Read/Write Reset Required: Yes
05	[COPN Rate Cfg] Sets the network data rate at which the adapter communicates if the Data Rate switch (Figure 2.2) is set to "PGM." (Updates Parameter 06 - [COPN Rate Act] after a reset.)	Default: 5 = 500 Kbps Values: 0 = 10 Kbps 1 = 20 Kbps 2 = 50 Kbps 3 = 125 Kbps 4 = 250 Kbps 5 = 500 Kbps 6 = 800 Kbps 7 = 1 Mbps Type: Read/Write Reset Required: Yes

Parameter		
No.	Name and Description	Details
06	<p>[COPN Rate Act]</p> <p>Displays the network data rate actually used by the adapter.</p>	<p>Default: 5 = 500 Kbps</p> <p>Values: 0 = 10 Kbps 1 = 20 Kbps 2 = 50 Kbps 3 = 125 Kbps 4 = 250 Kbps 5 = 500 Kbps 6 = 800 Kbps 7 = 1 Mbps</p> <p>Type: Read Only</p>
07	<p>[Ref/Fdbk Size]</p> <p>Displays the size of the Reference/Feedback. The drive determines the size of the Reference/Feedback.</p>	<p>Default: 0 = 16-bit</p> <p>Values: 0 = 16-bit 1 = 32-bit</p> <p>Type: Read Only</p>
08	<p>[Datalink Size]</p> <p>Displays the size of each Datalink word. The drive determines the size of Datalinks.</p>	<p>Default: 0 = 16-bit</p> <p>Values: 0 = 16-bit 1 = 32-bit</p> <p>Type: Read Only</p>
09	<p>[Reset Module]</p> <p>No action if set to "0" (Ready). Resets the adapter if set to "1" (Reset Module). Restores the adapter to its factory default settings if set to "2" (Set Defaults). This parameter is a command. It will be reset to "0" (Ready) after the command has been performed.</p>	<p>Default: 0 = Ready</p> <p>Values: 0 = Ready 1 = Reset Module 2 = Set Defaults</p> <p>Type: Read/Write</p> <p>Reset Required: No</p>
<p> ATTENTION: Risk of injury or equipment damage exists. If the adapter is transmitting I/O that controls the drive, the drive may fault when you reset the adapter. Determine how your drive will respond before resetting a connected adapter.</p>		
10	<p>[Comm Flt Action]</p> <p>Sets the action that the adapter and drive will take if the adapter detects that CANopen communications have been disrupted. This setting is effective only if I/O that controls the drive is transmitted through the adapter.</p>	<p>Default: 0 = Fault</p> <p>Values: 0 = Fault 1 = Stop 2 = Zero Data 3 = Hold Last 4 = Send Flt Cfg</p> <p>Type: Read/Write</p> <p>Reset Required: No</p>
<p> ATTENTION: Risk of injury or equipment damage exists. Parameter 10 - [Comm Flt Action] lets you determine the action of the adapter and connected drive if I/O communications are disrupted. By default, this parameter faults the drive. You can set this parameter so that the drive continues to run. Precautions should be taken to ensure that the setting of this parameter does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).</p>		
11	<p>[Idle Flt Action]</p> <p>Sets the action that the adapter and drive will take if the adapter is put in the Pre-Operational State.</p>	<p>Default: 0 = Fault</p> <p>Values: 0 = Fault 1 = Stop 2 = Zero Data 3 = Hold Last 4 = Send Flt Cfg</p> <p>Type: Read/Write</p> <p>Reset Required: No</p>

Parameter										
No.	Name and Description	Details								
12	<p>[DPI I/O Cfg]</p> <p>Sets the I/O that is transferred through the adapter.</p>	Default:	xxx0 0001							
		Bit Values:	0 = I/O disabled 1 = I/O enabled							
		Type:	Read/Write							
		Reset Required:	Yes							
		Bit Definition	Not Used	Not Used	Not Used	Datalink D	Datalink C	Datalink B	Datalink A	Cmd/Ref
		Default	x	x	x	0	0	0	0	1
		Bit	7	6	5	4	3	2	1	0
13	<p>[DPI I/O Act]</p> <p>Displays the I/O that the adapter is actively transmitting. The value of this parameter will usually be equal to the value of Parameter 12 - [DPI I/O Cfg].</p>	Default:	xxx0 0001							
		Bit Values:	0 = I/O disabled 1 = I/O enabled							
		Type:	Read Only							
		Bit Definition	Not Used	Not Used	Not Used	Datalink D	Datalink C	Datalink B	Datalink A	Cmd/Ref
		Default	x	x	x	0	0	0	0	1
		Bit	7	6	5	4	3	2	1	0
14	<p>[Fit Cfg Logic]</p> <p>Sets the Logic Command data that is sent to the drive if any of the following is true:</p> <ul style="list-style-type: none"> • Parameter 10 - [Comm Flt Action] is set to “4” (Send Flt Cfg) and I/O communications are disrupted. • Parameter 11 - [Idle Flt Action] is set to “4” (Send Flt Cfg) and the adapter is put in the Pre-Operational State. <p>The bit definitions will depend on the product to which the adapter is connected. See Appendix D or the documentation for the drive being used.</p>	Default:	0000 0000 0000 0000							
		Minimum:	0000 0000 0000 0000							
		Maximum:	1111 1111 1111 1111							
		Type:	Read/Write							
		Reset Required:	No							
15	<p>[Fit Cfg Ref]</p> <p>Sets the Reference data that is sent to the drive if any of the following is true:</p> <ul style="list-style-type: none"> • Parameter 10 - [Comm Flt Action] is set to “4” (Send Flt Cfg) and I/O communications are disrupted. • Parameter 11 - [Idle Flt Action] is set to “4” (Send Flt Cfg) and the adapter is put in the Pre-Operational State. 	Default:	0							
		Minimum:	0							
		Maximum:	4294967295							
		Type:	Read/Write							
		Reset Required:	No							
		Important:	If the drive uses a 16-bit Reference, the most significant word of this value must be set to zero (0) or a fault will occur.							

Parameter		
No.	Name and Description	Details
16	[Fit Cfg A1 In]	Default: 0
17	[Fit Cfg A2 In]	Default: 0
18	[Fit Cfg B1 In]	Default: 0
19	[Fit Cfg B2 In]	Default: 0
20	[Fit Cfg C1 In]	Default: 0
21	[Fit Cfg C2 In]	Default: 0
22	[Fit Cfg D1 In]	Default: 0
23	[Fit Cfg D2 In]	Default: 0
	<p>Sets the data that is sent to the Datalink in the drive if any of the following is true:</p> <ul style="list-style-type: none"> • Parameter 10 - [Comm Flt Action] is set to “4” (Send Flt Cfg) and I/O communications are disrupted. • Parameter 11 - [Idle Flt Action] is set to “4” (Send Flt Cfg) and the adapter is put in the Pre-Operational State. <p>These are 32-bit values. When using a 16-bit Datalink, only the least significant word will be used. If the 32-bit value is out of range for the 16-bit Datalink, a configuration error will force a correction before I/O can be enabled.</p>	<p>Minimum: 0 Maximum: 4294967295 Type: Read/Write Reset Required: No</p> <p>Important: If the drive uses 16-bit Datalinks, the most significant word of this value must be set to zero (0) or a fault will occur.</p>
24	[PDO1 Trigger]	<p>Default: 0 = COS Values: 0 = COS 1 = Cyclic Type: Read/Write Reset Required: Yes</p>
25	[COS Status Mask]	<p>Default: 0000 0000 0000 0000 Minimum: 0000 0000 0000 0000 Maximum: 1111 1111 1111 1111 Values: 0 = Ignore bit 1 = Check bit Type: Read/Write Reset Required: No</p>
26	[COS Fdbk Change]	<p>Default: 1 Minimum: 1 Maximum: 4294967295 Type: Read/Write Reset Required: No</p>
27	[Cyc Interval]	<p>Default: 0.02 seconds Minimum: 0.02 seconds Maximum: 655.35 seconds Type: Read/Write Reset Required: No</p>

CANopen Objects

Appendix D presents information about the CANopen objects implemented in this adapter.

Topic	Page
CANopen Object Tables	C-1
Emergency Object	C-4

CANopen Object Tables

The tables in this section describe the implemented CANopen objects. [Table C.A](#) describes the objects for the communication profile and [Table C.B](#) describes the manufacturer specific objects.

Table C.A Communication Profile Area

Index	Sub Index	Type	Access	Name and Description
0x1000	0	U32	Read	<i>Device Type.</i> Describes the type of device.
0x1001	0	U8		<i>Error register Bit 0.</i> Indicates that a generic error has occurred.
0x1003	0	U8	Read/Write	<i>Number of errors.</i> Writing a 0 to this sub index clears the list. The error list starts at sub index 1.
	1...5	U32	Read	<i>Pre-defined error field.</i> A list of errors that have occurred. Sub index 1 contains the most recent error.
0x1005	0	U32	Read/Write	<i>COB-ID Sync.</i> This is the ID for the sync message.
0x1008	0	Visible string	Read	<i>Manufacturer device name</i> (Family text from DPI Device object)
0x100A	0	Visible string	Read	<i>Manufacturer software version</i> (Product revision from DPI Device object as "SW V.MAJOR.MINOR" string)
0x100C	0	U16	Read/Write	<i>Guard time</i> This parameter is used together with <i>Life time factor</i> for the Life guarding protocol. The NMT master guards the node at this period in milliseconds.
0x100D	0	U8	Read/Write	<i>Life time factor.</i> If the node has not been guarded in the time period <i>Life-time factor x Guard time</i> , a "Guard Error" event is logged and a remote node error is indicated through the "Life Guarding event" service.
0x1014	0	U32	Read/Write	<i>COB-ID EMCY.</i> This is the ID for the Emergency object
0x1400... 0x1404	0	U8	Read	<i>Receive PDO parameter.</i> Number of entries (= 2)
	1	U32	Read/Write	<i>COB ID used by PDO</i>
	2	U8	Read/Write	<i>Transmission type</i>
0x1600... 0x1604	0	U8	Read/Write	<i>Receive PDO mapping.</i> Number of mapped application objects (N)
	1...N	U32	Read/Write	<i>Mapped object #N</i>

Index	Sub Index	Type	Access	Name and Description
0x1800... 0x1804	0	U8	Read	<i>Transmit PDO parameter.</i> Number of entries (= 2)
	1	U32	Read/Write	<i>COB ID used by PDO</i>
	2	U8	Read/Write	<i>Transmission type</i>
0x1A00... 0x1A04	0	U8	Read/Write	<i>Transmit PDO mapping.</i> Number of mapped application objects (N)
	1...N	U32	Read/Write	<i>Mapped object #N</i>

Table C.B Manufacturer Specific Area

Index	Sub index	Type	Access	Name and Description
0x2001... 0x201B	0	(1)	(1)	<i>Parameter mapping.</i> 0x2001 = Comm. adapter parameter 0x01, 0x2002 = Comm. adapter parameter 0x02, etc. The parameter value is mapped.
0x2101... 0x2108	0	U8	Read	<i>DPI Event objects.</i> Number of entries (= 12)
	1	U16	Read	<i>Fault code</i>
	2	U8	Read	<i>Fault Source - DPI Port Number</i>
	3	U8	Read	<i>Fault Source - Device Object Instance</i>
	4	U8	Read	<i>Fault Time Stamp - Least Significant Byte</i>
	5	U8	Read	<i>Fault Time Stamp</i>
	6	U8	Read	<i>Fault Time Stamp</i>
	7	U8	Read	<i>Fault Time Stamp</i>
	8	U8	Read	<i>Fault Time Stamp</i>
	9	U8	Read	<i>Fault Time Stamp</i>
	10	U8	Read	<i>Fault Time Stamp</i>
	11	U8	Read	<i>Fault Time Stamp - Most Significant Byte</i>
	12	U16	Read	<i>Fault Time Stamp - Timer Descriptor</i>
0x2200	0	U16	Read/Write	<i>Product Logic Command</i>
0x2201	0	U16	Read	<i>Product Logic Status</i>
0x2202	0	S16	Read/Write	<i>Reference 16-bit ⁽²⁾</i>
0x2203	0	S32	Read/Write	<i>Reference 32-bit</i>
0x2204	0	S16	Read	<i>Feedback 16-bit ⁽²⁾</i>
0x2205	0	S32	Read	<i>Feedback 32-bit</i>
0x2206	0	S16	Read/Write	<i>Datalink A1 In 16-bit ⁽²⁾</i>
0x2207	0	S32	Read/Write	<i>Datalink A1 In 32-bit</i>
0x2208	0	S16	Read/Write	<i>Datalink A2 In 16-bit ⁽²⁾</i>
0x2209	0	S32	Read/Write	<i>Datalink A2 In 32-bit</i>
0x220A	0	S16	Read/Write	<i>Datalink B1 In 16-bit ⁽²⁾</i>
0x220B	0	S32	Read/Write	<i>Datalink B1 In 32-bit</i>
0x220C	0	S16	Read/Write	<i>Datalink B2 In 16-bit ⁽²⁾</i>
0x220D	0	S32	Read/Write	<i>Datalink B2 In 32-bit</i>
0x220E	0	S16	Read/Write	<i>Datalink C1 In 16-bit ⁽²⁾</i>
0x220F	0	S32	Read/Write	<i>Datalink C1 In 32-bit</i>
0x2210	0	S16	Read/Write	<i>Datalink C2 In 16-bit ⁽²⁾</i>
0x2211	0	S32	Read/Write	<i>Datalink C2 In 32-bit</i>
0x2212	0	S16	Read/Write	<i>Datalink D1 In 16-bit ⁽²⁾</i>
0x2213	0	S32	Read/Write	<i>Datalink D1 In 32-bit</i>
0x2214	0	S16	Read/Write	<i>Datalink D2 In 16-bit ⁽²⁾</i>
0x2215	0	S32	Read/Write	<i>Datalink D2 In 32-bit</i>
0x2216	0	S16	Read	<i>Datalink A1 Out 16-bit ⁽²⁾</i>
0x2217	0	S32	Read	<i>Datalink A1 Out 32-bit</i>
0x2218	0	S16	Read	<i>Datalink A2 Out 16-bit ⁽²⁾</i>
0x2219	0	S32	Read	<i>Datalink A2 Out 32-bit</i>

Index	Sub index	Type	Access	Name and Description
0x221A	0	S16	Read	Datalink B1 Out 16-bit ⁽²⁾
0x221B	0	S32	Read	Datalink B1 Out 32-bit
0x221C	0	S16	Read	Datalink B2 Out 16-bit ⁽²⁾
0x221D	0	S32	Read	Datalink B2 Out 32-bit
0x221E	0	S16	Read	Datalink C1 Out 16-bit ⁽²⁾
0x221F	0	S32	Read	Datalink C1 Out 32-bit
0x2220	0	S16	Read	Datalink C2 Out 16-bit ⁽²⁾
0x2221	0	S32	Read	Datalink C2 Out 32-bit
0x2222	0	S16	Read	Datalink D1 Out 16-bit ⁽²⁾
0x2223	0	S32	Read	Datalink D1 Out 32-bit
0x2224	0	S16	Read	Datalink D2 Out 16-bit ⁽²⁾
0x2225	0	S32	Read	Datalink D2 Out 32-bit
0x2226	0	U8	Read	<i>DPI Object Send.</i> Number of entries (= 0x66)
	1	U8	Read/Write	Service
	2	U8	Read/Write	Port
	3	U8	Read/Write	Class
	4	U16	Read/Write	Instance
	5	U8	Read/Write	Attribute
	6	U8	Read/Write	<i>Length of request in bytes.</i> (Count starts at sub index 7)
	7...102	U8	Read/Write	Data
0x2227	0	U8	Read	<i>DPI Object Receive.</i> Number of entries (= 0x62)
	1	U8	Read	Service
	2	U8	Read	<i>Length of response in bytes.</i> (Count starts at sub index 3)
	3...98	U8	Read	Data
0x2228	0	U8	Read	<i>DPI Parameter send.</i> Number of entries (= 0x04)
	1	U8	Read/Write	Access (00 = Read, 01 = Write)
	2	U8	Read/Write	DPI Port
	3	U16	Read/Write	Parameter number
	4	U32	Read/Write	Parameter value
0x2229	0	U8	Read	<i>DPI Parameter receive.</i> Number of entries (= 0x02)
	1	U8	Read	Response status
	2	U32	Read	Parameter value

⁽¹⁾ Value depends on the mapped communication adapter parameters.

⁽²⁾ If the drive is a 32-bit drive, this object contains 16 bits of the 32-bit value and should not be used.

Emergency Object

The emergency object consists of a total of 8 data bytes. The first three bytes are defined by the CANopen specification, and the remaining 5 bytes are manufacturer specific.

Table C.C Emergency Object Format

Byte	0	1	2	3	4	5	6	7
Content	Emergency error code (See Table C.D)		Error register	Manufacturer specific error files; Byte 3 and Byte 4 = 0, Byte 5 = DPI Port, Byte 6 and 7 = DPI fault code (Byte 6 = LSB)				

Table C.D Implemented Emergency Error Codes

Emergency Error Code	Meaning	Manufacturer specific info
00XX	Error reset or no error	No
10XX	Generic Error	Yes (If fault in DPI adapter, DPI fault code is included.)

Emergency error codes are specified for a number of events, but since the DPI communication adapter is a generic module, all errors are reported as “Generic error.” For faults in the communication adapter itself, the DPI fault code is supplied as manufacturer-specific data.

Logic Command/Status Words

Appendix D presents the definitions of the Logic Command and Logic Status words that are used for some products that can be connected to the adapter. If the Logic Command/Logic Status for the product that you are using is not listed, refer to your product’s documentation.

PowerFlex 7-Class Drives (except PowerFlex 700S) Logic Command Word

Logic Bits																Command	Description
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
															x	Stop ⁽¹⁾	0 = Not Stop 1 = Stop
															x	Start ⁽¹⁾⁽²⁾	0 = Not Start 1 = Start
														x		Jog	0 = Not Jog (Par. 100) 1 = Jog
												x				Clear Faults	0 = Not Clear Faults 1 = Clear Faults
										x	x					Direction	00 = No Command 01 = Forward Command 10 = Reverse Command 11 = Hold Direction Control
										x						Local Control	0 = No Local Control 1 = Local Control
									x							MOP Increment	0 = Not Increment 1 = Increment
						x	x									Accel Rate	00 = No Command 01 = Accel Rate 1 Command (Par. 140) 10 = Accel Rate 2 Command (Par. 141) 11 = Hold Accel Rate
				x	x											Decel Rate	00 = No Command 01 = Decel Rate 1 Command (Par. 142) 10 = Decel Rate 2 Command (Par. 143) 11 = Hold Decel Rate
x	x	x														Reference Select ⁽³⁾	000 = No Command 001 = Ref A Select (Par. 90) 010 = Ref B Select (Par. 93) 011 = Preset 3 (Par. 103) 100 = Preset 4 (Par. 104) 101 = Preset 5 (Par. 105) 110 = Preset 6 (Par. 106) 111 = Preset 7 (Par. 107)
x																MOP Decrement	0 = Not Decrement 1 = Decrement

⁽¹⁾ A “0 = Not Stop” condition (logic 0) must first be present before a “1 = Start” condition will start the drive. The Start command acts as a momentary Start command. A “1” will start the drive, but returning to “0” will not stop the drive.

⁽²⁾ This Start will not function if a digital input (parameters 361-366) is programmed for 2-Wire Control (option 7, 8 or 9).

⁽³⁾ This Reference Select will not function if a digital input (parameters 361-366) is programmed for “Speed Sel 1, 2 or 3” (option 15, 16 or 17). Note that Reference Select is “Exclusive Ownership” – see drive User Manual for more information.

Logic Status Word

Logic Bits																Status	Description
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
															x	Ready	0 = Not Ready (Par. 214) 1 = Ready
															x	Active	0 = Not Active (Running) 1 = Active
														x		Command Direction	0 = Reverse 1 = Forward
												x				Actual Direction	0 = Reverse 1 = Forward
											x					Accel	0 = Not Accelerating 1 = Accelerating
										x						Decel	0 = Not Decelerating 1 = Decelerating
									x							Alarm	0 = No Alarm (Par. 211 & 212) 1 = Alarm
								x								Fault	0 = No Fault (Par. 243) 1 = Fault
							x									At Speed	0 = Not At Reference 1 = At Reference
				x	x	x										Local Control ⁽¹⁾	000 = Port 0 (TB) 001 = Port 1 010 = Port 2 011 = Port 3 100 = Port 4 101 = Port 5 110 = Port 6 111 = No Local
x	x	x	x													Reference	0000 = Ref A Auto (Par. 90) 0001 = Ref B Auto (Par. 93) 0010 = Preset 2 Auto 0011 = Preset 3 Auto 0100 = Preset 4 Auto 0101 = Preset 5 Auto 0110 = Preset 6 Auto 0111 = Preset 7 Auto 1000 = Term Blk Manual 1001 = DPI 1 Manual 1010 = DPI 2 Manual 1011 = DPI 3 Manual 1100 = DPI 4 Manual 1101 = DPI 5 Manual 1110 = DPI 6 Manual 1111 = Jog Ref

⁽¹⁾ See "Owners" in drive User Manual for further information.

PowerFlex 700S Drives Logic Command Word (Phase II Control)

Logic Bits																Command	Description																																								
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0																																										
															x	Normal Stop	0 = Not Normal Stop 1 = Normal Stop																																								
															x	Start ⁽¹⁾	0 = Not Start 1 = Start																																								
														x		Jog 1	0 = Not Jog using [Jog Speed 1] (Par. 29) 1 = Jog using [Jog Speed 1] (Par. 29)																																								
												x				Clear Fault ⁽²⁾	0 = Not Clear Fault 1 = Clear Fault																																								
										x	x					Unipolar Direction	00 = No Command 01 = Forward Command 10 = Reverse Command 11 = Hold Direction Control																																								
									x							Reserved																																									
								x								Jog 2	0 = Not Jog using [Jog Speed 2] (Par. 39) 1 = Jog using [Jog Speed 2] (Par. 39)																																								
							x									Current Limit Stop	0 = Not Current Limit Stop 1 = Current Limit Stop																																								
						x										Coast Stop	0 = Not Coast to Stop 1 = Coast to Stop																																								
					x											Reserved																																									
				x												Reserved																																									
			x													Spd Ref Sel0	<table border="1"> <thead> <tr> <th colspan="3">Bits</th> <th></th> </tr> <tr> <th>14</th><th>13</th><th>12</th><th></th> </tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>0</td><td>= Spd Ref A (Par. 27)</td> </tr> <tr> <td>0</td><td>0</td><td>1</td><td>= Spd Ref B (Par. 28)</td> </tr> <tr> <td>0</td><td>1</td><td>0</td><td>= Preset 2 (Par. 15)</td> </tr> <tr> <td>0</td><td>1</td><td>1</td><td>= Preset 3 (Par. 16)</td> </tr> <tr> <td>1</td><td>0</td><td>0</td><td>= Preset 4 (Par. 17)</td> </tr> <tr> <td>1</td><td>0</td><td>1</td><td>= Preset 5 (Par. 18)</td> </tr> <tr> <td>1</td><td>1</td><td>0</td><td>= Preset 6 (Par. 19)</td> </tr> <tr> <td>1</td><td>1</td><td>1</td><td>= Preset 7 (Par. 20)</td> </tr> </tbody> </table>	Bits				14	13	12		0	0	0	= Spd Ref A (Par. 27)	0	0	1	= Spd Ref B (Par. 28)	0	1	0	= Preset 2 (Par. 15)	0	1	1	= Preset 3 (Par. 16)	1	0	0	= Preset 4 (Par. 17)	1	0	1	= Preset 5 (Par. 18)	1	1	0	= Preset 6 (Par. 19)	1	1	1	= Preset 7 (Par. 20)
Bits																																																									
14	13	12																																																							
0	0	0	= Spd Ref A (Par. 27)																																																						
0	0	1	= Spd Ref B (Par. 28)																																																						
0	1	0	= Preset 2 (Par. 15)																																																						
0	1	1	= Preset 3 (Par. 16)																																																						
1	0	0	= Preset 4 (Par. 17)																																																						
1	0	1	= Preset 5 (Par. 18)																																																						
1	1	0	= Preset 6 (Par. 19)																																																						
1	1	1	= Preset 7 (Par. 20)																																																						
		x														Spd Ref Sel1																																									
	x															Spd Ref Sel2																																									
x																Reserved																																									

⁽¹⁾ A Not Stop condition (logic bit 0 = 0, logic bit 8 = 0, and logic bit 9 = 0) must first be present before a 1 = Start condition will start the drive.

⁽²⁾ To perform this command, the value must switch from “0” to “1.”

Logic Status Word (Phase II Control)

Logic Bits																Status	Description
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
															x	Active	0 = Not Active 1 = Active
															x	Running	0 = Not Running 1 = Running
														x		Command Direction	0 = Reverse 1 = Forward
												x				Actual Direction	0 = Reverse 1 = Forward
											x					Accel	0 = Not Accelerating 1 = Accelerating
										x						Decel	0 = Not Decelerating 1 = Decelerating
									x							Jogging	0 = Not Jogging 1 = Jogging
								x								Fault	0 = No Fault (Par. 323, 324, 325) 1 = Fault
							x									Alarm	0 = No Alarm (Par. 326, 327, 328) 1 = Alarm
						x										Flash Mode	0 = Not in Flash Mode 1 = In Flash Mode
					x											Run Ready	0 = Not Ready to Run (Par. 156) 1 = Ready to Run
				x												At Limit ⁽¹⁾	0 = Not At Limit (Par. 304) 1 = At Limit
			x													Tach Loss Sw	0 = Not Tach Loss Sw 1 = Tach Loss Sw
		x														At Zero Spd	0 = Not At Zero Speed 1 = At Zero Speed
	x															At Setpt Spd	0 = Not At Setpoint Speed 1 = At Setpoint Speed
x																Enable	0 = Not Enabled 1 = Enabled

⁽¹⁾ See Parameter 304 - [Limit Status] in the PowerFlex 700S drive User Manual for a description of the limit status conditions.

CANopen Network Example


This appendix provides instructions on how to use the IXXAT CANopen Configuration Studio and the *Mauell CoDeSys AA* programming software to configure the *Mauell Telmatic ME-series* of PLC hardware.

Topic	Page
Example Network	E-1
Configuring the Network Nodes	E-2
Configuring the Communications	E-8
Configuring the PLC Variables and Linking	E-9
Configuring the PDOs, SDOs, and SYNC	E-16
Downloading Configuration	E-20
PLC Program	E-22

Example Network


After the adapter is configured, the connected drive and adapter are a single node on the network. This appendix provides the steps that are needed to configure a simple network like the network shown in [Figure E.1](#). A PC/CAN-Interface card (for example tinCAN from IXXAT) is needed to configure the CANopen network with the computer. In our example, the drive is configured for using Logic Command/Status, Reference/Feedback and all Datalinks over the network.

Figure E.1 Example CANopen Network




Configuring the Network Nodes


1. Start the IXXAT CANopen Configuration Studio and click on **New Project**.



2. Type in a project name and click **OK**. A subdirectory is created which contains all files relevant to this project.




3. The database of the new project has now been created. The icons in the toolbar of the project are plug-ins that can be used with each section of the project. Note that some icons appear dimmed (unavailable).




4. Right click on the project icon and select **Network Properties**. Change the baud rate to the desired value and click **OK**.


NOTE: In this example, the baud rate 1000 kBaud has been used, which is the maximum allowable baud rate for CANopen. However, the standard baud rate of the Mauell Telmatic PLC is 500 kBaud.




- Right click on the project name and select **New Group**.




- Enter the **Name** and a **Description** (optional) and select an **Icon** (optional) for the new group. Click **OK**.




7. Select the new group and click the **Module selection** icon.




8. Select the hardware being used (V18 CN32), provide a **Name**, and adjust the **Node Address** and the **Baud Rate**. In this example, the node address of the PLC is set to 1, and the baud rate is set to 1000 Kbps. Click **OK**.




9. Click **aktualisieren (apply)** in the appearing window to build the configuration of the PLC. (Note the status bar at the bottom of the window.) Close the window after completion (no activity).




10. The project pane now shows the PLC at node 0x1 (hexadecimal notation). If the PLC is not visible, expand the tree with the (+) sign.




11. Generate a new group for the I/O. To do this, right click on the project again and select **New Group**.




12. Enter the **Name** and a **Description** (optional), and select an **Icon** (optional) for the new group. Click **OK**.




13. Right click on the new group and select **New Device**.




- Enter the **Name**, **Node ID**, **Baudrate**, and a **Description** (optional).




- Click **Select EDS...** and browse to the folder where the EDS files are stored. In this example, select *C01_de08.eds* in the folder *...\\Eds\C-Module* for the digital input.




- Click the **Icon** browse button and select the digital input icon *S_de.ico* in the icon folder. Click **Öffnen (Open)** in the **Choose Icon** window, and then click **OK** in the **Device Properties** window.






17. The project pane now shows the digital input module at address 0x2.




18. Repeat steps 11 through 16 for a new group with the PowerFlex drive (Node ID 7, 20COMM301_V101.eds, PF70.ico). The completed project pane is shown below.




Configuring the Communications


1. Select the PLC and click the **Communications** icon.



2. Select **Options > Serial Ports**.




3. Select the **3964R** tab, and uncheck the **spontaneous transmission (changed values)** and **cyclic transmission** boxes. Without these changes, the PLC would switch to error state because of a transmission failure on its own RS232 port.




4. Click **Ok** to close the **serial ports** window.

Configuring the PLC Variables and Linking



1. Select the project and click the **Visual Object Linker** icon.




2. The **Visual Object Linker** window has 3 tabs: **Link Matrix**, **Connection Listing**, and **PLC Setup**. Select the **PLC Setup** tab and click **Add...** to define the internal variables of the PLC. Create these variables carefully because they appear in the PLC program.




3. Create a variable to store the digital inputs from the digital input module. Select **Unsigned8** and **Network Output... - Consumer**, and enter a **Name**. Click **Add**. The variable appears in the network variables list on the **PLC Setup** tab.



4. Create the remaining network variables as shown in the next screen below. They are all **Unsigned16** and **Producers** (PLC outputs). To make the program more flexible in case all Datalinks should be used in the future, allocate these links with general variable names, such as **DLinkP_C1**, where P means producer.




5. Create the remaining network variables as shown in the next screen below. They are all **Unsigned16** and **Consumers** (PLC inputs).



- ▶ **TIP:** To get a better overview, sort the table by OD-Index.
- ▶ **TIP:** If the program should automatically start after the PLC has been powered up, select **Start** under the **Program State:** selections.


- Return to the **Link Matrix** tab, where the configured variables are listed. As an EDS file has been assigned to each hardware, the various I/Os are also listed in the Producer/Consumer areas. The producer items are shown in left side rows running top to bottom, and the consumer items are in top columns running left to right. Producers have an outgoing arrow (they produce onto the network), and consumers have an incoming arrow (they consume from the network). It is possible to selectively view parts of the project by adjusting the drop down boxes.



- Link the Producers to the Consumers. To do so, position the mouse over a connection point. The connection point appears blue if it is valid, or red if it is invalid. Double click the connection point and it will turn yellow. Click the **Calculate Connections** icon at the top left of the screen, and if the connection is made, it will turn green.



TIP: The variables are mapped to the PDOs in the order in which the connections are made.



- Confirmation and printout of all connections can be seen on the **Connection Listing** tab. Leave the **Visual Objects Linker** window open and return to the project.


#	ConnectionName	COB-ID	TxNode	TxPDO#	TxObject	RxNode	RxPDO#	RxObject
1	LogicCmd	0x181	1	0x01	A100sub01	7	0x01	2200sub00
2	SpeedRef	0x181	1	0x01	A100sub02	7	0x01	2202sub00
3	AccelTime1	0x181	1	0x01	A100sub03	7	0x01	2206sub00
4	BrakeLevel	0x181	1	0x01	A100sub04	7	0x01	2208sub00
10	CurrentLimit	0x281	1	0x02	A100sub05	7	0x02	220Asub00
11	JogFreq	0x281	1	0x02	A100sub06	7	0x02	220Csub00
12	DLinkP_C1	0x281	1	0x02	A100sub07	7	0x02	220Esub00
13	DLinkP_C2	0x281	1	0x02	A100sub08	7	0x02	2210sub00
16	DLinkP_D1	0x381	1	0x03	A100sub09	7	0x03	2212sub00
17	DLinkP_D2	0x381	1	0x03	A100sub0A	7	0x03	2214sub00
9	BE_02	0x200	2	0x05	6000sub01	1	0x01	A4C0sub01
5	Product Logic Status	0x187	7	0x01	2201sub00	1	0x02	A580sub02
6	Feedback 16 bit	0x187	7	0x01	2204sub00	1	0x02	A580sub03
14	Datalink A1 Out 16 bit	0x287	7	0x02	2216sub00	1	0x03	A580sub04
15	Datalink A2 Out 16 bit	0x287	7	0x02	2218sub00	1	0x03	A580sub05
18	Datalink B1 Out 16 bit	0x387	7	0x03	221Asub00	1	0x04	A580sub06
19	Datalink B2 Out 16 bit	0x387	7	0x03	221Csub00	1	0x04	A580sub07
20	Datalink C1 Out 16 bit	0x487	7	0x04	221Esub00	1	0x05	A580sub08
21	Datalink C2 Out 16 bit	0x487	7	0x04	2220sub00	1	0x05	A580sub09
7	Datalink D1 Out 16 bit	0x187	7	0x01	2222sub00	1	0x02	A580sub0A
8	Datalink D2 Out 16 bit	0x187	7	0x01	2224sub00	1	0x02	A580sub0B




TIP: Sorting by TxPDO# or RxPDO# will group all Consumers and Producers.

Configuring the PDOs, SDOs, and SYNC

1. Select the PowerFlex70 and click the **Device Configuration** icon in the project toolbar.




2. On the **Process Data Objects** tab, the **Transmission Type** of all PDOs can be configured (sub-tab **Properties**) and the PDO mapping can be checked and adjusted (sub-tab **Mapping**).




- A. Set the **Transmission Type** of all RPDOs to **asynchronous (Manuf. Event)**.
- B. Set the **Transmission Type** of the TPDO1 also to **asynchronous (Manuf. Event)**, so the adapter sends this PDO whenever the state of the drive has changed.
- C. Set the **Transmission Type** of the TPDO2 and TPDO3 to **synchronous cyclic** and the **Transmission Rate** to “10,” so these Datalinks are sent periodically with a cyclic interval of (10 x *Communication Cycle Period*).

- On the **Predefined Objects** tab, check the **Device consumes SYNC message** box (sub-tab **Synchronisation Message**).




- Select the PLC and click the **Device Configuration** icon in the project toolbar.




- On the **Process Data Objects** tab, set the **Transmission Type** of the RPDOs to **asynchronous (Manuf. Event)**. For RPDOs, only the transmission mode (synchronous or asynchronous) is relevant.

Leave the **Transmission Type** of all TPDOs set to **asynchronous (Profile Event)**, so the PDOs are sent when one of its variables has changed in the PLC program.




- On the **Predefined Objects** tab, check the **Device generates SYNC message** box (sub-tab **Synchronisation Message**). Note that the **Communication Cycle Period** can be changed on this tab.




7. Select the **Service Data Objects** tab and select the **Client-SDO** type. Set up the SDO-Channel to the 20-COMM-K by checking the **SDO valid** box and inserting the COB-IDs. The COB-IDs are calculated as follows:

Client -> Server: $0x600 + \text{Node ID} = 0x607$


Server -> Client: $0x580 + \text{Node ID} = 0x587$




8. On the **Administration Objects** tab, the parameters for Node/Life Guarding can be changed. See [Node/Life Guarding on page 4-5](#) for details. Set the **Guard Time** to 500 ms and the **Life Time Factor** to "3." Close the **Device Configurator** window.




- Downloading Configuration**
1. Select the project and click the **CAN-Bus Access** icon in the project toolbar.




2. Click **Download to Device(s)** on the **Download/Upload/Verify** tab to download the connections made in the linker to the network nodes. This takes a few minutes. The PowerFlex 70 will produce some errors, as it needs to be downloaded separately. (The adapter must be in Pre-Operational State). Close the window when complete.




3. Select the PowerFlex70 and click the **CAN-Bus Access** icon in the project toolbar.




- Select the **Common Utilities** tab and click **Start Scan** until node 7 appears, and then click **Cancel**.



- Select Node 7 and click the **NMT Module Control** tab. Click **Enter Pre-Operational** to put the PowerFlex 70 into the Pre-Operational State. Return to the **Download/Upload/Verify** tab.




6. Select the option **save all parameters** and click **Download to Device(s)**. Download must be finished without faults. Otherwise, the device was not in the pre-operational state for the full time period. If the problem is still pending, power off the PLC and start download again.




PLC Program

1. Return to the **Visual Object Linker** window, select the **PLC Setup** tab, and click **Run Codesys**. Now, the variables from the linker are created and embedded in the PLC program.




NOTE: If any connections are changed in the project, click **Update DCF** before clicking **Run Codesys**.


- When CoDeSys is launched, the hardware type has to be selected. Select **ME 30 telmatic V/B-Modul**.




- Confirm the defaults by selecting **OK**.




- The Program Unit has to be specified. This is the first unit in any program. It must be a **Program** and cannot be deleted. **ST** (Structured Text) has been selected as programming language in this example. Click **OK**.



5. The layout of the screen shows POU (Program Organization Units) on the left, with the programming area on the right. In the lower left corner are the icon tabs for **POUs**, **Data Types**, **Visualizations**, and **Resources**.



6. The file with the variables that are created from the linker is in **Global Variables** on the **Resources** tab.



Logic Controller Program Example

The example logic controller program in this appendix provides details of how to program the *Mauell Telmatic ME* series of PLC hardware with the *Mauell CoDeSys AA* programming software to control a PowerFlex 70 or PowerFlex 700 drive.

Topic	Page
Configuring the Drive/ Adapter	F-1
Network Variables File	F-2
Program Code and Program Run	F-3
SDO Access Example	F-4

The example program provides the following functions:

- Start, stop, change direction, jog the drive, and obtain the status information.
- Increase and decrease the speed reference and obtain the speed feedback.
- Dynamically control current limit, brake level, acceleration time 1, and the jog frequency.
- Receive the output current, the output power, the last fault, and the status of the digital inputs.

Configuring the Drive/ Adapter

For this example, the following parameters must be set in the PowerFlex drive:

Parameter	Value	Description
90 – [Speed Ref A Sel]	22 (DPI Port 5)	Assigns 20-COMM-K to be used for the Reference
300 – [Data In A1]	140	Points to Parameter 140 - [Accel Time 1]
P301 – [Data In A2]	158	Points to Parameter 158 - [DC Brake Level]
302 – [Data In B1]	148	Points to Parameter 148 - [Current Lmt Val]
303 – [Data In B2]	100	Points to Parameter 100 - [Jog Speed]
310 – [Data Out A1]	3	Points to Parameter 3 - [Output Current]
311 – [Data Out A2]	216	Points to Parameter 216 - [Dig In Status]
312 – [Data Out B1]	243	Points to Parameter 243 - [Fault 1 Code]
313 – [Data Out B2]	7	Points to Parameter 7 - [Output Power]

For this example, the following parameter must be set in the 20-COMM-K:


Parameter	Value	Description
12 – [DPI I/O Cfg]	xxx0 0111	Enables Cmd/Ref, Datalinks A and B

The CANopen network is configured as described in [Appendix E](#).

Network Variables File

Select the **Resources** tab. In the **Global Variables** folder, a file has been created with a unique number (for this example, **0003L8CJ**). Double-click on this number to view the variable created by the linker.

Figure F.1 Global Variables Screen



Program Code and Program Run

Figure F.2 Example Program Code

```


0001 PROGRAM PLC_PRG
0002 VAR
0003 (* Constants *)
0004   MAX_SPD : INT := 16#2000;
0005   MIN_SPD : INT := 16#0064;
0006 (* Variables *)
0007   ScaledCurrent : INT;
0008 END_VAR
0009
0010
0011
0012 ** Drive Control by Input Switch
0013
0014
0015 IF InputSwitch.0 THEN LogicCmd.0 := TRUE; ELSE LogicCmd.0 := FALSE; END_IF (* stop *)
0016 IF InputSwitch.1 THEN LogicCmd.1 := TRUE; ELSE LogicCmd.1 := FALSE; END_IF (* start *)
0017 IF InputSwitch.2 THEN LogicCmd.2 := TRUE; ELSE LogicCmd.2 := FALSE; END_IF (* jog *)
0018 IF InputSwitch.3 THEN LogicCmd.3 := TRUE; ELSE LogicCmd.3 := FALSE; END_IF (* reset fault *)
0019 IF InputSwitch.4 THEN LogicCmd.4 := FALSE; LogicCmd.5 := TRUE; (* reverse *)
0020 ELSE LogicCmd.4 := TRUE; LogicCmd.5 := FALSE; END_IF; (* forward *)
0021
0022
0023 ** Generate Speed Reference
0024
0025
0026 IF InputSwitch.5 THEN SpeedRef = SpeedRef + 16#000A; (* increment speed *)
0027 IF SpeedFdb > MAX_SPD THEN SpeedRef = MAX_SPD; END_IF (* limit speed *)
0028 END_IF
0029 IF InputSwitch.6 THEN SpeedRef = SpeedRef - 16#000A; (* decrement speed *)
0030 IF SpeedFdb < MIN_SPD THEN SpeedRef = MIN_SPD; END_IF (* limit speed *)
0031 END_IF
0032
0033
0034 ** Read and Write Values through the Datalinks
0035
0036
0037 JogFreq := 16#0064; (* write through Datalink*)
0038 AccelTime1 := 16#0014; (* write through Datalink*)
0039 ScaledCurrent := CurrentOutput / 16; (* read through Datalink*)
0040 (* ScaledCurrent may be used for further calculations *)
0041
0042

```

To run the program, perform these steps:

1. Select **Online > Communication Parameters** and configure the communication parameters. A PLC program can either be downloaded over a serial cable connected to a computer's COM Port (local) or over the PC/CAN-Interface card that has already been used to configure the devices on the CANopen network.

Figure F.3 Communication Parameters for PC/CAN-Interface Card



2. Select **Online > Login** or click the **Login** icon in the toolbar.

3. If the program has changed, the program must be downloaded first. Click **Ja (Yes)**.

Figure F.4 Login Menu



4. To set the PLC in Run mode, select **Online > Run** or click the **Run** icon in the toolbar.

NOTE: When the program is running, the current values of the variables are visible in the opened POU's (Program Organization Units) and the Global Variables files.

NOTE: After power cycling, the PLC must be set in RUN mode every time. However, if the program has been downloaded with the CANopen Configuration Studio (**CANopen Network Access - Download to Device**), the program starts automatically after a power cycle.

SDO Access Example

To read or write an adapter parameter, the data structure for CANopen object 0x2228 (DPI Parameter Send) has to be filled in and then, the response can be read in CANopen object 0x2229 (DPI Parameter Receive). The following figures show how to read and write to these data structures. The CIA405 functions CIA405_SDO_READ4 and CIA405_SDO_WRITE4, which are already defined in CoDeSys, are used to access the CANopen objects.

Figure F.5 Function Block SDO_READ - Declarations

```

0001 FUNCTION_BLOCK SDO_READ
0002 VAR_INPUT
0003     Node: CIA405_DEVICE;
0004     RdIndex: WORD;
0005     RdSubindex: BYTE;
0006     RdStart: BOOL;
0007 END_VAR
0008 VAR_OUTPUT
0009     readValue: DINT;
0010     Error: BOOL;
0011 END_VAR
0012 VAR
0013     (* CIA405 Functions *)
0014     FBSdoRead: CIA405_SDO_READ4;
0015     FBArrayToDWord: ARRAY_TO_DWORD;
0016     (* Variables *)
0017     RdEnable: BOOL;
0018     RdConfirm: BOOL;
0019     RdError: CIA405_CANOPEN_KERNEL_ERROR;
0020     RdErrInfo: CIA405_SDO_ERROR;
0021     tempArray: ARRAY[1..4] OF BYTE;
0022     tempDWord: DWORD;
0023     RdDatLen: USINT;
0024 END_VAR
0025
0026
0027

```


Figure F.6 Function Block SDO_READ - Program Code

```

0001(*-----*)
0002* Function Block : SDO_READ
0003* Date: 17.3.04
0004* Abstract: Reads an element specified by Node, RdIndex and RdSubindex.
0005(*-----*)
0006IF RdStart THEN RdEnable := TRUE; END_IF
0007tempArray[1] := 0; tempArray[2] := 0; tempArray[3] := 0; tempArray[4] := 0;
0008FBSdoRead( Device := Node, (* CIA405 writes SDO function call *)
0009           Index := RdIndex,
0010           SUBINDEX := RdSubindex,
0011           ENABLE := RdEnable,
0012           CONFIRM => RdConfirm,
0013           DATA => tempArray,
0014           DATALENGTH => RdDatLen,
0015           ERROR => RdError,
0016           ERRORINFO => RdErrInfo );
0017
0018IF RdError = 0 THEN
0019  Error := FALSE;
0020  IF RdConfirm THEN
0021    FBDWordToDWord( IA := tempArray,
0022                  QD => tempDWord );
0023    IF RdDatLen = 1 THEN readValue := DWORD_TO_USINT (tempDWord); END_IF
0024    IF RdDatLen = 2 THEN readValue := DWORD_TO_INT (tempDWord); END_IF
0025    IF RdDatLen = 4 THEN readValue := DWORD_TO_DINT (tempDWord); END_IF
0026    RdEnable := FALSE;
0027  END_IF
0028ELSE
0029  readValue := 0;
0030  Error := TRUE;
0031  RdEnable := FALSE;
0032END_IF
0033

```

Figure F.7 Function Block SDO_WRITE - Declarations

```

0001FUNCTION_BLOCK SDO_WRITE
0002VAR_INPUT
0003  Node: CIA405_DEVICE;
0004  WrIndex: WORD;
0005  WrSubindex: BYTE;
0006  parameterValue: DINT;
0007  WrDataLen: USINT;
0008  WrStart: BOOL;
0009END_VAR
0010VAR_OUTPUT
0011  Error: BOOL;
0012END_VAR
0013VAR
0014(* CIA405 Functions *)
0015  FBSdoWrite: CIA405_SDO_WRITE4;
0016  FBDWordToArray: DWORD_TO_ARRAY;
0017(* Variables *)
0018  WrEnable: BOOL := TRUE;
0019  WrConfirm: BOOL;
0020  WrError: CIA405_CANOPEN_KERNEL_ERROR;
0021  WrErrInfo: CIA405_SDO_ERROR;
0022  tempArray: ARRAY[1..4] OF BYTE;
0023  tempDWord: DWORD;
0024END_VAR
0025

```

Figure F.8 Function Block SDO_WRITE - Program Code

```
0001 (*-----*)
0002 * Function Block : SDO_WRITE
0003 * Date: 17.3.04
0004 * Abstract: Writes an element specified by Node, WrIndex and WrSubindex.
0005 *-----*)
0006 IF WrStart THEN
0007   WrEnable := TRUE;
0008   tempArray[1] := 0; tempArray[2] := 0; tempArray[3] := 0; tempArray[4] := 0;
0009   FBWordToArray(ID := DINT_TO_DWORD(parameterValue),
0010               QA => tempArray);
0011 END_IF
0012
0013 FBSdoWrite( Device := Node,          (* CIA405 writes SDO function call *)
0014            Index := WrIndex,
0015            SUBINDEX := WrSubindex,
0016            DATA := tempArray,
0017            DATALENGTH := WrDataLen,
0018            ENABLE := WrEnable,
0019            CONFIRM => WrConfirm,
0020            ERROR => WrError,
0021            ERRORINFO => WrErrInfo );
0022
0023
0024 IF WrError = 0 THEN
0025   Error := FALSE;
0026   IF WrConfirm THEN WrEnable := FALSE; END_IF
0027 ELSE
0028   Error := TRUE;
0029   WrEnable := FALSE;
0030 END_IF
0031
0032
0033
```

Figure F.9 Function Calls of SDO_READ and SDO_WRITE

```
0087 IF SdoReadStart THEN
0088     FBSdoReadValue( Node := SdoNodeNumber,
0089                   RdIndex := Index,
0090                   RdSubindex := Subindex,
0091                   RdStart := TRUE,
0092                   readValue => readValue,
0093                   Error => SdoError);
0094     SdoReadStart := FALSE;
0095 ELSE
0096     FBSdoReadValue( Node := SdoNodeNumber,
0097                   RdIndex := Index,
0098                   RdSubindex := Subindex,
0099                   RdStart := FALSE,
0100                   readValue => readValue,
0101                   Error => SdoError);
0102 END_IF
0103 IF SdoWriteStart THEN
0104     FBSdoWriteValue( Node := SdoNodeNumber,
0105                    WrIndex := Index,
0106                    WrSubindex := Subindex,
0107                    parameterValue := paramValue,
0108                    WrDataLen := DataLen,
0109                    WrStart := TRUE,
0110                    Error => SdoError);
0111     SdoWriteStart := FALSE;
0112 ELSE
0113     FBSdoWriteValue( Node := SdoNodeNumber,
0114                    WrIndex := Index,
0115                    WrSubindex := Subindex,
0116                    parameterValue := paramValue,
0117                    WrDataLen := DataLen,
0118                    WrStart := FALSE,
0119                    Error => SdoError);
0120 END_IF
```

For more information on these functions refer to SDO access in “CiA Draft Standard 405 CANopen Interface” and “Device Profile for IEC 61131-1 Programmable Devices.”

Notes:

A Adapter

Devices such as drives, controllers, and computers usually require an adapter to provide a communication interface between them and a network such as CANopen. An adapter reads data on the network and transmits it to the connected device. It also reads data in the device and transmits it to the network.

The 20-COMM-K CANopen adapter connects PowerFlex 7-Class drives to a CANopen network. Adapters are sometimes also called “cards,” “embedded communication options,” “gateways,” “modules,” and “peripherals.”

B Bus Off

A bus off condition occurs when an abnormal rate of errors is detected on the Control Area Network (CAN) bus in a device. The bus-off device cannot receive or transmit messages on the network. This condition is often caused by corruption of the network data signals due to noise or data rate mismatch.

C CANopen Network

A CANopen network uses a producer/consumer Controller Area Network (CAN) to connect devices (for example, controllers, drives, and motor starters). Both I/O and explicit messages can be transmitted over the network. A CANopen network can support a maximum of 64 devices. Each device is assigned a unique node address and transmits data on the network at the same data rate.

A cable is used to connect devices on the network. It contains both the signal and power wires. Devices can be connected to the network with drop lines, in a daisy chain connection, or a combination of the two.

General information about CANopen and the CANopen specification are maintained by the Open CANopen Vendor’s Association (ODVA). ODVA is online at <http://www.odva.org>.

Change of State (COS) I/O Data Exchange

A device that is configured for Change of State I/O data exchange transmits data at a specified interval if its data remains unchanged. If its data changes, the device immediately transmits the change. This type of exchange can reduce network traffic and save resources since unchanged data does not need to be transmitted or processed.

COB-ID

The CANopen 11 bit structure combines a 4 bit function code with the node address (0...127). This is called the COB-ID.

Communication Cycle Period

See Synchronization Object (Sync).

ControlFLASH

An Allen-Bradley software tool that lets users electronically update firmware on printed circuit boards.

Controller

A controller, also called programmable logic controller, is a solid-state control system that has a user-programmable memory for storage of instructions to implement specific functions such as I/O control, logic, timing, counting, report generation, communication, arithmetic, and data file manipulation. A controller consists of a central processor, input/output interface, and memory. See also Scanner.

Cyclic I/O Data Exchange

A device configured for Cyclic I/O data exchange transmits data at a user-configured interval. This type of exchange ensures that data is updated at an appropriate rate for the application, preserves bandwidth for rapidly-changing devices, and allows data to be sampled at precise intervals for better determinism.

D Datalinks

A Datalink is a type of pointer used by PowerFlex 7-Class drives to transfer data to and from the controller. Datalinks allow specified parameters to be read or written to without using explicit messages. When enabled, each Datalink in a PowerFlex 7-Class drive consumes either four bytes or eight bytes in both the input and output image table of the controller. The drive determines the size of Datalinks.

Data Rate

The data rate is the speed at which data is transferred on the CANopen network. The available data rates depend on the type of cable and total cable length used on the network:

Baud Rate	Maximum Cable Length
10 Kbps	5000 m (16,404 ft.)
20 Kbps	2500 m (8, 202 ft.)
50 Kbps	1000 m (3,280 ft.)
125 Kbps	500 m (1,640 ft.)
250 Kbps	250 m (820 ft.)
500 Kbps	100 m (328 ft.)
800 Kbps	50 m (164 ft.)
1 Mbps	25 m (82 ft.)

Each device on a CANopen network must be set for the same data rate.

DPI (Drive Peripheral Interface)

A second generation peripheral communication interface used by various Allen-Bradley drives and power products, such as PowerFlex 7-Class drives. It is a functional enhancement to SCANport.

DPI Peripheral

A device that provides an interface between DPI and a network or user. Peripheral devices are also referred to as “adapters” or “modules.” The 20-COMM-K adapter, 1203-USB or 1203-SSS converter, and PowerFlex 7-Class HIMs (20-HIM-xxx) are examples of DPI peripherals.

DPI Product

A device that uses the DPI communications interface to communicate with one or more peripheral devices. For example, a motor drive such as a PowerFlex 7-Class drive is a DPI product. In this manual, a DPI product is also referred to as “drive” or “host.”

DriveExplorer Software

A tool for monitoring and configuring Allen-Bradley products and adapters. It can be run on computers running various Microsoft Windows operating systems. DriveExplorer (version 4.xx or higher) can be used to configure this adapter and PowerFlex drives. Information about DriveExplorer software and a free lite version can be accessed at <http://www.ab.com/drives/driveexplorer>.

DriveTools SP Software

A software suite designed for running on various Microsoft Windows operating systems. This software suite provides a family of tools, including DriveExecutive, that you can use to program, monitor, control, troubleshoot, and maintain Allen-Bradley products. DriveTools SP can be used with PowerFlex drives. Information about DriveTools SP can be accessed at <http://www.ab.com/drives/drivetools>.

E EDS (Electronic Data Sheet) Files

Simple text files that are used by network configuration tools, such as IXAAT CANopen Configuration Studio, to describe products so that you can easily commission them on a network. EDS files describe a product device type, revision, and configurable parameters. EDS files for many Allen-Bradley products can be found at <http://www.ab.com/networks/eds>.

Emergency Message (Emcy)

The emergency object is used in CANopen for sending fault information from the communication adapter to the CANopen network. The emergency object is triggered by a fault event from the drive or the communication adapter itself. An emergency object is transmitted only once per error event.

F Fault Action

A fault action determines how the adapter and connected drive act when a communications fault (for example, a cable is disconnected) occurs or when the controller is switched out of run mode. The former uses a communications fault action, and the latter uses an idle fault action.

Fault Configuration

When communications are disrupted (for example, a cable is disconnected), the adapter and PowerFlex drive can respond with a user-defined fault configuration. The user sets the data that is sent to the drive using specific fault configuration parameters in the adapter. When a fault action parameter is set to use the fault configuration data and a fault occurs, the data from these parameters is sent as the Logic Command, Reference, and/or Datalink(s).

Feedback

See Reference/Feedback.

Flash Update

The process of updating firmware in a device. The adapter can be flash updated using various Allen-Bradley software tools. Refer to [Flash Updating the Adapter on page 3-10](#) for more information.

G Guard Time

See Node Guarding.

H HIM (Human Interface Module)

A device that can be used to configure and control a drive. PowerFlex 7-Class HIMs (20-HIM-xxx) can be used to configure PowerFlex 7-Class drives and their connected peripherals.

Hold Last

When communication is disrupted (for example, a cable is disconnected), the adapter and PowerFlex drive can respond by holding last. Hold last results in the drive receiving the last data received via the network connection before the disruption. If the drive was running and using the Reference from the adapter, it will continue to run at the same Reference.

I I/O Data

I/O data, sometimes called “implicit messages” or “input/output,” is time-critical data such as a Logic Command and Reference. The terms “input” and “output” are defined from the controller’s point of view. Output is produced by the controller and consumed by the adapter. Input is produced by the adapter and consumed by the controller.

L Life Guarding

Life Guarding is used for error control to check that the NMT master is working properly. The NMT master guards all of its NMT slaves cyclically (cycle time = Guard Time) by using an RTR frame (see Node Guarding). If a slave does not receive an RTR frame from the NMT master within a specified time (= Guard Time x Life Time Factor), the slave knows that the NMT master must have failed. This mechanism is called Life Guarding.

Life Time Factor

See Life Guarding.

Logic Command/Logic Status

The Logic Command is used to control the PowerFlex 7-Class drive (for example, start, stop, direction). It consists of one 16-bit word of output to the adapter from the network. The definitions of the bits in this word depend on the drive, and are shown in [Appendix D](#).

The Logic Status is used to monitor the PowerFlex 7-Class drive (for example, operating state, motor direction). It consists of one 16-bit word of input from the adapter to the network. The definitions of the bits in this word depend on the drive, and are shown in [Appendix D](#).

M Master-Slave Hierarchy

An adapter configured for a master-slave hierarchy exchanges data with the master device. Usually, a network has one controller which is the master device, and all other devices (for example, drives connected to CANopen adapters) are slave devices. On a network with multiple controllers (called a multimaster hierarchy), each slave device must have a controller specified as a master.

N NMT (Network Management)

The NMT master of a CANopen network can transmit NMT messages which forces the nodes to change to another NMT state. The CANopen state machine specifies these states as Initialization, Pre-Operational, Operational, and Stopped.

Node Address

A CANopen network can have as many as 64 devices connected to it. Each device on the network must have a unique node address between 0 and 63. Node address 63 is the default used by uncommissioned devices. Node addresses are sometimes called “MAC IDs.”

Node Guarding

Node Guarding is used for error control to check that any CANopen device is working properly. The mechanism used for guarding is based on the master/slave relationship. The NMT master guards all of its NMT slaves cyclically (cycle time = Guard Time) by using an RTR frame. Any CANopen slave responds to this RTR frame to guarantee that the application program is running.

NVS (Non-Volatile Storage)

NVS is the permanent memory of a device. Devices such as the adapter and drive store parameters and other information in NVS so that they are not lost when the device loses power. NVS is sometimes called “EEPROM.”

O Objects

The CANopen specification defines an object as “an abstract representation of a particular component within a product.”

Object Dictionary

Any CANopen device has a unique object dictionary, which is the interface to the application. The object dictionary contains all data types used in the device, the communication parameters, the application data, and the configuration parameters. To gain access to the object dictionary, Process Data Objects (PDOs) and Service Data Objects (SDOs) are used.

P PDO (Process Data Objects)

Process Data Objects (PDO) are used to transmit any process data. The process data are transmitted without any protocol overhead and by using the producer/consumer model. PDO transmission is not confirmed. Each PDO has a unique CAN identifier. The maximum length of a PDO message is 8 bytes.

PDO Mapping

The PDO mapping defines which application objects are transmitted within a PDO. It describes the sequence and length of the mapped application objects.

Polled I/O Data Exchange

See Remote Transmission Request.

PowerFlex 7-Class (Architecture Class) Drives

The Allen-Bradley PowerFlex 7-Class family of drives supports DPI and includes the PowerFlex 70, PowerFlex 700, PowerFlex 700H, PowerFlex 700S, PowerFlex 700L, and PowerFlex 7000. These drives can be used for applications ranging from 0.37...3000 kW (0.5...4000 HP).

Producer/Consumer Network

On producer/consumer networks, packets are identified by content rather than an explicit destination. If a node needs the packet, it will accept the identifier and consume the packet. The source therefore sends a packet once and all the nodes consume the same packet if they need it. Data is produced once, regardless of the number of consumers. Also, better synchronization than Master-Slave networks is possible because data arrives at each node at the same time.

R Reference/Feedback

The Reference is used to send a setpoint (for example, speed, frequency, torque) to the drive. It consists of one word of output to the adapter from the network. The size of the word (either a 16-bit word or 32-bit word) is determined by the drive.

Feedback is used to monitor the speed of the drive. It consists of one word of input from the adapter to the network. The size of the word (either a 16-bit word or 32-bit word) is determined by the drive.

Remote Transmission Request (RTR)

A PDO can be remotely requested. The PDO consumer transmits a CAN remote frame and the corresponding PDO producer responds to this remote frame by sending the requested PDO. This is also called “Polled I/O Data Exchange.”

S Scanner

A scanner is a separate module (of a multi-module controller) or a built-in component (of a single-module controller) that provides communication with adapters connected to a network. See also Controller.

SDO (Service Data Objects)

Service Data Objects (SDO) are used to transfer data that does not require continuous updates. A SDO reads from entries or writes to entries of the Object Dictionary. The SDO transport protocol allows transmitting objects of any size. The receiver confirms each object, so that a peer-to-peer communication (client/server) takes place.

Status Indicators

Status indicators are LEDs that are used to report the status of the adapter, network, and drive. They are on the adapter and can be viewed on the front cover of the drive when the drive is powered.

Synchronization Object (Sync)

The Sync object is used for synchronizing devices and is broadcast periodically by the Sync Producer. The time period between Sync messages is defined by the Communication Cycle Period.

T Transmission Mode

See Transmission Type.

Transmission Type

The transmission type parameter of a PDO specifies the transmission mode (synchronous or asynchronous) and the triggering mode. In CANopen, there are three types of PDO triggering: COS (Change of State), Cyclic Transmission, and Remote Transmission Request (RTR).

Triggering Mode

See Transmission Type.

Z Zero Data

When communications are disrupted (for example, a cable is disconnected), the adapter and drive can respond with zero data. Zero data results in the drive receiving zero as values for Logic Command, Reference, and Datalink data. If the drive was running and using the Reference from the adapter, it will stay running but at zero Reference.

A

adapter
 applying power, **2-8**
 commissioning, **2-1**
 compatible products, **1-2**
 components, **1-1**
 configuration tools, **3-1**
 connecting to the drive, **2-4**
 connecting to the network, **2-7**
 definition, **G-1**
 features, **1-2**
 flash updating, **3-10**
 grounding, **2-6**
 installation, **2-1 to 2-10**
 mounting on the drive, **2-6**
 parameters, **B-1 to B-4**
 resetting, **3-9**
 specifications, **A-1**
 viewing its status, **3-10**
 applying power to the adapter, **2-8**
 attentions, **1-4**

B

baud rate, *see data rate*
 bit definitions of Logic Command/Status word for
 PowerFlex 70/700/700H drives, **D-1**
 PowerFlex 700S drives, **D-3**
 bus off, **7-6, G-1**

C

cables
 CANopen, **2-7**
 DPI Internal Interface, **2-4, 2-5**
 CANopen
 cable, **2-7**
 connector on adapter, **1-1**
 plug, **2-7**

CANopen Network
 communications configuration, **E-8**
 data rates, **A-1**
 definition, **G-1**
 example, **E-1**
 NMT (Network Management), **4-1**
 Node/Life Guarding, **4-5, E-19**
 nodes configuration, **4-3, 4-4**
 PDOs configuration, **4-4, E-16**
 PLC program, **E-22**
 PLC variables configuration and linking, **E-9**
 SDOs configuration, **4-4, E-16**
 specification, **G-1**
 SYNC configuration, **4-5, E-16**
 CANopen objects, **C-1**
 definition, **G-6**
 tables, **C-1**
 Change of State (COS)
 configuring adapter for, **3-5**
 definition, **G-1**
 Comm Flt Action parameter, **B-2**
 commissioning the adapter, **2-1**
 communications configuration for CANopen
 network, **E-8**
 communications module, *see adapter*
 compatible products, **1-2**
 components of the adapter, **1-1**
 configuration tools, **3-1**
 connecting adapter to the
 drive, **2-4**
 network, **2-7**
 ControlFLASH, **G-2**
 controller
 definition, **G-2**
 running SDOs, **6-2**
 COPN Addr Act parameter, **B-1**
 COPN Addr Cfg parameter, **B-1**
 COPN Rate Act parameter, **B-2**
 COPN Rate Cfg parameter, **B-1**
 COS Fdbk Change parameter, **B-4**
 COS Status Mask parameter, **B-4**
 COS, *see Change of State*
 Cyc Interval parameter, **B-4**
 Cyclic
 configuring adapter for, **3-6**
 definition, **G-2**

D

data exchange
 Change of State (COS), **3-5, G-1**
 Cyclic, **3-5, G-2**
 RTR (Polled), **3-5, G-7**

data rate
 definition, **G-2**
 setting with parameter, **3-3**
 setting with switch, **2-3**

Datalink Size parameter, **B-2**

Datalinks
 definition, **G-2**
 in I/O image, **5-4**
 using, **5-8**

diagnostic items, **7-4**

dimensions, **A-1**

downloading configuration, **4-5, E-20**

DPI
 connector on adapter, **1-1**
 data rates, **A-1**
 definition, **G-2**
 Internal Interface cable, **2-4, 2-5**
 peripheral, **G-3**
 products, **G-3**

DPI Data Rate parameter, **B-1**

DPI I/O Act parameter, **B-3**

DPI I/O Cfg parameter, **B-3**

DPI Port parameter, **B-1**

DriveExecutive software
 adapter configuration tool, **3-1**
 definition/web site, **G-3**

DriveExplorer software
 adapter configuration tool, **3-1**
 definition/web site, **G-3**
 free lite version, **G-3**

drives, *see PowerFlex drives*

DriveTools SP software, **G-3**

E

EDS (Electronic Data Sheet) files
 definition/web site, **G-3**

EEPROM, *see Non-Volatile Storage (NVS)*

EMCY (Emergency object), **4-5, G-3**

environmental specifications, **A-1**

equipment required, **1-3**

events

clearing/viewing, **7-5**
 list of, **7-6**

F

fault action
 configuring the adapter for, **3-7**
 definition, **G-3**

fault configuration
 configuring the adapter for, **3-8**
 definition, **G-4**

faulted node recovery feature, **1-2**

faults, *see events*

features, **1-2**

firmware release, **P-2**

flash update
 definition, **G-4**
 guidelines, **3-10**

Fit Cfg A1-D2 In parameters, **B-4**

Fit Cfg Logic parameter, **B-3**

Fit Cfg Ref parameter, **B-3**

G

grounding the adapter, **2-6**

H

HIM (Human Interface Module)
 accessing parameters with, **3-2**
 definition, **G-4**
 LCD model, **3-2**
 LED model, **3-2**

hold last
 configuring the adapter for, **3-7**
 definition, **G-4**

I

I/O
 configuring the adapter for, **3-4**
 definition, **G-4**
 image, **5-4**

Idle Fit Action parameter, **B-2**

Initialization state, **4-2**

- installation
 - applying power to the adapter, **2-8**
 - commissioning the adapter, **2-1**
 - connecting to the drive, **2-4**
 - connecting to the network, **2-7**
 - preparing for, **2-1**
- Internal Interface cables
 - connecting to the adapter, **2-5**
 - connecting to the drive, **2-5**
 - illustration, **2-5**
- L**
- LCD HIM, **3-2**
- LED HIM, **3-2**
- LEDs, *see status indicators*
- Life Guarding, **4-5, E-19, G-4**
- Logic Command/Status
 - bit definitions for
 - PowerFlex 70/700/700H drives, **D-1**
 - PowerFlex 700S drives, **D-3**
 - definition, **G-5**
 - in I/O image, **5-4**
 - using, **5-6**
- logic controller program example
 - configuring drive/adapter, **F-1**
 - program code, **F-3**
 - program run, **F-4**
 - SDO access, **F-4**
 - variables files, **F-2**
- M**
- MAC ID, *see node address*
- manual
 - conventions, **P-2**
 - related documentation, **P-1**
 - web site, **P-1**
- master/slave, **4-5, G-5**
- mechanical dimensions, **A-1**
- MOD status indicator
 - locating, **1-6**
 - troubleshooting with, **7-2**
- mounting the adapter, **2-6**
- N**
- NET A (CAN RUN) status indicator
 - locating, **1-6**
 - troubleshooting with, **7-3**
- NET B (CAN ERR) status indicator
 - locating, **1-6**
 - troubleshooting with, **7-3**
- network
 - cable, **2-7**
 - nodes, **4-4**
 - plug, **2-7**
- NMT (Network Management), **4-1, G-5**
- NMT slave state machine, **4-2**
- node address
 - definition, **G-5**
 - setting with parameter, **3-3**
 - setting with switches, **2-2**
- Node Guarding, **4-5, E-19, G-5**
- Non-Volatile Storage (NVS)
 - definition, **G-5**
 - in adapter, **3-1**
 - in drive, **5-8, 6-1**
- O**
- Object Dictionary, **4-3, G-6**
- objects
 - access, **6-3**
 - process data PDO, **5-1**
- operating status, **2-8**
- Operational State, **4-3**
- P**
- parameters
 - accessing, **3-1, 6-3**
 - convention, **P-2**
 - list of, **B-1 to B-4**
 - numbering scheme, **B-1**
 - restoring to factory-default settings, **3-9**
- PDO (Process Data Objects)
 - about, **5-1**
 - configuration, **4-4**
 - configuration example, **E-16**
 - definition, **G-6**
 - mapping, **G-6**
 - Receive mapping, **5-10**
 - Transmission Mode, **5-2**
 - Transmission Type, **5-2**
 - Transmit mapping, **5-9**
 - Triggering Mode, **5-3**
- PDO1 Trigger parameter, **B-4**

- PLC
 - program, **E-22**
 - variables, **E-9**
- plug for adapter, **2-7**
- Polled, *see RTR (Remote Transmission Request)*
- PORT status indicator
 - locating, **1-6**
 - troubleshooting with, **7-2**
- power consumption, **A-1**
- PowerFlex drives
 - compatible with adapter, **1-2**
 - definition, **G-6**
 - HIM, **3-2**
 - installing adapter on, **2-4**
- Pre-Operational state, **4-2**
- preparing for an installation, **2-1**
- processor, *see controller*
- producer/consumer network, **G-6**
- programmable logic controller, *see controller*

- Q**
- quick start, **1-5**

- R**
- Ref/Fdbk Size parameter, **B-2**
- Reference/Feedback
 - definition, **G-7**
 - in I/O image, **5-4**
 - using, **5-6**
- regulatory compliance, **A-2**
- related documentation, **P-1**
- Reset Module parameter, **B-2**
- resetting the adapter, **3-9**
- ribbon cable, *see Internal Interface cable*
- RTR (Remote Transmission Request)
 - configuring adapter for, **3-7**
 - definition, **G-7**

- S**
- safety precautions, **1-4**
- scanner, **G-7**

- SDO (Service Data Objects)
 - about, **6-1**
 - configuration, **4-4**
 - configuration example, **E-16**
 - definition, **G-7**
 - running, **6-2**
- selecting data exchange
 - COS (Change of State), **3-5**
 - Cyclic, **3-5**
 - RTR (Polled), **3-5**
- specifications
 - adapter, **A-1**
 - CANopen Network, **G-1**
- state
 - Initialization, **4-2**
 - Operational, **4-3**
 - Pre-Operational, **4-2**
 - Stopped, **4-3**
- status indicators
 - definition, **G-7**
 - locating, **1-6**
 - MOD, **1-6, 7-2**
 - NET A (CAN RUN), **1-6, 7-3**
 - NET B (CAN ERR), **1-6, 7-3**
 - normal operation, **2-8**
 - PORT, **1-6, 7-2**
 - troubleshooting with, **7-2 to 7-3**
 - understanding, **7-1**
- Stopped state, **4-3**
- switches
 - Data Rate, **2-3**
 - Node Address, **2-2**
- SYNC (Synchronization Object)
 - configuration, **4-5**
 - configuration example, **E-16**
 - definition, **G-7**

- T**
- technical support, **P-2**
- tools required, **1-3**
- Transmission Mode, **5-2**
- Transmission Type, **5-2, G-7**
- Triggering Mode, **5-3**
- troubleshooting, **7-1 to 7-6**

- U**
- update, *see flash update*

W

web site

DriveExecutive software, **G-3**

DriveExplorer software, **G-3**

DriveTools SP software, **G-3**

EDS files, **G-3**

manuals, **P-1**

wiring, *see cables*

Z

zero data

configuring the adapter for, **3-7**

definition, **G-8**

U.S. Allen-Bradley Drives Technical Support - Tel: (1) 262.512.8176, Fax: (1) 262.512.2222, Email: support@drives.ra.rockwell.com, Online: www.ab.com/support/abdrives

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846