

Kinetix 5700 DC-bus Connector Kits

Catalog Numbers 2198-BARCON-55DC200, 2198-BARCON-85DC200,
2198-BARCON-100DC200, 2198-BARCON-ENDCAP200

About the DC-bus Connector Kits

The Kinetix® 5700 DC-bus connector kits are used to extend DC-bus power from drive to drive in DC-bus multi-axis configurations. DC-bus links are rated for 270 A, maximum bus-bar current.

DC-bus Connector Kit Applications

DC-bus Connector Kit Cat. No.	Kinetix 5700 Drive Module Type	Kinetix 5700 Drive Cat. No.	Description
2198-BARCON-55DC200	Dual axis inverter	2198-D006-ERS3 2198-D012-ERS3 2198-D020-ERS3 2198-D032-ERS3	DC-bus link, 55 mm, 200 A
2198-BARCON-85DC200	Dual axis inverter	2198-D057-ERS3	DC-bus link, 85 mm, 200 A
	Single axis inverter	2198-S086-ERS3 2198-S130-ERS3	
2198-BARCON-100DC200	Single axis inverter	2198-S160-ERS3	DC-bus link, 100 mm, 200 A
2198-BARCON-ENDCAP200	DC-bus supply	2198-P031 2198-P070 2198-P141 2198-P208	DC-bus end caps, 200 A

See the Kinetix 5700 Servo Drives User Manual, publication [2198-UM002](#), for detailed information on wiring, applying power, troubleshooting, and integration with Logix5000™ controllers.

Install the Connector Kits



ATTENTION: To avoid hazard of electrical shock, perform all mounting and wiring of the Kinetix 5700 drives and shared-bus connector kits before applying power. Once power is applied, connector terminals can have voltage present even when not in use.


IMPORTANT

When the shared-bus connection system is used, the zero-stack tab and cutout must be engaged between adjacent drives.

The DC-bus connection system is comprised of two components:

- DC-bus links that are inserted between drive modules to extend the DC bus from drive to drive
- DC-bus end caps that are inserted into the first and last drive modules to cover the exposed DC-bus connector on both ends of the bus

This example configuration illustrates the shared DC-bus connection system and consists of one 2198-P208 DC-bus power supply, one 2198-S160-ERS3 single-axis inverter, one 2198-S086-ERS3 single-axis inverter, and one 2198-D006-ERS3 dual-axis inverter.



- (1) DC-bus links latch on both sides when inserted into the DC-bus connectors. To remove the DC-bus link, depress both sets of upper pivots to unlatch the lower pivots and hold the DC-bus link firmly while pulling upward.

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Allen-Bradley, Kinetix, Logix5000, Rockwell Software, and Rockwell Automation are trademarks of Rockwell Automation, Inc. Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846