

STOP

111

SECOND









SMARTIMEP Type 84.02

Digital Timer "Two in one": two totally independent programmable channels, in a single product

A step forward for easier, quick and flexible programming right from your smartphone. With NFC technology and "Finder Toolbox" Android App.

FEATURES

- Two programming modes: "Smart" mode via smartphone with NFC communication or "Classic" mode via the joystick
- Wide backlit display for easy reading of all information during the programming phase and during normal operation
- Flexibility: it's possible to create new specific functions, mixing the 25 available functions on each channel
- High precision and possibility of choice in time set-up: Time units; 0.1 seconds, seconds, minutes, hours

- Set-time to 4 digits, anywhere between 000.1 second and 9999 hours

- Large display allows easy viewing: set time, current time, timing in progress, input command state, output state
- 1 CO (16 A) + 1 CO (16 A) output contacts




Type 84.02.0.230.0000

- Nominal voltage:
- 110...240 V AC/DC (non-polarized)
- Operating range: 90...264 V AC/DC (47/63Hz)




Type 84.02.0.024.0000

- Nominal voltage:
 - 12...24 V AC/DC (non-polarized) - Operating range:
- 10...30 V AC/DC (47/63Hz) - It's possible to directly connect
- timer input to proximity sensors (both PNP and NPN)



- Two independent Start input one per channel
- One common Reset input (select to apply to either, or both, channels)
- One common Pause input (select to apply to either, or both, channels)
 PIN to protect access
- to programming session
- Up or Down timing modes
- Setting accuracy-full range: $\pm 0,05\%$
- Ambient temperature range: -20° + 50°
- 35 mm rail (EN 60715) mount








TIMER-SOCKET COMPATIBILITY

85 SERIES TIMERS

COMPATIBLE with all 94 Series sockets



88 SERIES TIMERS

COMPATIBLE with all 90 Series sockets



86 SERIES TIMER MODULES

TYPE 86.00 COMPATIBLE with the following socket Types: 90.02, 90.03 92.03 96.04

TYPE 86.30

COMPATIBLE with the following socket Types: 90.02, 90.03 92.03 96.02, 96.04 94.02, 94.03, 94.04, 94.54, 94.P3, 94.P4 97.01, 97.02, 97.51, 97.52, 97.P1, 97.P2 95.03, 95.05, 95.55, 95.P3, 95.P5



93 SERIES TIMER SOCKETS

Timer socket 93.21 with relay, comprises the following interface 38.21 (SSR / EMR) Dual screw head (blade + cross) terminals

Timer socket 93.68

with relay, comprises the following interfaces 39.81 (EMR) Dual screw head (blade + cross) terminals 39.80 (SSR) Dual screw head (blade + cross) terminals

Timer socket 93.69

with relay, comprise the following interfaces 39.91 (EMR) - Push-in terminals 39.90 (SSR) - Push-in terminals

Finder SWITCH TO THE FUTURE

	(t) finder	VEWA								
	SWITCH TO THE FUTURE							1		
	FUNCTIONS PAGE 1	80 SERIES	81 SERIES	83 SERIES	84 SERIES	85 SERIES	86 SERIES	88 SERIES	93 SERIES	
AI	ON-DELAY	80.01 80.11 80.71	81.01	83.01 83.02 83.11	84.02	85.02 85.03 85.04	86.00 86.30	88.02	93.21 93.68 93.69	
AE	© ON-DELAY WITH CONTROL SIGNAL			83.52	84.02					
BI	POWER OFF-DELAY (True off-delay)	80.61		83.62						
BE	off-delay with control signal	80.01 80.41 80.71	81.01	83.01 83.02 83.41	84.02		86.00	88.02	93.68 93.69	
CE	ON- AND OFF-DELAY WITH CONTROL SIGNAL	80.01 80.71		83.01 83.02	84.02		86.00	88.02	93.68 93.69	
DI		80.01 80.21 80.71	81.01	83.01 83.02 83.21	84.02	85.02 85.03 85.04	86.00 86.30	88.02	93.21 93.68 93.69	
DE	s INTERVAL WITH	80.01 80.71	81.01	83.01 83.02	84.02		86.00	88.02	93.68 93.69	
EE	s T T T T T T T T T T T T T				84.02		86.00		93.68 93.69	
EEa _a	s σ σ σ σ σ σ σ σ σ σ σ σ σ			83.52	84.02					
EEb	INTERVAL WITH		81.01		84.02					
FE	INTERVAL WITH CONTROL			83.52	84.02		86.00			
WD	S S S S S S S S S S S S S S S S S S S			83.01 83.02	84.02					
GI	PULSE DELAYED			83.01 83.02	84.02	85.02 85.03 85.04		88.02 88.12	93.21 93.68 93.69	
GE	PULSE DELAYED			83.52	84.02					
SW	SYMMETRICAL FLASHER , T, T, T, T, IIIT, (starting pulse on)	80.01 80.71	81.01	83.01 83.02	84.02	85.02 85.03 85.04	86.00	88.02 88.12	93.21 93.68 93.69	
SP	SYMMETRICAL FLASHER		81.01		84.02					
LI	ASYMMETRICAL FLASHER (starting pulse on)	80.91		83.91	84.02			88.92.0001		

NEW

finder
SWITCH TO THE FUTURE

	SWITCH TO THE FUTURE		NEWA								
				1		1205			N.		
	FUNCTIONS PAGE 2	2	80 SERIES	81 SERIES	83 SERIES	84 SERIES	85 SERIES	86 SERIES	88 SERIES	93 SERIES	
LE	U S T1 T2 T1 T2 KT	ASYMMETRICAL FLASHER (starting pulse on) WITH CONTROL SIGNAL	80.91		83.91	84.02					
Ы		ASYMMETRICAL FLASHER (starting pulse off)			83.91	84.02			88.92.0000		
PE		ASYMMETRICAL FLASHER (starting pulse off) WITH CONTROL SIGNAL			83.91	84.02					
SD	u ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	STAR-DELTA	80.82		83.82	84.02 *					
п		TIMING STEP			83.52	84.02					
SHp	V S P(X1-X2)	"Shower" FUNCTION			83.52	84.02					
ВЕр		OFF-DELAY WITH CONTROL SIGNAL AND PAUSE SIGNAL			83.52	84.02					
DEp	P(X1-X2)	INTERVAL WITH CONTROL SIGNAL ON AND PAUSE SIGNAL			83.52	84.02					
Al a		ON-DELAY (2 timed contacts)				84.02 *			88.12		
Alb		ON-DELAY (1 timed + 1 instantaneous contact)				84.02 *			88.12		
DI a		INTERVAL (2 timed contacts)				84.02 *			88.12		
DI b		INTERVAL (1 timed + 1 instantaneous contact)				84.02 *			88.12		
OFF	v	RELAIS OFF The output contact stays permanently open				84.02					
ON		RELAIS ON The output contact stays permanently closed				84.02					
SS		MONOSTABLE CONTROLLED BY SIGNAL SWITCH The output contact follows the status of Signal Switch (S)				84.02					
PS	U S P	MONOSTABLE CONTROLLED BY PAUSE SWITCH The output contact follows the status of Pause Switch (P)				84.02					
ł	* Achievable by combining basic f	functions			NOTE _ 80 81 83	93 Series: for 35 mm	n rail (EN 60715) mo	unting _ 85 86 88	Series: nlug-in conner	rtion/mount	

NFM

* Achievable by combining basic functions

NOTE - 80, 81, 83, 93 Series: for 35 mm rail (EN 60715) mounting - 85, 86, 88 Series: plug-in connection/mount