# **Plotter Kit**




Catalog Numbers 1492-PLTKIT

# **User Manual**











#### **Important User Information**

Because of the variety of uses for the products described in this publication, those responsible for the application and use of this control equipment must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards.

The illustrations, charts, sample programs and layout examples shown in this guide are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Allen-Bradley does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.

Allen-Bradley publication SGI-1.1, *Safety Guidelines for the Application, Installation and Maintenance of Solid-State Control* (available from your local Allen-Bradley office), describes some important differences between solid-state equipment and electromechanical devices that should be taken into consideration when applying products such as those described in this publication.

Reproduction of the contents of this copyrighted publication, in whole or part, without written permission of Rockwell Automation, is prohibited.

Throughout this manual we use notes to make you aware of safety considerations:



**ATTENTION:** Identifies information about practices or circumstances that can lead to personal injury or death, property damage or economic loss

Attention statements help you to:

- identify a hazard
- · avoid a hazard
- recognize the consequences

#### **IMPORTANT**

Identifies information that is critical for successful application and understanding of the product.

Allen-Bradley is a trademark of Rockwell Automation. Windows is a trademark of the Microsoft Corporation.

# Table of Contents

Preface	Overview of this Manual	
	Intended Audience	ii
	Conventions	ii
Ch. 1—Marking System	Chapter Objectives	1-1
Description	Marking System Components	1-1
, and the second	Marker Cards	1-2
	Marker Types	1-3
	ClearTools Software	1-6
	Accessories	1-7
Ch. 2 — Initial Setup	Chapter Objectives	2-1
·	Setup	
	Location	2-1
	Connections	2-1
	Installing the Plotter Driver	2-2
	Installing the driver for the plotter 1492-PLTKIT Series E with:	in:
	Windows 2000	2-2
	Windows Vista	2-6
	Windows XP	2-12
	Windows 7	2-14
	Installing a Pen in the Pen Station	2-19
	Removing a Pen from the Pen Station	2-19
	Plotting with the 1492-PLOTADPT	2-20
	Activating the Plotter with ClearTools	
	Introduction	
	Switching to Plot Mode	
	Startup options for Plot Mode	
	Mapping to Plotter:	2-22
	Adjusting Marker Type	
	Plotting Multiple Cards	2-27
Operation of Plotter— 3	Chapter Objectives	3-1
•	Operation	3-1
	ON/OFF Buttons	3-1
	Clear Buffer	3-1
	Pen Station Open/Close Button	3-2
	Stop/View Button	3-2
	Cursor and Pen Up/Down Buttons	3-3

Troubleshooting and	Chapter Objectives	4-1
Maintenance—4	Using the Troubleshooting Chart	
	Required Equipment	4-1
	Plotter Maintenance	4-2
	Cleaning Plotter	4-2
	Removing Sealing Unit from Pen Station	4-2
	Inserting and Adjusting Sealing Unit	4-2
	Exchanging Priming Plates (for starting plotter pen)	4-3
	Pen Maintenance	4-3
	Technical Specifications	4-4
Appendix A	For Plotter Plates with Adhesive Strips, 1492-PLOTPLT,	
	Series A	A-1
	Adhesive Strip Preparation	A-1

# **Preface**

## **Overview of this Manual**

This manual describes how to use components of the Allen–Bradley Plotter Kit to create and print markers for Bulletin 1492 Terminal Blocks and accessories.

The following table describes the contents of this manual.

Chapter	Title	Contents
	Preface	Provides an overview of the manual.
1	Marking System Description	Provides a brief overview of the hardware and software. Includes a description of system accessories.
3	Operation of Plotter	Describes plotter controls.
2	Initial Setup	Describes initial plotter setup.
4	Troubleshooting and Maintenance	Provides assistance in identifying and correcting common operating problems. Procedures for routine maintenance items are also provided.

**Note:** Refer to the ClearTools<sup>TM</sup> Software Manual for software installation and setup.



At the end of its life, this equipment should be collected separately from any unsorted municipal waste


#### **Intended Audience**

Basic knowledge of the Microsoft Windows™ Operating System is required to operate the 1492-PLTKIT Plotter System. For ClearTools software instructions, refer to the user's manual contained within the ClearTools software.


#### **Conventions**

This manual uses the following conventions:

- · Allen-Bradley Marking System software is referred to as ClearTools.
- · Marker refers to the individual tabs that snap onto a terminal block.



• A marker card is a set of multiple markers. See Table 1.A for more information on marker cards.



# **Marking System Description**

## **Chapter Objectives**

This chapter describes:

- Marking System components
- Marker Cards
- Marker types
- Accessories


# Marking System Components

The Terminal Block Marking System kit (Catalog No. 1492–PLTKIT) includes:

- Allen-Bradley Marking System (ClearTools) Software
- Plotter
- Base Plate\*
- Stainless-Steel Inlay (5)
- Disposable Pen
- USB Cable (connects personal computer to plotter)
- Power Cable
- Plotter User Manual (this document)
- 220V Adapter

In addition, you need:

- Personal computer
- Marker Cards (See Table 1.A)




Personal Computer

 $<sup>^{\</sup>star}$  A special plate, 1492-PLOTPLTA, is needed for the following markers: 1492-MW5-21, 1492-MW6-21, 1492-MW7-21).


#### **Marker Cards**

Allen-Bradley markers can be printed in either a horizontal or vertical direction. The ClearTools software displays a view of the markers as they would appear on the plotter.



Plotting always starts in the upper left corner of the marker card.

The plotter base plate has spaces for 5 marker cards. Spaces are numbered 1 to 5, from left to right.



The inlay may be installed in the base plate at different heights by lining up the number (1 to 5) of the inlay with the red locating rib of a given space.

# **Marker Types**

The marking system supports a variety of marker types.

Table 1.A Allen–Bradley Markers for Allen-Bradley Products

Marker/Label Catalog No.	Use With These Allen-Bradley Terminal Blocks and Other Products	
1492-M3X12	1492-L2, 1492-L2T, 1492-L2Q,1492-LD2, 1492-LD2C, 1492-LG2, 1492-LG2T, 1492-LG2Q, 1492-LDG2, 1492-LDG2C	
1492-M3X5	1492-L2, 1492-L2T, 1492-L2Q, 1492-LD2, 1492-LD2C, 1492-LG2, 1492-LG2T, 1492-LG2Q, 1492-LDG2, 1492-LDG2C, 1738-OB16EM12, 1738-OB16E25DS, 1738-OB16E19M23, 1738-IB16DM12	
1492-M5X5	1492-CPL, 1492-FPK2, 1492-J3, 1492-J10, 1492-J16, 1492-J35, 1492-J50, 1492-J70, 1492-JD3, 1492-J20, 1492-J3TW, 1492-JD3C, 1492-J3F, 1492-JD3F, 1492-JG20, 1492-JKD3TP, 1492-J3TW, 1492-JDG3C, 1492-JKD3, 1492-JKD3TP, 1492-JD3PSS, 1492-JD3PSS, 1492-JD3PSSTP, 1492-JDG3P, 1492-JDG3PTP, 1492-JDG3PSS, 1492-JDG3PSSTP, 1492-JD3DF*, 1492-JD3DF*, 1492-JD3DR*, 1492-JD3RB*, 1492-JD3RC001, 1492-JD3SS, 1492-JTC3*, 1492-JC3, 1492-JDC3, 1492-LMJ3, 1492-LMJG3, 1492-LM3, 1492-LM30, 1492-LMG3, 1492-LMP3, 1492-LMF3, 1492-LG3, 1492-LS2-3, 1492-LS2-3, 1492-LS2-3, 1492-LS2-3, 1492-LG3T, 1492-LS2-4, 1492-LS2-4, 1492-LS2-3, 1492-LG3T, 1492-LG3T, 1492-LG3D, 1492-LDG3C, 1492-LDG3C, 1492-LDG3C, 1492-LDG3C, 1492-LS2-B* Fuse Blocks	
1492-M5X8	1492-JD3, 1492-JD3C, 1492-JD3F, 1492-JDG3, 1492-JDG3C, 1492-JD3DF*, 1492-JD3DR*, 1492-JD3RB*, 1492-JD3RC001, 1492-JD3SS	
1492-M5X10	1492-ERL35, 1492-LM30, 1492-LMG3, 1492-LMJ3, 1492-LMJG3, 1492-LMP3, 1492-LMP30, 1492-L3, 1492-L3T, 1492-L30, 1492-LD3, 1492-L30S, 1492-LD3C, 1492-LG3, 1492-LG3T, 1492-LG30, 1492-LDG3, 1492-LDG3	
1492-M5X12	1492-J3F, 1492-JG2Q, 1492-JG3, 1492-JG3TW, 1492-JKD3, 1492-JKD3TP, 1492-J3P, 1492-J3PTP, 1492-JTC3*, 1492-JC3, 1492-JDC3, 1492-J3, 1492-J2Q, 1492-J3TW	
1492-M5X15	<b>1492-ERL15,</b> 1492-LMP30	
1492-M5X30	1492-WGB5	
1492-M6X5	<b>1492-EAJ15,</b> 1492-J4, 1492-JG4, 1492-L4, 1492-L4T, 1492-L4Q, 1492-LD4, 1492-LD4C, 1492-LG4, 1492-LG4T, 1492-LDG4, 1492-LDG4C, 1492-LD4DF, 1492-LD4DR, 1492-LD4RB*, 1492-LD4SS, 1492-J4M	
1492-M6X10	1492-L4, 1492-L4T, 1492-L4Q, <b>1492-LD4, 1492-LD4C</b> , 1492-LG4, 1492-LG4T, 1492-LG4Q, <b>1492-LDG4, 1492-LDG4C, 1492-LD4DF, 1492-LD4DR, 1492-LD4RB*, 1492-LD4SS, Bulletin 931 Signal Condioners</b>	
1492-M6X12	1492-J4, 1492-JG4, 1492-J4M, 1492-L6, 1492-L6T, 1492-L10, 1492-LG6, 1492-LG6T, 1492-LG10, 1492-EAJ35	

Table 1.A Allen–Bradley Markers for Allen-Bradley Products

Marker/Label Catalog No.	Use With These Allen-Bradley Terminal Blocks and Other Products
1492-M7X12	<b>1492-EAJ35, 1492-EAHJ35, 1492-H4, 1492-H5, 1492-H6, 1492-H7,</b> 1492-J6, 1492-J10, 1492-J16, 1492-J35, 1492-J50, 1492-J70, 1492-J120, 1492-JG6, 1492-JG10, 1492-JG16, 1492-JG35, 1492-JG50, 1492-JG70, 1492-JG120, 1492-L16, 1492-L16D, 1492-L35, 1492-LG16, 1492-LG35
1492-M8X5	1492-J6, 1492-J10, 1492-J16,1492-J35,1492-J50,1492-J70, 1492-JG6, 1492-JG10, 1492-JG16, 1492-JG35, 1492-JG50, 1492-JG70, 1492-L6, 1492-L6T, 1492-L10, 1492-L16, 1492-L16D, 1492-L35, 1492-LG6, 1492-LG6T, 1492-LG10, 1492-LG16, 1492-LG35
1492-MR5X8	1492-J3, <b>1492-JD3, 1492-JD3C, 1492-JD3F, 1492-JDG3,</b> <b>1492-JDG3C, 1492-JD3DF*, 1492-JD3DR*, 1492-JD3RB*,</b> <b>1492-JD3RC001, 1492-JD3SS, 1492-L3</b>
1492-MR6X8	1492-J4, 1492-J4M, 1492JG4, 1492-L4T, 1492-L4Q, 1492-LD4 1492-LD4C, 1492-LG4, 1492-LG4T, 1492-LG4Q, 1492-LDG4, 1492-LDG4C, 1492-LD4DF, 1492-LD4DR, 1492-LD4RB*, 1492-LD4SS, 1492-L6, 1492-L6T, 1492-L10, 1492-LG6, 1492-LG6T, 1492-LG10, 1492-EAJ35
1492-MR5X10	1492-ERL35, 1492-LM30, 1492-LMG3, 1492-LMJ3, 1492-LMJG3, 1492-LMP3, 1492-LMP30, 1492-L3T, 1492-L3Q, 1492-LD3, 1492-L3QS, 1492-LD3C, 1492-LG3, 1492-LG3T, 1492-LG3Q, 1492-LDG3C, 1492-LKD3, 1492-L3P, 1492-LC3, 1492-LDC3, Bulletin 931 Signal Conditioners, 1492-JD3P, 1492-LM3, 1492-LDG3P, 1492-LDAG3
1492-MR5X12	1492-J20, 1492-J3, 1492-J3TW, 1492-J3F, 1492-JG20, 1492-JG3, 1492-JG3TW, 1492-JKD3, 1492-JKD3TP, 1492-J3P, 1492-J3PTP, 1492-JTC3*, 1492-JC3, 1492-JDC3
1492-MR6X12	1492-J4, 1492-JG4, 1492-J4M, <i>1492-L6T, 1492-L10, 1492-LG6, 1492-LG6T, 1492-LG10</i>
1492-MR8X12	<b>1492-J6,</b> 1492-J10, 1492-J16, 1492-J35, 1492-J50, 1492-J70, 1492-J120, 1492-J240, 1492-JG10, 1492-JG16, 1492-JG35, 1492-JG50, 1492-JG70, 1492-JG120, 1492-L6, 1492-L6T, 1492-L10, 1492-L16, 1492-L16D, 1492-L35, 1492-LG6, 1492-LG6T, 1492-LG10, 1492-LG16, 1492-LG35
1492-MC4X5	Some terminal blocks from Murr and Phoenix Contact
1492-MC5X5	Some terminal blocks from Murr and Phoenix Contact
1492-MC6X5	1492-FB* fuse blocks, some terminal blocks from Murr and Phoenix Contact
1492-MC7X5	Some terminal blocks from Phoenix Contact
1492-MC5X4	Some terminal blocks from Phoenix Contact
1492-MC5X8	Some terminal blocks from Entrelec, Phoenix Contact, Telemecanique, Wieland
1492-MC5X10	Some terminal blocks from Entrelec, Phoenix Contact, Telemecanique, Wieland
1492-MC5X12	Some terminal blocks from Entrelec, Phoenix Contact, Telemecanique, Wieland

Table 1.A Allen–Bradley Markers for Allen-Bradley Products

Marker/Label Catalog No.	Use With These Allen-Bradley Terminal Blocks and Other Products	
1492-MC6X10	<b>Bulletin 700-HL relays</b> , Some terminal blocks from Entrelec, Phoenix Contact, Telemecanique, Wieland	
1492-MC8X10	<b>Bulletin 700-HL relays,</b> Some terminal blocks from Entrelec, Phoenix Contact, Telemecanique, Wago, Wieland	
1492-MCS7X10	Some terminal blocks from Siemens	
1492-MCS5X10	Some terminal blocks from Siemens	
1492-MCS6X10	Some terminal blocks from Siemens	
1492-MCS7X7	Some terminal blocks from Siemens	
1492-MCS5X8	Some terminal blocks from Siemens	
1492-MCS6X8	Some terminal blocks from Siemens	
1492-MCW4X9	Some terminal blocks from Murr and Wago	
1492-MCW5X9	Some terminal blocks from Murr and Wago	
1492-MCW5X9F	Some terminal blocks from Murr and Wago	
1492-MCW5X5	Some terminal blocks from Murr and Wago	
1492-MCW6X9	Some terminal blocks from Murr and Wago	
1492-MH5X10	1492-L3, <b>1492-L3T, 1492-L3Q, 1492-L3QS</b> , 1492-LG3, <b>1492-LG3T, 1492-LG3Q, 1492-LMJ3, 1492-LMJG3, 1492-LM3Q, 1492-LMG3, 1492-LMP3, 1492-LMP3Q</b>	
1492-MH5X15	<b>1492-L3,1492-L3T, 1492-L3Q</b> 1492-L10, 1492-L16, 1492-L16D, 1492-L35, <b>1492-LG3</b> , <b>1492-LG3T, 1492-LG3Q</b> , 1492-LG10, 1492-LG16, 1492-LG35	
1492-MH6X12	1492-L4, 1492-L4T, 1492-L4Q, 1492-L6, 1492-L6T, 1492-LG4, 1492-LG4T, 1492-LG4Q, 1492-LG6, 1492-LG6T	
1492-MN81	1492-HM1, 1492-HM2, 1492-HM3, 1492-CB*	
1492-MN83	<b>1492-CB*</b> , 1492-HM3	
1492-MAS9X17	Any equipment (self-adhesive)	
1492-MAS6X15	Bulletin 700 relays, any equipment (self-adhesive)	
1492-MAS9X11	1760-Pico, any equipment (self-adhesive)	
1492-MS5X5	1492-WM3, 1492-WMD1	
1492-MS5X9	<b>1492-WR3, 1492-WTF3*, 1492-WTS3*,</b> 700-HA, Bulletin 800F contact blocks	
1492-MS5X12	<b>1492-W3,</b> 700-HA	
1492-MS6X9	<i>1492-RFB4*, 1492-RAFB4*,</i> <b>1492-WM4, 1492-WMG4, 1492-W4TW</b> , 700-HA	
1492-MS6X12	<b>1492-W4, 1492-W6,</b> 1492-W10 1492-W16S <b>, 1492-WG4, 1492-WG6,</b> 1492-WG10S, 1492-WG16S <b>,</b> 700-HA	
1492-MS8X9	700-HA, <b>1492-H4, 1492-H5, 1492-H6, 1492-H7, 1492-WFB4*</b>	

Table 1.A Allen–Bradley Markers for Allen–Bradley Products

Marker/Label Catalog No.	Use With These Allen-Bradley Terminal Blocks and Other Products
1492-MS8X12	1492-H4, 1492-H5, 1492-H6, 1492-H7, 1492-RFB4*, 1492-RAFB4*, 1492-W10, 1492-WFB4*, 700-HA, 1492-W165, 1492-WG10, 1492-WG165
1492-MS8X17	700-HN204, 700-HN205
1492-MS9X20	1667 PanelConnect
1492-MS10X17	100-C, 100-D, 700-CF, 140, 193-E1, 193-E3, 1492-REC*
1492-MW9X24	Wire/cable from 6 AWG (from 16.0 mm²)
1492-MW10X23	Wire/cable from 6 AWG (from 16.0 mm²)
1492-MW14X23	Wire/cable from 6 AWG (from 16.0 mm²)
1492-MW11X60	Wire/cable from 6 AWG (from 16.0 mm²)
1492-MW5-21	#1210 AWG (4.06.0 mm <sup>2</sup> ) wire
1492-MW6-21	#108 AWG (6.010.0 mm <sup>2</sup> ) wire
1492-MW7-21	#86 AWG (10.016.0 mm <sup>2</sup> ) wire
1492-MWC1-21	#2018 AWG (0.51.0 mm <sup>2</sup> ) wire
1492-MWC3-21	#1814 AWG (0.752.5 mm <sup>2</sup> ) wire
1492-MWC4-21	#12 AWG (2.54.0 mm <sup>2</sup> ) wire
1492-MWC1-12	#2018 AWG (0.51.0 mm <sup>2</sup> ) wire
1492-MWC3-12	#1814 AWG (0.752.5 mm <sup>2</sup> ) wire
1492-MWC4-12	#12 AWG (2.54.0 mm <sup>2</sup> ) wire
1492-SM5X10	1492-JD3P, 1492-JD3PTP, 1492-JD3PSS, 1492-JD3PSSTP, 1492-JDG3P, 1492-JDG3PSTP, 1492-JDG3PSS, 1492-JDG3PSSTP
1492-M5X30	1492-GMC
1492-MD6X9	1732 I/O

- Catalog numbers in bold indicate the preferred marker.
- **2** Catalog numbers in italics indicate the corner markers of a spring-clamp terminal block.
- Many bulletin number 1492-M markers have identical mounting feet, resulting in the ability to use many different types of markers in a given product.

### **ClearTools Software**

Clear Tools software is a Microsoft Windows-based program that creates files containing marker card layouts. These files contain all the information to print multiple base plates full of marker cards. See Table 1.B lists the available marking system accessories.

#### **Accessories**

**Table 1.B Accessories** 

Item	Catalog No.	Description
Disposable Pen	1492-PLOTPEN25	Disposable ink pen with ∅0.25 mm tip
Disposable Pen	1492-PLOTPEN35	Disposable ink pen with Ø0.35 mm tip
Pen Adapter	1492-PLOTADPT	Pen adapter for use with Sharpie™ Ultra Fine Point Pen <b>①</b>
Pen Station Service Kit 2	1492—PLOTSERV	Pen Station Service Kit for replacing pen priming tabs and ink-coated pen sealing units
Base Plate	1492-PLOTPLT	Base plate for the plotter
Plotter Software 2	_	CD of ClearTools Software
Single Plate	1492-PLOTPLTA	Single plate used with wire markers (not included in plotter kit)

- Recommended when plotting 12-point font or larger.
- The latest software can be downloaded at: www.ab.com/industrialcontrols/products. Select Connection Devices > Terminal Blocks > Marking Solutions > X-Y Plotter Marking System > Software



It is important to only use the above accessories with the plotter. Use of other accessories may damage the plotter.

**Table 1.C Inlay Spacer Settings** 

Marker Card	Inlay Position Number
1492-M3X5	3
1492-M3X12	2
1492-M5X5	3
1492-M5X8	2
1492-M5X10	2
1492-M5X12	2
1492-M5X15	2
1492-M5X30	3
1492-M6X5	3
1492-M6X10	2
1492-M6X12	2
1492-M7X12	2
1492-M8X5	3
1492-MAS6X15	5
1492-MAS9X11	5
1492-MAS9X17	5
1492-MC4X5	4
1492-MC5X4	2
1492-MC5X5	4
1492-MC5X8	1
1492-MC5X10	1
1492-MC5X12	1
1492-MC6X5	4
1492-MC6X10	1
1492-MC7X5	2
1492-MC8X10	1
1492-MCS5X8	3
1492-MCS5X10	3
1492-MCS6X8	3
1492-MCS6X10	3
1492-MCS7X7	3
1492-MCS7X10	3
1492-MCW4X9	4
1492-MCW5X5	4
1492-MCW5X9	4


**Table 1.C Inlay Spacer Settings** 

1492-MCW6X9F       3         1492-MCW6X9       4         1492-MH5X10       6         1492-MH5X15       6         1492-MH6X12       6         1492-MN81       1         1492-MN83       1         1492-MR5X8       2         1492-MR5X10       2         1492-MR5X12       2         1492-MR6X8       2         1492-MR6X12       2         1492-MS6X12       2         1492-MS5X5       2         1492-MS5X9       1         1492-MS6X12       1         1492-MS6X12       1         1492-MS8X9       1         1492-MS8X17       2         1492-MS9X20       2         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW11X60       5         1492-MWC1-12       1         1492-MWC1-21       1         1492-MWC1-21       1         1492-MWC1-21       1	Marker Card	Inlay Position Number
1492-MH5X10       6         1492-MH5X15       6         1492-MH6X12       6         1492-MN81       1         1492-MN83       1         1492-MR5X8       2         1492-MR5X10       2         1492-MR6X12       2         1492-MR6X12       2         1492-MR6X12       2         1492-MSSX5       2         1492-MS5X5       2         1492-MS5X12       6         1492-MS6X9       1         1492-MS6X9       1         1492-MS8X9       1         1492-MS8X12       1         1492-MS8X17       2         1492-MS9X20       2         1492-MV9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MWC1-12       1         1492-MWC1-12       1         1492-MWC1-21       1	1492-MCW5X9F	3
1492-MH6X12       6         1492-MN81       1         1492-MR83       1         1492-MR5X8       2         1492-MR5X10       2         1492-MR6X12       2         1492-MR6X8       2         1492-MR6X12       2         1492-MS5X5       2         1492-MS5X5       2         1492-MS5X12       6         1492-MS6X9       1         1492-MS6X12       1         1492-MS8X17       2         1492-MS8X17       2         1492-MS9X20       2         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MCW6X9	4
1492-MH6X12       6         1492-MN81       1         1492-MR5X8       2         1492-MR5X10       2         1492-MR5X12       2         1492-MR6X8       2         1492-MR6X12       2         1492-MS5X5       2         1492-MS5X5       2         1492-MS5X9       1         1492-MS6X9       1         1492-MS6X12       1         1492-MS8X9       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MW11X60       5         1492-MW11X60       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MH5X10	6
1492-MN81       1         1492-MR5X8       2         1492-MR5X10       2         1492-MR5X12       2         1492-MR6X8       2         1492-MR6X12       2         1492-MR8X12       2         1492-MS5X5       2         1492-MS5X9       1         1492-MS5X12       6         1492-MS6X9       1         1492-MS6X12       1         1492-MS8X9       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS9X20       2         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MH5X15	6
1492-MN83       1         1492-MR5X8       2         1492-MR5X10       2         1492-MR5X12       2         1492-MR6X8       2         1492-MR6X12       2         1492-MS5X5       2         1492-MS5X9       1         1492-MS5X12       6         1492-MS6X9       1         1492-MS8X12       1         1492-MS8X12       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS9X20       2         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MH6X12	6
1492-MR5X8       2         1492-MR5X10       2         1492-MR5X12       2         1492-MR6X8       2         1492-MR6X12       2         1492-MR5X12       2         1492-MS5X5       2         1492-MS5X9       1         1492-MS6X9       1         1492-MS6X12       1         1492-MS8X9       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS9X20       2         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MN81	1
1492-MR5X10       2         1492-MR6X12       2         1492-MR6X12       2         1492-MR8X12       2         1492-MS5X5       2         1492-MS5X9       1         1492-MS5X12       6         1492-MS6X9       1         1492-MS8X9       1         1492-MS8X12       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS9X20       2         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MN83	1
1492-MR5X12       2         1492-MR6X8       2         1492-MR6X12       2         1492-MS5X5       2         1492-MS5X9       1         1492-MS5X12       6         1492-MS6X9       1         1492-MS6X12       1         1492-MS8X9       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW01-12       1         1492-MWC1-21       1	1492-MR5X8	2
1492-MR6X8       2         1492-MR6X12       2         1492-MR8X12       2         1492-MS5X5       2         1492-MS5X9       1         1492-MS6X9       1         1492-MS6X12       1         1492-MS8X9       1         1492-MS8X17       2         1492-MS9X17       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MR5X10	2
1492-MR6X12       2         1492-MR8X12       2         1492-MS5X5       2         1492-MS5X9       1         1492-MS6X12       6         1492-MS6X12       1         1492-MS8X9       1         1492-MS8X12       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MWV10X23       5         1492-MWV14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MR5X12	2
1492-MR8X12       2         1492-MS5X5       2         1492-MS5X9       1         1492-MS5X12       6         1492-MS6X9       1         1492-MS8X9       1         1492-MS8X12       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MWV14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MR6X8	2
1492-MS5X5       2         1492-MS5X9       1         1492-MS5X12       6         1492-MS6X9       1         1492-MS8X12       1         1492-MS8X12       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MR6X12	2
1492-MS5X9       1         1492-MS5X12       6         1492-MS6X9       1         1492-MS8X12       1         1492-MS8X12       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MR8X12	2
1492-MS5X12       6         1492-MS6X9       1         1492-MS6X12       1         1492-MS8X9       1         1492-MS8X12       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MS5X5	2
1492-MS6X9       1         1492-MS6X12       1         1492-MS8X9       1         1492-MS8X12       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MS5X9	1
1492-MS6X12       1         1492-MS8X9       1         1492-MS8X12       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MS5X12	6
1492-MS8X9       1         1492-MS8X12       1         1492-MS8X17       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MS6X9	1
1492-MS8X12     1       1492-MS8X17     2       1492-MS9X20     2       1492-MS10X17     3       1492-MW9X24     5       1492-MW10X23     5       1492-MW11X60     5       1492-MW14X23     5       1492-MWC1-12     1       1492-MWC1-21     1	1492-MS6X12	1
1492-MS8X17       2         1492-MS9X20       2         1492-MS10X17       3         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MS8X9	1
1492-MS9X20     2       1492-MS10X17     3       1492-MW9X24     5       1492-MW10X23     5       1492-MW11X60     5       1492-MW14X23     5       1492-MWC1-12     1       1492-MWC1-21     1	1492-MS8X12	1
1492-MS10X17       3         1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MS8X17	2
1492-MW9X24       5         1492-MW10X23       5         1492-MW11X60       5         1492-MW14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MS9X20	2
1492-MW10X23     5       1492-MW11X60     5       1492-MW14X23     5       1492-MWC1-12     1       1492-MWC1-21     1	1492-MS10X17	3
1492-MW11X60       5         1492-MW14X23       5         1492-MWC1-12       1         1492-MWC1-21       1	1492-MW9X24	5
1492-MW14X23     5       1492-MWC1-12     1       1492-MWC1-21     1	1492-MW10X23	5
1492-MWC1-12     1       1492-MWC1-21     1	1492-MW11X60	5
1492-MWC1-21 1	1492-MW14X23	5
	1492-MWC1-12	1
1492-MWC3-12	1492-MWC1-21	1
1702 1010000 12	1492-MWC3-12	1
1492-MWC3-21 1	1492-MWC3-21	1
1492-MWC4-12 1	1492-MWC4-12	1
1492-MWC4-21 1	1492-MWC4-21	1
1492-SM5X10 2	1492-SM5X10	2
1492-SM6X10 2	1492-SM6X10	2
1492-MD6X9 3	1492-MD6X9	3

- **1.** Line up the number on the inlay with the notched locator on the base plate.
- 2. Slide right side of marker card under ledge on plotter plate.
- **3.** Line-up first notch on the left side of the marker card to the notch on the plotter plate.
- **4.** Press the left side on the marker card down on to the plotter plates. For plotter plates with the adhesive strip, refer to Adhesive Strip Preparation on page A-1.







Installing Marker Card onto Plate

Table 1.D Inlay Spacer Requirement Using Special Plate, 1492-PLOTPLTA

Marker Card	Inlay
1492-MW5-21	Inlay needed
1492-MW6-21	No inlay needed
1492-MW7-21	No inlay needed

# **Initial Setup**

## **Chapter Objectives**

This chapter shows how to:

- Set up the Plotter
- Installing the Plotter Driver
- Activating the Plotter with ClearTools

## Setup

#### Location

A dry, dust-free room is the ideal environment for the plotter. If possible, do not install the device in damp or very dusty areas. Do not expose the system to direct sunlight. Please ensure the connections on the right-hand side of the device are accessible all times. Position the plotter firmly on the work surface where it is to be used, ensuring it is level. Please ensure the writing arm can move freely and is not obstructed by other objects.

#### **Connections**

1. Install the power cord and plug into outlet.

The plotter power supply features a variable AC input voltage of 100 to 240V AC/50...60 Hz. The power connection can be replaced by way of adapter plugs, as required.

**2.** Connect the plotter to the computer using the USB cable. The USB port is located on the right-hand side of the plotter.

### **Installing the Plotter Driver**

# Installing the driver for the plotter 1492-PLTKIT Series E within Windows 2000

- 1. Login into your Computer using an account with administrative rights.
- 2. Connect the Plotter to your system and switch on the power. The "Found New Hardware Wizard" starts. Click on "Next".



3. Choose "Search for a suitable driver for my device (recommended)" and then click "Next".



4. Choose "Specify a location" and click on "Next".



5. In the opening window, click on "Browse" and select the subfolder "W2K" in the folder "Psetup" on your installation CD. Confirm with "Open" and then with "OK".






6. Then click on "NEXT". The installation begins now.



7. During the installation a message appears stating "The software you are about to install does not contain a Microsoft digital signature..." and asks "Do you want to continue the installation?" Click on "Yes".



**8.** Click on "Finish" to close the window.




The driver for the connected device 1492-PLTKIT Series E is now installed and ready to use.

# Installing the driver for the 1492-PLTKIT Series E within Windows Vista

1. Login into your Computer using an account with administrative rights.


Before you begin installing the driver you need to know if you are running the 32-bit or the 64-bit version of Windows Vista on your computer. If you are not sure, you can open the following window:

Start > Control Panel > System and Maintenance > System or Start > Control Panel > System (when using the classical view of the control panel).



Within the line "System type" you can find the information needed.

**2.** Go to "Start > Control Panel > Printers". Then connect your 1492-PLTKIT Series E plotter to the system and switch on the power. If the driver is already installed, you will find your plotter in the list of Printers and Faxes.




If the driver is not yet installed, the window "Found New Hardware" appears.





Click on "Locate and install driver (recommended)".

**3.** If a window appears, asking "Allow windows to search online....?" answer with "Don't search online".



**4.** After the following window appears, insert the installation CD into the drive and click on "Next".






**5.** The recognized drivers on the CD are listed.


Choose the entry ...\Psetup\vista\_64\1492\_pltkit.inf (for the 64-Bit version of Windows Vista). or ...\Psetup\vista\_32\1492\_pltkit.inf (for the 32-Bit version of Windows Vista) and click on "Next", to start the installation.


If this list does NOT appear (or you have stored the driver files at a different location on your computer), you can search for the driver files manually.

- 6.1. Click on "I don't have the disk. Show me other options." (in the window shown above)
- 6.2. Choose "browse my computer for driver software (advanced)"




Click on "Browse" and select the path Psetup\vista\_32 or Psetup\vista-64, depending on whether you have a 32-bit or 64-bit version of Windows Vista. (In order to see which Windows Vista version you have, navigate to Start > Control Panel > System and Maintenance > System or Start > Control Panel > System.)





Confirm with "OK" and then "Next". The installation starts now.

7. During the installation the following message appears: "Windows can't verify the publisher of this driver software":




Choose "Install the driver software anyway".

**8.** After a successful installation Windows issues the following message. Press click on **"Close"** to complete the installation.



**9.** Reopen the window "Control Panel > Printers". Your plotter should now appear in the list of Printers and Faxes.




### Installing the driver for the 1492-PLTKIT Series E within Windows XP

- 1. Login into your Computer using an account with administrative rights.
- **2.** Connect the Plotter to your system and switch on the power. The **"Found New Hardware Wizard"** starts.
- **3.** Choose **"Install from a list or specific location"** and then click **"Next"**.



4. In the next window, choose "Search for the best driver in these locations" and check the box "Include this location in the search", click on "Browse" and select the subfolder "XP" in the folder "Psetup" on your installation CD. Confirm with "OK" and then with "Next".



The driver will now be installed. During the installation the following message appears:

"The software you are installing for this hardware: ... has not passed Windows Logo testing...".



**5.** Choose **"Continue Anyway"** and wait until the installation is completed. This can take about one minute.




**6.** Click on "Finish" to close the window.

The driver for the connected plotter **1492-PLTKIT Series E** is now installed and can be used.

# Installing the driver for the 1492-PLTKIT Series E within Windows 7

- 1. Login into your Computer using an account with administrative rights.
- **2.** Before you start the installation, you need to know if you are running the 32-bit version or the 64-bit version of Windows 7 on your computer. If you are not sure, you can open the following window:


Start > Control Panel > System




Within the line "System type" you can find the information needed.

**3.** Connect your 1492-PLTKIT Series E plotter to the system and switch on the power.

Go to "Start > Devices and Printers". If the driver is already installed, you will find your plotter in the list of Printers and Faxes.




If the driver is not yet installed, then an entry **"USB- Printing Support"** appears in the Unspecified list.



4. In this case, take the following steps:


Double-Click on the entry "USB Printing Support".

5. In the new window that appears, choose the tab "Hardware".




**6.** Double-click on the entry **"Rockwell 1492-PLTKIT..."** in the **"Device Functions"** list.

Choose the tab "Driver" in the next window.



7. Click on the button "Update Driver...". The following window appears.

Choose "Browse my Computer for driver software".



8. Click on "Browse" and select the path Psetup\W7\_32 or Psetup\w7\_64 on your installation CD, depending whether you have a 32-Bit or 64-Bit version of Windows 7:





9. Confirm with "OK" and then "Next". The installation starts now.

10. During the installation the following message appears: "Windows can't verify the publisher of this driver software":




Choose "Install the driver software anyway".

**11.** After a successful installation Windows issues the following message. Press **"Close"** to complete the installation.



**12.** Reopen the window "Devices and Printers". Your plotter should now appear in the list of Printers and Faxes.



# Installing a Pen in the Pen Station

- 1. Turn the power on by pressing the "On" button,
- **2.** Press the "Pen Station open/close" button. This will lower the pen stations to allow a pen to be placed in the station
- **3.** Follow the pen instructions for use on the 1492-PLOTPEN25 or 1492-PLOTPEN35 box by: assembling the pen point to ink cartridge, shaking pen back and forth to activate ink.
- **4.** Insert pen into pen station. The default pen station is #1 (closest to user.)

#### **IMPORTANT**

It is important only the 1492-PLOTPEN25 or 1492-PLOTPEN35 pens be installed in the pen station. Use of a different pen may result in damage to the pen or plotter.

**5.** Press the "Pen Station open/close" button. This will close the pen station, sealing it in place. You are now ready to plot.

#### **Removing a Pen from the Pen Station**

- **1.** Press the "Pen Station open/close" button. This will open the pen stations to allow a pen to be removed.
- **2.** Remove the pen from the pen station. Place the cap on the pen.
- **3.** Press the "Pen Station open/close" button. This will close the pen station.
- **4.** Turn the power off by pressing the "Off" button.

# Plotting with the 1492-PLOTADPT

The 1492-PLOTADPT allows the user to plot with a standard Sharpie<sup>TM</sup> UltraFine point marker (which can be purchased in various colors). The pen station will not hold this accessory, so the next process must be followed:

- 1. Open ClearTools software.
- 2. Create the marker layout you desire.
- **3.** In the software, select "Plot," then "Settings."
- **4.** Set "Pen selection" to "No." This will cause the plotter to plot without taking a pen from the pen station.
- 5. Carefully install the 1492-PLOTADPT (with the Sharpie<sup>TM</sup> pen affixed to it) in the arm of the plotter, being careful not to move the plotter arm while performing this operation.
- **6.** Begin plotting as usual with the ClearTools software. Note the pen will have to be manually removed when you have finished plotting.

# Activating the Plotter with ClearTools

#### Introduction


This chapter describes the setup, activation, mapping/calibration of the plotter to the printed marker cards, and plotting options while using ClearTools.

#### **Switching to Plot Mode**

Before you can plot with ClearTools, the software must be put into "Plot Mode"

1. Select the icon on the toolbar, or go to "File" and select "Toggle Plot Mode"






Note: Plot mode is active when "Plot Mode" is written adjacent to the version number or when the following icon in the toolbar appears



### **Startup options for Plot Mode**

1. The display in Plot Mode can be set up via the Options window (select Tools > Options > Plotter).



Note: Activate the "Start in Plot Mode" checkbox if Plot Mode is to be launched in the program after a restart, when opening an application-file or when creating a new project.

### **Printing/Plotting**

Before plotting a card, the card must be calibrated and mapped to the plotter.

# **Mapping to Plotter:**

- 1. After you have filled out your card as desired, go to File? Print
- 2. Select the Plotter (1492-PLTKIT Series E) in the "Printer" pull down menu
- **3.** Click "Map" on the print screen. When the following pop up appears, select the plotter and click "OK"



Note: Each time a new card is selected it will need to be mapped to the plotter


#### **General Calibration:**


Plot a card with a row of X's going vertically down the marker tags, and with a row going horizontally across the marker tags.







- -If the X's are centered on all of the tags, do not change any calibration settings and move onto plotting your cards.
- -If the X's are not centered, follow the steps on the next page.





2. Select "Zero Points"





- **3.** Place a piece of tape over the engraved "+" on the upper left corner of the plotter; this is your ideal Zero Point.
- **4.** Select the pen you wish to use for plotting ("No Pen" if you are using a Sharpie)
- **5.** Press "Plot Zero Point" and watch where on the tape the plotter draws a "+" in relation to the engraved one on the plotter
- **6.** If the plotted "+" is above or below the engraved one, adjust the Y setting, if it is to the right or left, adjust the X setting

-Increasing X value: Moves the "+" to the right

- -Decreasing X value: Moves the "+" to the left
- -Increasing Y value: Moves the "+" up
- -Decreasing Y value: Moves the "+" down

#### Note: Suggested increment of change: 5.0

7. Continue adjusting the settings until the Zero points match, then reprint the test card and determine if the calibration is correct.

## **Adjusting Marker Type**


If calibrating the Zero Point does not seem to be effective on a single card type, go to File → Print → Calibration and select "Adjust Marker Type" to

TIP




create specific settings for that card. If you are satisfied with your calibration, move onto the "Plotting" section.

1. Go to File→ Print→ Calibration and select "Adjust Marker Type"



**2.** The following screen will appear, verify that the plotter is selected under "Options"



TIP




**3.** Use the Offset X and Offset Y values to adjust the single cards calibration

Increase Offset X: Text moves down Decrease Offset X: Text moves up Increase Offset Y: Text moves left Decrease Offset Y: Text moves right


Note: Suggested increment of change: 0.5mm

Note: The directions are based on a vertical card as placed on the plotter (see image below)



### **Plotting**

- 1. To plot a card, fill out the card as desired and go to File→ Print
- 2. Click "Print." The following window will appear:



A. The inlay position is indicated by whichever number is next to the red bar (position 2 in this case)

> 3. Verify that the inlay is in the correct position (a), that the card is on the right frame (b), and that the correct pen is selected (c). If they are all correct, click "Continue Plotting"


Note: Pen Selection—Select the pen that is to be used in the plotter. If "No Pen" is selected, an external pen (i.e. a Sharpie) can be used that is not returned to the pen holder.

### **Plotting Multiple Cards**


Multiples of the same card and multiple different cards can both be plotted in the same print session.

#### Multiples of the same card:


1. Create multiple "Pages" of a marker card by right clicking on the bottom tab strip in ClearTools and selecting "Insert New Page"



- **2.** Fill the multiple pages as desired. Each page can be treated as a different Marker Card
- 3. Go to File→ Print
- **4.** Select "Single Pages" on the Print Window, and select the desired page's check boxes.



5. Select "Print"



- **6.** Verify that all the inlay positions are correct, and that the desired pen is selected.
- 7. Select "Continue Plotting"

**Note:** If you do not want to print five marker cards, or wish to skip a frame, deselect the "Use Frame" checkbox located above each frame. Any frames not selected will not be plotted upon.


**Note:** When plotting more than five cards in a single plot job, multiple "Marker Card Fixture" (see above) windows will appear. Select "Continue Plotting" on the first window, but do not on the second until the first batch of marker cards are plotted upon and you have put new marker cards into the frames.

#### Plotting Multiple Different Cards:


1. In the Project Explorer window right click and select "Insert New Marker Type" to create multiple cards



2. Fill the cards as desired, and go to File -- Print



- **3.** You must map all different cards to the plotter. Do this by clicking a card, selecting the plotter from the pull down menu, and clicking "Map"
- 4. Click "Print"



- **5.** Verify that all the inlay positions, Marker Card to frame orientations, and the pen selection are correct.
- **6.** Select "Continue Plotting"

# Notes:

# **Operation of Plotter**

### **Chapter Objectives**

This chapter covers:

- Operation
- ON/OFF Buttons
- Clear Buffer
- Pen Station Open/Close Button
- Stop/View Button


### **Operation**

Once you have installed the plotter and connected the power supply and data cable, you may switch the potter on.

**IMPORTANT** 

Before switching the device on, please ensure there are no objects on the writing/plotting area which might prevent the writing arm from moving freely.

All settings and commands are entered using the control panel.



### **ON/OFF Buttons**

The ON/OFF buttons are used to activate and deactivate the device. When the plotter is switched on, the writing arm moves to the top right-hand corner of the labeling area. The green light comes on when the system is ready for use and ready to receive data from the PC.

#### **Clear Buffer**

If the plotter contains data, the yellow light will come on. You can delete this data by first making sure the system is in the stop mode (red light on). The

stop mode is entered by pressing the "Stop" button. Then delete the data by pressing the "Clear Buffer" button.

#### **Pen Station Open/Close Button**

Pressing the "Pen Station Open/Close" button will operate the pen station. A pen must be installed in the bottom location prior to plotting (unless ClearTools software has pen selection set to "no," in which case the pen must be installed manually in the plotter arm).

#### **IMPORTANT**

Only 1492-PLOTPEN 25 and 1492-PLOTPEN 35 plotter pens may be used, as the sealing system is designed specifically for these plotter pens.

When using the 1492-PLOTADPT, the ClearTools software must be the pen selection set to "No."

Using other plotter pens and writing instruments may damage the device.

Operation of the pen station is only possible when the system is in the stop mode. When the pen station has been opened, you can insert the plotter pens into the corresponding storage holders and then re-close the pen station by pressing the "Pen Station Open/Close" button again.

#### **IMPORTANT**

Do not leave the pen station open for extended periods, as the pens will dry out.

You may leave the plotter pens in the pen station because the optimized seal largely prevents the pens from drying out. If the storage holders become soiled over time, replace them with the 1492-PLOTSERV kit.

### Stop/View Button

If the "Stop/View" button is activated while the plotter is in action, the job will pause immediately and the plotter pen will recalibrate, return the pen to the pen station, and the writing arm will return to the right-hand corner. The red light will signal the interruption. Pressing the "Stop/View" button again will cause the plotter to continue plotting where it left off. The red light will go out.

#### IMPORTANT

Inserting a pen into the writing arm holder by hand can result in the writing arm inadvertently moving the writing arm and compromise calibration.

After inserting the pen, press the "Stop/View" button twice in succession to recalibrate the system.

### **Cursor and Pen Up/Down Buttons**

The "Cursor" buttons are used to move the writing arm manually in all directions.

The "Pen Up/Down" buttons lowers and raises the plotter pen. To raise or lower the pen, the system must be in the stop mode.

**IMPORTANT** 

These key functions are not used for normal operation. They are intended solely for service functions.

Open the pen station before using the plotter. Insert the plotter pen into the pen station and then close the pen station

# Notes:

# **Troubleshooting and Maintenance**

### **Chapter Objectives**

This chapter describes how to:

- Troubleshoot the marking system
- Perform routine maintenance
- Clean the plotter pens
- Technical Specifications

# Using the Troubleshooting Chart

Table 4.A is a troubleshooting chart. This chart lists the most common operating problems, probable causes, and steps to correct the problem. If you encounter a problem that is not listed in the table, contact Rockwell Automation Technical Support at (440) 646-3434, options: 3, 2, 4, 2, 5.

### **Required Equipment**

A voltmeter is required for verifying that the correct voltage is supplied to the plotter. The voltmeter is also required for verifying the correct communications cable configuration.

**Table 4.A Troubleshooting Chart** 

Probable Cause(s)	Corrective Action(s)
Plotter not plugged in.     Improper connection to power source.	Verify that plotter is plugged in.     Verify 110/220 VAC, 50/60 Hz     voltage at power source.
Faulty communications cable.     Wrong COM or USB port selected.     USB plugged in upside down.	Check cable connections.     Verify cable is plugged into COM or USB port selected in ClearTools.     If steps 1 and 2 do not restore communications, turn off plotter, unhook communications cable, reboot computer, hookup communications cable, turn on plotter, and start ClearTools.
The Plotter is not calibrated correctly.	Check that plotter is calibrated as described in the ClearTools manual.
Defective marker pen or pen is out of ink.     Incorrect inlay placement.     Plotting speed is too fast.	<ol> <li>Replace marker pen.</li> <li>Check inlay installation per table         <ol> <li>Check inlay installation per table               <ol> <li>Reduce plotting speed.</li> </ol> </li> <li>Verify items 1 through 3 have been corrected. Contact Technical                     <ol> <li>Support at (440) 646-3434.</li> </ol> </li> <li>Reduce plotting speed.</li> </ol> </li> </ol> <li>Verify items 1 through 3 have been corrected. Contact Technical</li> <ol> <li>Support at (440) 646-3434.</li> </ol>
	1. Plotter not plugged in. 2. Improper connection to power source.  1. Faulty communications cable. 2. Wrong COM or USB port selected. 3. USB plugged in upside down.  1. The Plotter is not calibrated correctly.  1. Defective marker pen or pen is out of ink. 2. Incorrect inlay placement.

### **Plotter Maintenance**

The plotter has several sliding surfaces. These surfaces **do not** require any lubrication. However, dust and lint may adversely affect plotter performance. Use a dust cover to keep the plotter as clean as possible.

### **Cleaning Plotter**

1. If necessary, clean the plotter with a dry, lint-free cloth or a mild cleaning solution. **DO NOT** use abrasives.





Do not use aerosol cleaners, household wall cleaners, or anything containing solvents since these may damage certain components.

Never oil the mechanical parts of your plotter.

**2.** If the pen station storage holders (sealing units) are heavily soiled, they can be replaced. Order service kit 1492-PLOTSERV. This same service kit supplies additional priming surfaces.

### **Removing Sealing Unit from Pen Station**

- 1. Open pen station by pressing the "Open/Close" button.
- **2.** Apply the key (enclosed in the 1492-PLOTSERV) to the sealing unit and carefully lift the sealing unit from the holding device.

### **Inserting and Adjusting Sealing Unit**

- 1. Insert new sealing unit into pen station.
- **2.** Carefully press the sealing unit up to the limit-stop in the aluminium tube.
- **3.** Using the key, adjust the sealing unit until the key is parallel with the plotter surface. The opening on the side of the sealing unit should be centered.

### **Exchanging Priming Plates (for starting plotter pen)**

- 1. Remove the priming plates by pulling them out sideways.
- **2.** Insert new priming plates by sliding them into the guide on the side of the clamping device until the plates fit snugly.

### **Pen Maintenance**

1492-PLOTPEN 25 and 1492-PLOTPEN 35 must be removed from pen station, capped tightly and stored in the provided pen holder.



# **Technical Specifications**

**Table 4.B Technical Specifications** 


Plotter type	Flatbed plotter
Maximum plotting area	440 mm x 305 mm (17.3 in x 12 in)
Plotting speed	Max. 40 cm/sec. (15.75 in/sec)
Plotter pen	1492-PLOTPEN25, 1492-PLOTPEN35
Ports	USB level 1.1
Control language	Based on HP-GL 7475A
Buffer	16 MB
Drive	Two-phase step motor
Pen station	Max. four plotter pens with double seal
Addressable resolution	0.01 mm (0.0004 in)
Repeat accuracy	0.05 mm (0.002 in)
Repeat accuracy after pen change	0.05 mm (0.002 in) with optimum pen
Power supply type	Separate power supply with interchangeable adapter plug
Power supply voltage/current	Input voltage: 100-240V AC 50~60 Hz Input current: 0.3 A max. at 220V AC Output voltage: 24V DC Output current: 1.4 A max.
Operating temperature	10°35°C (50°95° F) at 35%75% relative humidity
Storage temperature	-10°50°C (14°122°F) at 10%90% relative humidity
Product compliance	UL-UL1950 CSA-950 VDE En60950
EMI certification	FCC class B FCC part 15 VDE class B EN 55022
Dimensions	660 mm x 440 mm x 125 mm (26 in x 17.3 in x 5 in)
Weight	8 kg (17.6 lb) (approximately)

# Appendix A

For Plotter Plates with Adhesive Strips, 1492-PLOTPLT, Series A

### **Adhesive Strip Preparation**

Before placing any markers on the base plate, carefully remove the five green protective coverings from the adhesive strips on the plate. This reveals an adhesive surface which aids in holding a marker card when the plotter is operating. Remove *only* the green protective covering, not the blue adhesive strip, from the plate.



# Index

A	Marker Types
Accessories	Marker Types, Adjusting
Adhesive Strip Preparation A-1	0
1 1	ON/OFF Buttons
	Operation
В	1
Base Plate	р
Buffer, Clear	Pen
,	Pen Maintenance
r	Pen Station Open/Close Button
Calibration 2.22	Plotter
Classing Platter	Base Plate
Clear Buffer	Maintenance4-2
Clear Tools Software	Cleaning
Connections	Plotter Driver Installation
Cusor and Pen Up/Down Buttons	Windows 2000
cusor and ren op, bown buttons	Windows Vista2-6
n	Windows XP
	Windows 72-14
Description, System and Components 1-1	Plotting with the 1492-PLOTADPT 2-20
	Plotting multiple cards2-27
_	Priming Plates, exchanging
E	
Exchanging Priming Plates 4-3	R
	Removing a Pen from the Penstation 2-19
1	Removing Sealing Unit from Penstation 4-3
Initial Setup	Required Equipment 4-1
Inlay	
Spacer Settings	S
Installation 1-10	Sealing Unit, Removing, Inserting, Adjusting 4-3
Installing a Pen in the Pen Station 2-19	Setup2-1
	Software
L	Stop/View Button
Location Recommendations 2-1	
М	<b>T</b> Technical Specifications
Maintanence, Plotter	Troubleshooting
Maintenance, Pen	TroubleshootingT-1
Manual Contents	
Marker Cards	

Index

Notes:

www.rockwellautomation.com	
Power, Control and Information Solutions Headquarters	
Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444  Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640  Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846	
Table 2 week real rationing level 11, Cole 1, Cyberpore 3, 100 Cyberpore Roda, 110ng Rong, 101 (0)2/200/ 4/00, Pax: (0)2/2000 1040	