S Couplers Series KK/KKH/KK13



Variations

Male	thread	type

Carries	Port size								
Series	M5	R1/8	R1/4	R3/8	R1/2	R3/4			
KK2	0	0							
KK3		0	0	0					
KK4		0	0	0	0				
KK6				0	0	0			

Female thread type

0	Port size							
Series	M5	Rc1/8	Rc1/4	Rc3/8	Rc1/2			
KK2	0							
KK3		0	0	0				
KK4			0	0				
KK6				0	0			

Nut fitting type (for fiber reinforced urethane hose)

0	Applicable hose I.D./O.D. mm								
Series	5/8	6/9	6.5/10	8/12	8.5/12.5	11/16			
KK3	0	0	0						
KK4	0	0	0	0	0				
KK6				0	0	0			

One-touch fitting type (Straight/Elbow/Bulkhead)

Carles	Applicable tubing O.D. mm								
Series	ø 3.2	ø 4	ø 6	ø 8	ø 10	ø 12	ø16		
KK2	0	0	0						
KK3		0	0	0	0				
KK4			0	0	0	0			
KK6						0	0		

	Port size						
Series	R1/8	R1/4	R3/8	R1/2			
KKH3	0	0	0				
KKH4	0	0	0	0			
Eomolo th	road turna						

Female thread type

0	Port size				
Series	Rc1/8	Rc1/4	Rc3/8		
ККНЗ	0	0	0		
KKH4		0	0		

Nut fitting type (for fiber reinforced urethane hose)

0	Applicable hose I.D./O.D. mm							
Series	5/8	6/9	6.5/10	8/12	8.5/12.5			
KKH3	0	0	0					
KKH4	0	0	0	0	0			

Male thread type

0		Port	size							
Series	R1/8	R1/4	R3/8	R1/2						
KK13	0	0	0	0						
Female thread type										
Carriaa		Port	size							
Series	Rc1/4	Rc3/8	Rc1/2	G1/4						
KK13	0	0	0	0						
Barb fittin	g type									
0	Applicable hose I.D.									
Series	1/4"	1/4"	3/8"	1/2"						
KK13	0	0	0	0						
Plug nut f	itting type	(for fiber r	einforced	urethane						
		<u>`</u>								

Corico	Applicable nose i.D./O.D. mm								
Series	5/8	6/9	6.5/10	8/12	8.5/12.5	11/16			
KK13	0	0	0	0	0	0			

Series	; KKA	Stain	ess steel	type	•••••	•••••		•••••	267 to 275
Male/Fema	ale thread	type							
Series	R·Rc1/8	R·Rc1/4	R·Rc3/8		size R·Rc3/4	R-Rc1	R.Rc1 1/4	R-Rc1 1/2	
KKA3	0	0	0						
KKA4		0	0	0					
KKA6			0	0	0				
KKA7				0	0	0			
KKA8					0	0	0		
KKA9						0	0	0	




Series KK3/4/6











Sleeve lock mechanism

Lock

Prevents accidents caused by unexpected separation.

Note) Except for M5 type (Series KK2).



Series **KK**

P	ug (P)		
	· /		
lale thread type	Body size	Port size	Part no.
	M5	M5 x 0.8	KK2P-M5M
	-	R 1/8 R 1/8	-01MS KK3P-01MS
	1/8	R 1/4	-02MS
		R 3/8	-03MS
		R 1/8	KK4P-01MS
	1/4	R 1/4	-02MS
-		R 3/8 R 1/2	-03MS -04MS
		R 3/8	KK6P-03MS
	1/2	R 1/2	-04MS
		R 3/4	-06MS
emale thread type	Pody oizo	Port oizo	Port no
	Body size M5	Port size M5 x 0.8	Part no. KK2P-M5F
		Rc 1/8	KK3P-01F
time in the	1/8	Rc 1/4	-02F
		Rc 3/8	-03F
	1/4	Rc 1/4 Rc 3/8	KK4P-02F -03F
		Rc 3/8	KK6P-03F
	1/2	Rc 1/2	-04F
ut fitting type (for fiber reinforced		e)	
	Body size	Applicable hose I.D./O.D. mm	Part no.
	1/8	5/8 6/9	KK3P-50N -60N
	1/0	6.5/10	-65N
		5/8	KK4P-50N
		6/9	-60N
	1/4	6.5/10 8/12	-65N -80N
		8.5/12.5	-85N
		8/12	KK6P-80N
	1/2	8.5/12.5	-85N
		11/16	-110N
traight type with One-touch fitting	-	Applicable	Deutine
	Body size	Applicable tubing O.D. mm 3.2	Part no. KK2P-23H
	M5	4	-04H
		6	-06H
-		4	KK3P-04H
	1/8	6	-06H -08H
		10	-10H
		6	KK4P-06H
	1/4	8	-08H
	., .	10	-10H -12H
		12	KK6P-12H
	1/2	16	-16H
bow type with One-touch fitting			
	Body size	Applicable tubing O.D. mm	Part no.
		3.2	KK2P-23L
	M5	4 6	-04L -06L
		4	KK3P-04L
	1/8	6	-06L
	1/0	8	-08L
		10 6	-10L KK4P-06L
		8	-08L
	1/4	10	-10L
		12	-12L
	1/2	12	KK6P-12L
Ikhood tupo with One touch fitti		16	-16L
Ikhead type with One-touch fitti	ng Body size	Applicable tubing O.D. mm	Part no.
	Douy Size	3.2	KK2P-23E
	M5	4	-04E
		6	-06E
		4	KK3P-04E
	1/8	6	-06E -08E
		10	-10E
		6	KK4P-06E
-	1/4	8	-08E
		10 12	-10E -12E
		12	KK6P-12E
	1/2		

Socket (S)

Male thread type



Body size	Port size	Part no.
M5	M5 x 0.8	KK2S-M5M
INIS	R 1/8	-01MS
	R 1/8	KK3S-01MS
1/8	R 1/4	-02MS
	R 3/8	-03MS
	R 1/8	KK4S-01MS
1/4	R 1/4	-02MS
1/4	R 3/8	-03MS
	R 1/2	-04MS
	R 3/8	KK6S-03MS
1/2	R 1/2	-04MS
	R 3/4	-06MS

Female thread type



	Body size	Port size	Part no.
	M5	M5 x 0.8	KK2S-M5F
		Rc 1/8	KK3S-01F
	1/8	Rc 1/4	-02F
		Rc 3/8	-03F
	1/4	Rc 1/4	KK4S-02F
1/4	Rc 3/8	-03F	
	1/0	Rc 3/8	KK6S-03F
	1/2	Do 1/2	_0/E

Nut fitting type (for fiber reinforced urethane hose) Body size Applicable hose Part no.

	_			
	IS IS	-		
IF	KKAS War		-	

1/8	5/8	KK3S-50N
	6/9	-60N
	6.5/10	-65N
	5/8	KK4S-50N
1/4	6/9	-60N
	6.5/10	-65N
	8/12	-80N
	8.5/12.5	-85N
	8/12	KK6S-80N
1/2	8.5/12.5	-85N
	11/16	-110N

Straight type with One-touch fitting



Body size	Applicable tubing O.D. mm	Part no.
	3.2	KK2S-23H
M5	4	-04H
	6	-06H
	4	KK3S-04H
1/8	6	-06H
	8	-08H
	10	-10H
	6	KK4S-06H
	8	-08H
1/4	10	-10H
	12	-12H
1/0	12	KK6S-12H
1/2	16	-16H

Elbow type with One-touch fitting



Body size	Applicable tubing O.D. mm	Part no.
	3.2	KK2S-23L
M5	4	-04L
	6	-06L
	4	KK3S-04L
1/8	6	-06L
1/8	8	-08L
	10	-10L
	6	KK4S-06L
1/4	8	-08L
1/4	10	-10L
	12	-12L
1/0	12	KK6S-12L
1/2	16	-16L

Bulkhead type with One-touch fitting




Body size	Applicable tubing O.D. mm	Part no.
	3.2	KK2S-23E
M5	4	-04E
	6	-06E
	4	KK3S-04E
1/8	6	-06E
	8	-08E
	10	-10E
	6	KK4S-06E
	8	-08E
1/4	10	-10E
	12	-12E
1/2	12	KK6S-12E
	16	-16E



S Couplers Series KK



Series KK3/4/6



Specifications

Specifications		K□
Fluid	Air, Water	M□
Operating Note) pressure range	KK2: –100 kPa to 1 MPa KK3: –90 kPa to 1 MPa	H□
	KK4/6: 0 to 1 MPa	KK
Proof pressure	1.5 MPa	
Ambient and	Air: −5 to 60°C Water: 5 to 40°C	D□
fluid temperature	(No freezing)	MS
Plating, Sealant	Electroless nickel plated (copper-free and fluorine-free application), With male thread sealant	MO
•	vith a leak tester or for vacuum retention because they are not guaranteed for	LQ

Performance

Plug and socket connection	One-touch connection and release
Check valve	Socket: Built-in check valve (standard)
Sleeve lock mechanism Note)	Manual locking type (standard)

Note) Series KK2 is not provided with lock mechanism.

Effective Area

Body size	Plug	Socket	Effective area mm ²
M5	KK2P-M5M	KK2S-M5M	3.8
1/8	KK3P-01MS	KK3S-01MS	20
1/4	KK4P-02MS	KK4S-02MS	39
1/2	KK6P-04MS	KK6S-04MS	82

How to Order

KK 4	S	- 02	Μ	S
De du ella				

Boay size •								
2	M5							
3	1/8							
4	1/4							
6	1/2							

Socket/Plug designation

-	
S	Socket
Ρ	Plug

• With sealant (male thread)

Connection type

Symbol	Туре
М	Male thread
F	Female thread
Ν	With nut fitting
Н	Straight with One-touch fitting
L	Elbow with One-touch fitting
E	Bulkhead with One-touch fitting

• Piping port size variation

Male/Fer	nale thread type	One-touch fitting type							
Symbol	Thread size	Symbol	Applicable tubing O.D. mm						
M5	M5 x 0.8	23	ø3.2						
01	R, Rc 1/8	04	ø4						
02	R, Rc 1/4	06	ø6						
03	R, Rc 3/8	08	ø8						
04	R, Rc 1/2	10	ø10						
06	R, Rc 3/4	12	ø12						
		16	ø16						

Nut fittin	Nut fitting type										
Symbol	Applicable hose I.D./O.D. mm										
50	5/8										
60	6/9										
65	6.5/10										
80	8/12										
85	8.5/12.5										
110	11/16										


MQR


Tロ

SMC

Series **KK**

Flow Characteristics





13

14

15

16

17

Sleeve spring

Cassette

Collar 2

Sleeve cover

Seal

Stainless steel 304

NBR


Stainless steel 304


Weather resistant NBR



Dimensions/Plug (P)

Male thread type






(mm)

(mm)


(mm)





Female thread type


	Body size	Model	T Connection port size	H Width across flats	L1	L2	Min. bore size	Effective area mm ²	Mass g	
	M5	KK2P-M5F	M5 x 0.8	8	17.6	12.3	3.4	8.1	2.6	т
		KK3P-01F	Rc 1/8	14	28.3	18.4			10.4	
	1/8	-02F	Rc 1/4	17	35.0	19.9	6.0	22.6	20.8	
		-03F	Rc 3/8	19	36.8	19.9			23.2	
	1/4	KK4P-02F	Rc 1/4	17	37.2	25.2	9.0	50.9	23.9	
	1/4	-03F	Rc 3/8	10	39.8	20.2	9.0	50.9	24.6	- н
	1/2	KK6P-03F	nt 3/0	19	43.3	21.0	13.0	106.2	28.6	-
	1/2	-04F	Rc 1/2	24	50.2	31.0	13.0	100.2	43.9	

Nut fitting type (for fiber reinforced urethane hose)









Straight type with One-touch fitting

-	-			
		P.Marrie	1	-
				_
				_
	_	(stans	~~	_

Model	tubing O.D.	ø D 1	Ø D 2	L1									
K2D-23H	O.D.		L2	М	bore size	Urethane tubing		g					
1121 -2011	ø3.2		7.0	227		107	2.5	3.7	4.4	3.3			
-04H	ø4	10.0	8.0	20.7	20.7	20.7	20.7	12.3	12.7	24	01	0.1	3.4
-06H	ø6		10.0	26.7		13.5	3.4	0.1	0.1	4.0			
K3P-04H	ø4	12.0	10.0	35 /		16.0	3.2	3.9	5.6	7.9			
-06H	ø6	14.0	12.0	55.4	101	17.0	4.7	10.1	12.8	9.1			
-08H	ø8	16.0	14.0	38.6	10.4	18.5	6.0	15.7	00 G	13.2			
-10H	ø10	19.0	17.0	39.7		21.0	6.0	22.6	22.0	17.6			
K4P-06H	ø6	14.0	12.0			17.0	4.7	10.1	12.8	22.3			
-08H	ø8	16.0	14.0	46.2	25.2	18.5	6.2	19.8	22.6	23.0			
-10H	ø10	19.0	17.0		20.2	21.0	7.7	27.6	35.3	27.1			
-12H	~10	01.0	10.0	47.5		00.0	9.0	40.2	50.0	30.0			
K6P-12H	012	21.0	19.0	56 1	31.0	22.0	9.2	41.2	50.9	44.4			
-16H ø16 26.0 23.8	23.8	50.1	31.0	25.0	13.0	_	106.2	50.7					
	-06H (3P-04H -06H -08H -10H (4P-06H -08H -10H -12H (6P-12H	-04H Ø4 -06H Ø6 Ø4 -06H Ø6 -08H Ø8 -10H Ø10 -08H Ø8 -10H Ø10 -10H Ø10 -12H Ø12	-04H Ø4 10.0 -06H Ø6 (3P-04H) Ø4 12.0 -06H Ø6 14.0 .00 .00 -06H Ø6 14.0 .00 .00 -08H Ø8 16.0 .00 .00 -08H Ø6 14.0 .00 .00 -08H Ø6 14.0 .00 .00 -10H Ø10 19.0 .00 .00 .00 -10H Ø10 .00	-04H Ø4 10.0 8.0 -06H Ø6 10.0 8.0 -06H Ø6 10.0 10.0 -06H Ø6 14.0 12.0 -06H Ø6 14.0 12.0 -08H Ø8 16.0 14.0 -10H Ø10 19.0 17.0 -08H Ø8 16.0 14.0 -10H Ø10 19.0 17.0 -10H Ø10 19.0 17.0 -10H Ø10 19.0 17.0 -10H Ø10 19.0 17.0 -12H Ø12 21.0 19.0	-04H Ø4 10.0 8.0 23.7 -06H Ø6 10.0 8.0 26.7 -06H Ø6 10.0 26.7 -06H Ø6 14.0 12.0 35.4 -06H Ø6 14.0 12.0 35.4 -08H Ø8 16.0 14.0 38.6 -10H Ø10 19.0 17.0 39.7 Ø6 14.0 12.0 46.2 -08H Ø8 16.0 14.0 46.2 -10H Ø10 19.0 17.0 47.5 21.0 19.0 56.1	-04H Ø4 10.0 8.0 23.7 12.3 -06H Ø6 10.0 26.7 12.3 -06H Ø6 10.0 26.7 12.3 -06H Ø6 14.0 12.0 35.4 18.4 -06H Ø6 14.0 12.0 35.4 18.4 -06H Ø6 14.0 12.0 39.7 18.4 -08H Ø8 16.0 14.0 39.7 25.2 -10H Ø10 19.0 17.0 39.7 25.2 -10H Ø10 19.0 17.0 39.7 25.2 -10H Ø10 19.0 17.0 47.5 25.2 -10H Ø12 21.0 19.0 56.1 31.0	$\begin{array}{c c c c c c c c c c c c c c c c c c c $	$\begin{array}{c c c c c c c c c c c c c c c c c c c $	$\begin{array}{c c c c c c c c c c c c c c c c c c c $	$\begin{array}{c c c c c c c c c c c c c c c c c c c $			

Applicable tubing Μ Ő ⁸D²



(mm)

Elbow type with One-touch fitting

	size
_	M5
	1/8
-	

Body				~ Do	L1	L2	L3	м	Min.	mi		Mass
size	Model	tubing O.D.	ø D 1	ø D 2	LI	L2	L3	IVI		Urethane tubing		g
	KK2P-23L	ø3.2		9.3	24.0		16.5	12.7	2.5	3.6	4.3	5.8
M5	-04L	ø4		9.3	24.0	12.3	10.5	12.7	2.5	3.0	4.3	0.0
	-06L	ø6	10.0	11.6	25.1		16.6	13.5	3.4	7.8	7.8	6.4
	KK3P-04L	ø4		10.4	31.6		18.0	16.0	3.0	3.7	5.3	7.2
1/0	-06L	ø6		12.8	32.8	18.4	20.0	17.0	4.5	10.1	11.4	8.0
1/8	-08L	ø8	12.0	15.2	34.0	10.4	23.0	18.5	6.0	15.0	16.8	9.7
	-10L	ø10	17.0	18.5	36.0		26.5	21.0		18.0	18.5	23.0
	KK4P-06L	ø6	14.0	12.8	40.2		20.0	17.0	4.5	10.1	11.4	19.6
	-08L	ø8	14.0	15.2	41.4	25.2	23.0	18.5	6.0	17.5	19.8	21.3
1/4	-10L	ø10	17.0	18.5	42.8		26.5	21.0	7.5	24.7	27.5	25.7
	-12L	010	17.0	20.9	44.0		28.5	22.0	9.0	29.0	29.6	28.0
1/2	KK6P-12L	ø12	19.0	20.9	49.9	31.0	20.5	22.0	9.0	38.1	39.7	40.3
	-16L	ø16	21.0	26.5	53.5		34.0	25.0	13.0	_	58.7	48.7
	-16L	ø16	21.0	26.5	53.5		34.0	25.0	13.0	_	58.7	48.7

Applicable tubing ØD2 e L ē 1 2

Effective area

Mass

g

6.0

6.6

9.7

22.3

30.2

54.7

30.6

38.2

61.4

75.2

86.1


5.6 16.6

106.2 125.0

Bulkhead type with One-touch fitting

<u> </u>			0											
	Body	Model	Applicable tubing		H1 Width	H2 Width	Lı	L2	L3	м	Min. bore	Effectiv mi		Ν
	size	Woder	O.D.	Threads	across flats	across flats		LZ	23		size	Urethane tubing	Nylon tubing	
		KK2P-23E	ø3.2	M8 x 0.75	10	10	28.3		12.5	12.7	2.5	3.7	4.4	
	M5	-04E	ø4	M9 x 0.75		11	20.3	12.3	12.5	12.7	24		0.1	
		-06E	ø6	M11 x 0.75	14	14	28.6		12.7	13.5	3.4	8.1	8.1	Γ
	1/8	KK3P-04E	ø4	M12 x 1	14	14	39.3		16.9	16.0	3.2	3.9	5.6	
		-06E	ø6	M14 x 1	17	17	40.2	18.4	16.8	17.0	4.7	10.1	12.8	
		-08E	ø8	M16 x 1		19	43.4		20.0	18.5	6.0	15.7	00.0	
		-10E	ø10	M20 x 1	22	24	46.4		22.0	21.0	6.0	22.6	22.6	
		KK4P-06E	ø6	M14 x 1	17	17	47.0		16.8	17.0	4.7	10.1	12.8	
	1/4	-08E	ø8	M16 x 1		19	50.2	25.2	20.0	18.5	6.2	19.8	22.6	Γ
	1/4	-10E	ø10	M20 x 1	22	24	53.2	20.2	22.0	21.0	7.7	27.6	35.3	
		-12E	~10	M22 x 1	24	27	54.2		00.0	00.0	9.0	40.2	50.0	Γ
	1/2	KK6P-12E	ø12		24	21	60.1	31.0	23.0	22.0	9.2	41.2	50.9	
	1/2	-16E	ø16	M28 x 1.5	30	32	62.6	51.0	24.5	25.0	13.0	_	106.2	








Series **KK**


Dimensions/Socket (S)

Male thread type

КК2	Body size	Model	T Connection port size	H Width across flats	øD	L1	L2 When connected	A 1*	A2* When connected	DOLE	Effective area mm ²	Mass g
		KK2S-M5M	M5 x 0.8	8	10.0	24.7	26.2	21.7	23.7	2.5	3.8	6.1
	M5	-01MS	R 1/8	10	10.0	24.4	25.9	21.7	22.8	4.7	5.8	9.1
		KK3S-01MS	R 1/8	14		36.6	39.1	33.5	36.0	6.0	20.4	20.1
	1/8	-02MS	R 1/4	14	20.2	37.0 3	39.5	31.5	34.0	9.0	21.1	19.2
		-03MS	R 3/8	17		37.6	40.1	32.2	34.5	9.0	21.1	29.0
KK3/4/6		KK4S-01MS	R 1/8		28.0	49.5	53.2	46.4	50.1	6.0	22.9	47.5
		-02MS	R 1/4	19		50.5	54.2	45.0	48.7	9.0	38.9	44.1
CICK4S Microsoft	1/4	-03MS	R 3/8		20.0	48.9	52.6	43.5	47.2	11.0	40.4	50.9
		-04MS	R 1/2	22		48.8	52.5	41.7	45.4	13.0	42.7	61.2
		KK6S-03MS	R 3/8	24		59.1	64.4	53.7	59.0	11.0	71.7	87.9
	1/2	-04MS	R 1/2	24	31.6	59.3	64.6	52.2	57.5	13.0	82.3	90.1
		-06MS	R 3/4			60.2	65.5	50.7	56.0	15.0	83.8	113.3
						* Ref	erence d	imensio	n for R t	hreads a	after inst	allation.









Female thread type

KK2	Body size	Model	T Connection port size	H Width across flats	øD	L1	L2 When connected	Min. bore size	Effective area mm ²	Mass g
pertain sector	M5	KK2S-M5F	M5 x 0.8	8	10.0	25.3	26.8	4.2	5.4	6.4
		KK3S-01F	Rc 1/8	14		36.0	38.5		20.6	23.6
	1/8	-02F	Rc 1/4	17	20.2	40.1	42.6	8.2	21.1	34.4
KK3/4/6		-03F	Rc 3/8			41.9	44.4		21.1	38.8
	1/4	KK4S-02F	Rc 1/4	19	28.0	50.4	54.1	10.9	39.6	56.9
eds and a second	1/4	-03F	Rc 3/8		20.0	51.1	54.8	444	42.7	46.2
KO KO	1/2	KK6S-03F	nc 3/0	24	31.6	58.6	63.9	14.4	83.1	93.6
	1/2	-04F	Rc 1/2	24	51.0	61.0	66.3	18.0	83.8	87.4







Nut fitting type (for fiber reinforced urethane hose)







Straight type with One-touch fitting

	Body size		Applicable				L2		Min.	Effecti m	ve area m²	Mass	КК2
	size	Model	tubing O.D.	ø D 1	ø D 2	L1	When connected	М	bore size	Urethane tubing	Nylon tubing	g	Applicable tubing
KK2		KK2S-23H	ø3.2		7.0	33.8	35.3	12.7	2.5	3.8	4.6	6.4	
	M5	-04H	ø4	10.0	8.0	33.6	35.1	12.7	3.4	4.0	4.8	6.5	ē
		-06H	ø6		10.0	33.9	35.4	13.5	4.7	5.8	5.8	7.9	
		KK3S-04H	ø4		10.0	46.6	49.1	16.0	3.2	3.8	5.8	22.5	
	1/8	-06H	ø6	ø6 20.2	12.0	47.1	49.6	17.0	4.7	10.4	13.4	24.4	
KK3/4/6	1/0	-08H	ø8	20.2	14.0	48.9	51.4	18.5	6.2	16.8	18.9	27.3	
		-10H	ø10		17.0	49.9	52.4	21.0	7.7	19.1	19.1	37.1	KK3/4/6
		KK4S-06H	ø6		12.0	58.2	61.9	17.0	4.7	10.4	13.4	51.4	Applicable tubing
	1/4	-08H	ø8	28.0	14.0	60.1	63.8	18.5	6.2	18.3	21.8	51.3	
	1/4	-10H	ø10	20.0	17.0	61.5	65.2	21.0	7.7	27.0	29.4	54.8	ő +
		-12H	ø12		10.0	62.5	66.2	22.0	9.2	30.5	32.0	59.4	
	1/2	KK6S-12H	210	31.6	19.0	70.1	75.4	22.0	5.2	42.7	48.8	84.1	
	1/2	-16H	ø16	51.0	25.7	72.3	77.6	25.0	13.2	53.4	62.5	99.9	L2




KK2S-23L Ø3.2 9.3 26.0 27.5 16.5 12.7 2.5 3.7 4.4 6.7	KK2
M5 -04L Ø4 10.0 9.3 26.0 27.5 16.5 12.7 2.5 3.7 4.4 6.7	; † - [
M5 -04L Ø4 10.0 00 200 0 00 00 00 00 00 00 00 00 00 00	
	¶
-06L Ø6 11.6 27.2 28.3 16.6 13.5 4.5 5.6 5.6 7.2	
KK3S-04L ø4 10.4 41.7 44.2 18.0 16.0 3.0 3.7 5.3 23.2	1
1/8 -06L Ø6 20.2 12.8 42.9 45.4 20.0 17.0 4.5 10.1 11.4 24.0	-
-08L Ø8 25.2 15.2 43.1 45.6 23.0 18.5 6.0 15.0 16.8 25.0	
KK3/4/6 -10L Ø10 18.5 42.9 45.4 26.5 21.0 7.5 18.0 18.5 34.4	ккз
KK4S-06L Ø6 12.8 54.3 58.0 20.0 17.0 4.5 10.1 11.4 53.5	
1/4 -08L Ø8 28.0 15.2 55.5 59.2 23.0 18.5 6.0 17.5 19.8 53.1 4	Applica
-10L Ø10 ^{20.0} 18.5 54.2 57.9 26.5 21.0 7.5 24.7 27.5 54.7	<u>ا ا</u>
-12L Ø12 20.9 55.4 59.1 28.5 22.0 9.0 29.6 57.0 57.0 57.0 57.0 57.0 57.0 57.0 57.0	
1/2 KK6S-12L 31.6 66.3 71.6 28.3 22.0 13.0 38.1 39.7 91.4	»
-16L Ø16 31.6 26.5 66.9 72.2 34.0 25.0 50.3 58.7 93.5	-





Bulkhead type with One-touch fitting

	Body size	Model	Applicable tubing O.D.	Threads	H1 Width across flats	H2 Width across flats	øD	L1	L2 When conne- cted	L3	м	Min. bore size	Effectiv mi Urethane tubing	m² Nyrlon	Mass g	KK2 Applicable tubing Mounting plate H2 thickness 7 mm or less
KK2		KK2S-23E	ø3.2	M8 x 0.75	10	10		33.8	35.3	13.0	12.7	2.5	3.8	4.6	9.6	
	M5	-04E	ø4	M9 x 0.75	10	11	10.0	33.5	35.0	10.0	12.1	3.4	4.0	4.8	9.1	
		-06E	ø6	M11 x 0.75	x 0.75 14 1	14		33.9	35.4	13.1	13.5	4.7	5.8	5.8	12.6	
		KK3S-04E	ø4	M12 x 1	14	14		46.6	49.1	16.9	16.0	3.2	3.8	5.8	29.0	
	1/8	-06E	ø6	M14 x 1	17	17	00.0	47.1	49.6	16.8	17.0	4.7	10.4	13.4	39.4	
	1/0	-08E	ø8	98 M16 x 1	l 17 19 ²	20.2	49.0	51.5	20.0	18.5	6.2	16.8	18.9	43.4	$- L_1 \rightarrow L_2$	
KK3/4/6		-10E	ø10	M20 x 1	x1 22 24	24		49.9	52.4	22.0	21.0	7.7	19.1	19.1	68.3	
		KK4S-06E	ø6	M14 x 1	19	17		58.2	61.9	16.8	17.0	4.7	10.4	13.4	57.2	KK3/4/6 Applicable tubing
	1/4	-08E	ø8	M16 x 1	19	19	00.0	60.1	63.8	20.0	18.5	6.2	18.3	21.8	60.6	Mounting plate
	1/4	-10E	ø10	M20 x 1	1 22	24	28.0	61.7	65.4	22.0	21.0	7.7	27.0	29.4	86.8	thickness 7 mm or less
		-12E	ø12	M00 v 1	24	07		62.7	66.4	23.0	22.0		30.5	32.0	105.7	
	1/2	KK6S-12E	012	M22 x 1	24	27	01.0	70.1	75.4	24.5	25.0	9.2	42.7	48.8	116.0	
	1/2	-16E	ø16	M28 x 1.5	30	32	31.6	72.5	77.8	24.3	23.0	13.2	53.4	62.5	183.2	
																<u> </u>



(mm)

(mm)

K□

Mロ

Η□

KK

D

MS


LQ

MQR

Tロ

(mm)

øD2








S Couplers

Series KKH

Able to absorb drop impact

(equivalent to impact energy of 0.5 J).

• The pulling strength for the plugs and sockets has been improved. Twice as strong as the conventional models.



Sleeve cover (Rubber)

Plug (P)

Male thread type

Body size	Connection port size	Part no.
	R 1/8	KK3P-01MS
1/8	R 1/4	-02MS
	R 3/8	-03MS
	R 1/8	KK4P-01MS
1/4	R 1/4	-02MS
1/4	R 3/8	-03MS
	R 1/2	-04MS

Female thread type

Body size	Connection port size	Part no.
	Rc 1/8	KK3P-01F
1/8	Rc 1/4	-02F
	Rc 3/8	-03F
4/4	Rc 1/4	KK4P-02F
1/4	Rc 3/8	-03F

Nut fitting type (for fiber reinforced urethane hose)

Body size	Applicable hose I.D./O.D. mm	Part no.
	5/8	KK3P-50N
1/8	6/9	-60N
	6.5/10	-65N
	5/8	KK4P-50N
	6/9	-60N
1/4	6.5/10	-65N
	8/12	-80N
	8.5/12.5	-85N

Series KKH are only available as sockets. Series KK should be used as plugs.

Same effective sectional area as that of Series KK.

Socket (S) Male thread type

wale thread ty	pe		
	Body size	Connection port size	Part no.
		R 1/8	KKH3S-01MS
	1/8	R 1/4	-02MS
		R 3/8	-03MS
		R 1/8	KKH4S-01MS
	1/4	R 1/4	-02MS
	1/4	R 3/8	-03MS
		R 1/2	-04MS

Female thread type

	Body size	Connection port size	Part no.
		Rc 1/8	KKH3S-01F
CARE -	1/8	Rc 1/4	-02F
		Rc 3/8	-03F
	4/4	Rc 1/4	KKH4S-02F
	1/4	Rc 3/8	-03F

Nut fitting type (for fiber reinforced urethane hose)

	Body size	Applicable hose I.D./O.D. mm	Part no.
		5/8	KKH3S-50N
_	1/8	6/9	-60N
		6.5/10	-65N
		5/8	KKH4S-50N
		6/9	-60N
	1/4	6.5/10	-65N
		8/12	-80N
		8.5/12.5	-85N

S Couplers Series KKH

Specifications



JIS Symbol

Single plug	Single socket
Connected plu	ig and socket

Fluid	Air, Water
Operating Note) pressure range	KKH3: –90 kPa to 1 MPa KKH4: 0 to 1 MPa
Proof pressure	1.5 MPa
Ambient and fluid temperature	Air: -5 to 60°C Water: 5 to 40°C (No freezing)
Plating, Sealant	Electroless nickel plated (copper-free and fluorine-free application), With male thread sealar
Connection plug	Series KK plug

Note) Do not use the S couplers with a leak tester or for vacuum retention because they are not guaranteed for zero leakage.

Performance

Plug and socket connection	One-touch connection and release
Check valve	Socket: Built-in check valve (standard)
Sleeve lock mechanism	

Effective Area

Body size	Plug	Socket	Effective area mm ²
1/8	KK3P-01MS	KKH3S-01MS	20
1/4	KK4P-02MS	KKH4S-02MS	39

The flow characteristics are the same as those of Series KK. Please refer to page 168.

How to Order

KKH 4 <u>S-02 M S</u>

Body size

Socket/Plug designation

1/4

3 4 With sealant (male thread)

Connection type

Туре
Male thread
Female thread
With nut fitting

• Piping port size variation

Male/Fe	emale thread type	Nut fitti	ng type
Symbol	Connection port size	Symbol	Hose I.D./O.D. mm
01	R, Rc 1/8	50	5/8
02	R, Rc 1/4	60	6/9
03	R, Rc 3/8	65	6.5/10
04	R, Rc 1/2	80	8/12

85

8.5/12.5

K
M□
H□
KK
D
MS
LQ
MQR
T□


Series KKH

Dimensions/Socket (S)

Male thread type



Body size	Model	T Connection port size	H Width across flats	øD	L1	L2 When connected	A 1*	A2* When connected	Min. bore size	Effective area mm ²	Mass g
	KKH3S-01MS	R 1/8	14	20.2	36.6	39.1	33.5	36.0	6.0	20.4	20.3
1/8	-02MS	R 1/4	14		37.0	39.5	31.5	34.0	9.0	21.1	19.4
	-03MS	R 3/8	17		37.6	40.1	32.2	34.5	9.0		27.7
	KKH4S-01MS	R 1/8			49.5	53.2	46.4	50.1	6.0	22.9	48.7
1/4	-02MS	R 1/4	19	28.0	50.5	54.2	45.0	48.7	9.0	38.9	45.3
1/4	-03MS	R 3/8		28.0	48.9	52.6	43.5	47.2	11.0	40.4	52.1
	-04MS	R 1/2	22		48.8	52.5	41.7	45.4	13.0	42.7	62.4




* Reference dimension for R threads after installation.

Female thread type



be									(mm)
Body size		T Connection port size		øD	Lı	L2 When connected	Min. bore size	Effective area mm ²	Mass g
	KKH3S-01F	Rc 1/8	14		36.0	38.5		20.6	23.8
1/8	-02F	Rc 1/4	17	20.2	40.1	42.4	8.2	21.1	33.1
	-03F	Rc 3/8	19		41.9	44.3			37.1
1/4	KKH4S-02F	Rc 1/4	19	28.0	50.4	54.1	10.9	39.6	58.1
1/4	-03F	Rc 3/8	19	20.0	51.1	54.8	14.4	42.7	47.4



Nut fitting type (for fiber reinforced urethane hose)

Nut fitting type (for fiber reinforced urethane hose) (mm))			
	Body size	Model	Applicable hose I.D./O.D.	Width	H2 Width across flats	øD	L1	L2 When connected	М	Min. bore size	Effective area mm ²	Mass g	Applicable hose
	1/8	KKH3S-50N	5/8	14	14		42.6	45.1	13.7	4.5	12.2	32.3	
		-60N	6/9	17	17	, 20.2	20.2 44.4	46.9	16.5	5.4	18.3	48.9	
		-65N	6.5/10	17	17					5.9	19.2	46.6	
	1/4	KKH4S-50N	5/8		14		54.1	57.8	13.7	4.5	12.2	57.0	
		-60N	6/9		17		50.0	56.8 60.5	60.5 16.5	5.4	20.4	70.5	
		-65N	6.5/10	19	17	28.0	0.00			5.9	24.1	68.0	
		-80N	8/12		10	19	55.4	50.4	47.4	7.4	35.1	69.7	
		-85N	8.5/12.5		19			59.1	17.4	7.8	36.6	72.3	

Series KKH are only available as sockets. Series KK should be used as plugs. For dimensions, please refer to page 170.



Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 13 to 16 for Fittings and Tubing Precautions.

Selection

Warning

- Make sure to confirm the specifications. Please do not use with pressures or temperatures outside the range of specifications, as this may result in damage and malfunction (Refer to specifications). SMC takes no responsibility for damage incurred by use in excess of the specification range.
- 2. Prohibition of disassembly and modification Do not disassemble or modify (including additional machining) the main body.
- False use may cause an injury or accident.
- 3. Confirm that PTFE can be used in application. Thread sealant contains PTFE (polytetrafluoroethylene) powder. Confirm if the use of it may cause any adverse effect in the system.
- 4. Cannot be used as a stop valve that requires zero leakage. A certain amount of leakage is allowed during operation.
- Series KK and Series KKH cannot be connected with Series KKA. Also, SMC's S coupler cannot be connected with quick couplers of other brands. This will cause leakage, damage, and disconnection of the plug.
 With series KK13, manufactured by BECTUS AG, verify

With series KK13, manufactured by RECTUS AG, verify the manufacturer of applicable couplers before use.

- 6. Do not couple or uncouple the S coupler during pressurization or while residual pressure remains. The coupler may shoot out under the influence of the pressure.
- 7. Never apply pressure to an S coupler without check valve when it is uncoupled. The piping may move violently and cause danger.
- 8. An S coupler without check valve experiences leakage of fluid inside piping when it is uncoupled. Pay special attention in using fluid that can cause danger such as fluid of a high temperature and pressure. Additional use of a stop valve is recommended.
- 9. The S coupler is heated when used at a high temperature. Take precautions not to touch it since touching it can cause burns.

A Caution

- 1. For a plug and socket connection, select a plug and socket with the same body size. If their body sizes are different, they cannot be connected. This will cause leakage, damage, and disconnection of the plug. Inserting a plug other than the specialized plug into the socket may result in equipment damage.
- 2. Do not use in locations where the connecting threads and tubing connection will slide or rotate. The connecting threads and tubing connection will come apart under these conditions.
- 3. Do not use couplers with flammable, explosive, or toxic substances, such as gas, gas fuel, and refrigerant. They may leak from inside the tubing to the outside.
- 4. Operate with a surge pressure of no more than the maximum operating pressure. If the surge pressure exceeds the maximum operating pressure, it will cause damage to couplers and tubing.
- 5. Do not use the S coupler with steam. Corrosion of the metal material and deterioration of the sealing material may result from long-term use with steam.

Mounting

- A Warning
- 1. Mount and operate the product after reading the instruction manual carefully and understanding its contents. Also, keep the manual where it can be referred to as necessary.
- 2. Ensure sufficient space for maintenance. Be sure to allow the space required for maintenance and inspection.
- 3. Tightening torque When installing the products, please tighten the screw with the recommended tightening torque.
- During use, tube deterioration or damage to fitting can result in disconnection of the tube from the fitting and uncontrollable behavior of the tube. To stop the tube from going out of control, use a protective cover or fix the tube in place.
- 5. Do not use couplers where rotation normally occurs. The couplers may be damaged.
- 6. Avoid applications in which vibration or shock is directly applied to the fittings.
- 7. Fittings with sleeve lock mechanism must be locked during operation in order to prevent sudden disconnection.
- 8. Install a stop valve at the supply pressure side of the socket. Emergency shutdown may not be possible without it.

A Caution

- 1. Preparation before piping Before piping is connected, it should be thoroughly blown out by air (flushed) or washed to eliminate cutting chips, cutting oil, and other debris from inside the pipe.
- 2. Wrapping of pipe tape When screwing in the pipes or fittings, make sure to prevent cutting chips or the sealing material on the threaded portion of the pipe from entering the piping. Also, if pipe tape is used, leave about 1 thread ridges exposed at the end of the threads.



- 3. Before mounting confirm the model and size, etc. Also, confirm that there are no blemishes, nicks or cracks in the product.
- 4. When connecting a tube, consider factors such as changes in the tubing length due to pressure, and allow sufficient leeway.
- 5. Mount so that couplers and tubing are not subjected to twisting, pulling or moment loads. This can cause damage to couplers and flattening, bursting or disconnection of tubing, etc.
- 6. Mount so that tubing is not damaged due to tangling and abrasion. This can cause flattening, bursting or disconnection of tubing, etc.



Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 13 to 16 for Fittings and Tubing Precautions.

Air Supply

Warning

1. Excessive drainage

Compressed air containing large amounts of drainage can cause malfunction of pneumatic equipment. As a countermeasure, install an air dryer or drain catch before the filter.

2. Drain flushing

If the drain removal from air filter is missed, drain will be flown out to the outlet side and may result in a malfunction of the pneumatic equipment. When removing drain is difficult, use of a filter with an auto drain is recommended.

Refer to SMC's "Air Cleaning Equipment" catalog for further details on compressed air quality.

3. Use clean air.

If the compressed air includes chemicals, synthetic oils containing organic solvents, salt or corrosive gases, etc., it can cause damage or malfunctions in the system.

A Caution

Install an air filter.
 Install an air filter upstream, near the valve.
 Select an air filter with a filtration degree of 5 μm or finer.

- 2. Compressed air containing large amounts of drainage can cause malfunction of pneumatic equipment. As a countermeasure, install an aftercooler, air dryer or drain catch.
- 3. Ensure that the fluid and ambient temperature are within the specified range.

If the fluid temperature is 5°C or below, the moisture in the circuit could freeze, causing damage to the seals and leading to equipment malfunction. Therefore, take appropriate measures to prevent freezing.

Refer to SMC's "Air Cleaning Equipment" catalog for further details on compressed air quality.

Operating Environment

Warning

- 1. Do not use in atmospheres of corrosive gases, chemicals, salt water, water, steam, or where there is direct contact with any of these.
- 2. Do not use in direct sunlight.
- 3. In locations near heat sources, protect against radiated heat.
- 4. Do not use in locations where static electric charges will be a problem. Consult with SMC regarding use in this kind of environment.
- 5. Do not use in locations where spatter occurs. There is a danger of spatter causing a fire. Consult with SMC regarding use in this kind of environment.

Operating Environment

Warning

- 6. Do not use in environments where there is direct contact with liquids such as cutting oil, lubricating oil or coolant oil, etc. Consult SMC regarding use in environments where there will be direct contact with cutting oil, lubricating oil or coolant oil, etc.
- 7. Do not use in locations influenced by vibrations or impacts. This may cause air leakage and fitting damage. Consult SMC regarding use in this kind of environment.
- 8. Do not use in places or environments where foreign matter sticks to the product or gets inside the product. It may cause air leakage or tube release.

Maintenance

- 1. Follow the procedures given in the operation manual to perform a maintenance inspection. Improper handling could lead to malfunction or damage the machinery and equipment.
- 2. Maintenance work

If handled improperly, compressed air can be dangerous. Assembly, handling, repair and element replacement of pneumatic systems should be performed by qualified personnel only.

3. Drain flushing

Remove drainage from air filters regularly.

4. Removal of equipment, and supply/exhaust of compressed air

When components are removed, first confirm that measures are in place to prevent workpieces from dropping, run-away equipment, etc. Then, cut the supply pressure and power, and exhaust all compressed air from the system using the residual pressure release function.

When machinery is restarted, proceed with caution after confirming that appropriate measures are in place to prevent cylinders from sudden movement.

- 5. Be absolutely sure to wear safety glasses when conducting periodic inspections.
- 6. Check for the following during regular maintenance, and replace components as necessary.
 - a) Scratches, gouges, abrasion, corrosion
 - b) Leakage
 - c) Twisting, flattening or distortion of tubing
 - d) Hardening, deterioration or softness of tubing
- 7. Do not repair or patch the replaced tubing or couplers for reuse.

Do not disassemble the S coupler.

K

M



Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 13 to 16 for Fittings and Tubing Precautions.

Handling


A Caution

- 1. When connecting the plug, hold the plug securely. The plug may be uncoupled due to reaction at the time of connection.
- 2. When connecting a plug, insert it securely until a click sound is heard from the socket. After the connection, gently pull the plug to see whether it will release. If not securely inserted, the plug may pop out due to the pressure. Also, do not touch the sleeve until the plug is securely inserted.


Otherwise, it may lead to a malfunction.

- 3. When connecting the plug, insert it straight into the socket. If not inserted straight, the socket and/or plug may be damaged or cause a malfunction.
- 4. When releasing the plug, hold it securely. The connection pipe may move due to reacting stress and/or residual pressure on the plug side.
- 5. Do not press the inside of the socket with an incompatible plug and/or with a stick. The internal fluid may be ejected and cause a dangerous situation. Also, the ejecting internal fluid may cause the sealings to come apart resulting in the product not functioning.

Plug Insertion Force in Pressurized Condition



Insertion Force of Series KKA



Handling of One-touch Fittings

A Caution

- 1. Tube attachment/detachment for One-touch fittings
 - 1) Attaching of tubing
 - (1) Take a tube having no flaws on its periphery and cut it off at a right angle. When cutting the tubing, use tubing cutters TK-1, 2 or 3. Do not use pinchers, nippers or scissors, etc. If cutting is done with tools other than tubing cutters, the tubing may be cut diagonally or become flattened, etc. This can make a secure installation impossible, and cause problems such as the tubing pulling out after installation or air leakage. Allow some extra length in the tubing.
 - (2) Outside diameter of polyurethane tubing is swelled by applying internal pressure. As such, it may be that the tubing cannot be re-inserted into a onetouch fittings. Make sure to confirm the tubing outside diameter, and when the accuracy of the outside diameter is more than + 0.15, insert into a one-touch fitting again, not cutting the tubing to use it. When tubing is re-inserted into a one-touch fitting, make sure to confirm that the tubing was able to go through the release bushing smoothly.
 - (3) Grasp the tubing and push it in slowly, inserting it securely all the way into the fitting.
 - (4) After inserting the tubing, pull on it lightly to confirm that it will not come out. If it is not installed securely all the way into the fitting, this can cause problems such as air leakage or the tubing pulling out.
 - (5) When attaching tubes, resin plugs, metal rods, etc., do not push the release button while attaching.

Also, do not push the release button before attaching. This may cause releasing.

- 2) Detaching of tubing
 - (1) Push in the release bushing sufficiently. When doing this, push the collar evenly.
 - (2) Pull out the tubing while holding down the release bushing so that it does not come out. If the release bushing is not pressed down sufficiently, there will be increased bite on the tubing and it will become more difficult to pull it out.
 - (3) When the removed tubing is to be used again, cut off the portion which has been chewed before reusing it. If the chewed portion of the tubing is used as is, this can cause trouble such as air leakage or difficulty in removing the tubing.
- 3) When attaching resin plugs or metal rods to the tube, do not push the release button while attaching. This may cause releasing.
- 4) Connecting products with attached metal rods
 - (1) After attaching products with attached metal rods such as the KC series, to the one-touch fitting, please do not use tubes, resin plugs, or reducers, etc. This may cause releasing.



Unit[.] mm

Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 13 to 16 for Fittings and Tubing Precautions.

Recommended piping conditions

 When installing piping in the one-touch fitting, please make sure there is sufficient slack to the tube length as per the recommended piping conditions shown in Figure 1. Also, when binding pipes together with a unifying band, etc., make sure piping is carried out without receiving external force (See Fig. 2).




Fig. 1 Recommended piping

				Onit. mini		
Tubing size	1	Mounting pitch A				
Tubing size	Nylon tube	Soft nylon tube	Polyurethane tube	Straight section		
ø3.2, 1/8"	44 or more	29 or more	25 or more	16 or more		
ø4, 5/32"	56 or more	30 or more	26 or more	20 or more		
ø3/16"	67 or more	38 or more	38 or more	24 or more		
ø6	84 or more	39 or more	39 or more	30 or more		
ø1/4"	89 or more	56 or more	57 or more	32 or more		
ø8, 5/16"	112 or more	58 or more	52 or more	40 or more		
ø10	140 or more	70 or more	69 or more	50 or more		
ø3/8"	134 or more	76 or more	69 or more	48 or more		
ø12	168 or more	82 or more	88 or more	60 or more		
ø1/2"	178 or more	118 or more	93 or more	64 or more		
ø16	224 or more	144 or more	114 or more	80 or more		




Fig. 2 When using a unifying band to bind together the pipes

Handling of Barb Fittings and Nut Fittings

A Caution

- 1. When using a nut fitting, insert the hose all the way to the end and securely tighten it with the nut. When the insertion of the hose or the tightening of the nut are not sufficient, the hose may slip out.
- 2. Disconnection may occur depending on the material or the O.D. accuracy of the hose; therefore be sure to confirm the applicability of the hose.

Handling of Fittings

A Caution

- 1. Tightening of the M5-size connection threads
 - 1) Tighten it by hand, then give it an additional 1/6 turn with a wrench. As a guideline, the tightening torque should be 1 to 1.5 N·m.
 - 2) Over tightening can cause damage to the threads and/or air leakage due to deformation of the gasket.
 - 3) Insufficient tightening can cause the threads to loosen and/or air to leak out.
- 2. Tightening of the fittings with a sealant
 - 1) Tighten fittings with sealant using the proper tightening torques in the table below. As a rule, they should be tightened 2 to 3 turns with a tool after first tightening by hand.

Proper tightening torque N·m		
7 to 9		
12 to 14		
22 to 24		
28 to 30		
28 to 30		
36 to 38		
40 to 42		
48 to 50		

- 2) When a fitting is over tightened, more of the sealant material is squeezed out. Remove the squeezed out sealant material.
- 3) When tightening is not sufficient, it will cause sealant failure or a loose fitting.
- 4) Re-using
 - (1) Normally, a fitting with sealant can be re-used 2 to 3 times.
 - (2) Remove the sealant material that is separated and adhering to a removed fitting with air blow, etc. If the separated sealant enters into nearby equipment, it will cause air leakage or malfunction.
 - (3) When the sealant is no longer effective, wrap sealant tape over the sealant material and re-use the fitting. Do not use a sealant material other than sealant tape.
- 5) In cases where positioning is required, turning the fitting in the reverse direction after tightening will cause air leakage.

Precautions on Other Tubing Brands

\land Caution

SMC

- 1. When using tubing brands other than SMC, confirm that the tubing outside diameter tolerances satisfy the following specifications.
 - 1) Nylon tubing within ±0.1 mm
 - 2) Soft nylon tubing within ±0.1 mm
 - 3) Polyurethane tubing within +0.15 mm

within -0.2 mm

When the tube O.D. accuracy is not satisfactory and measurement of the internal diameter dimensions does not match the dimensions provided by SMC, do not use. The tube may not connect, or leaks, tube disconnection, or damage to fittings may occur.



TΠ

K

M

185

S Couplers

Series KKA

Stainless steel type




Body material: Stainless steel 304 Seal material: Fluoro rubber (Special FKM)


Both plug and socket have an integral check valve. Available with and without check valves depending on the operating conditions.


Reduces liquid dripping when the plug and socket are uncoupled.

Liquid dripping: 0.02 to 0.77 cm³ at each removal Aeration: 0.1 to 2.7 cm³ at each removal



Socket valve





Non-greased specification (standard)

Allows smooth installation and removal even without grease

- O-ring: Fluorine coated
- Sliding parts of plug and socket: Plated with fluorine-contained material

Fluid: Water, Air

Operating temperature range: –5 to 150°C

Note) This product should not be used with steam.





Series KKA

Plug (P)

Male thread type

	size		With ch
		R 1/8	KKA3
	1/8	R 1/4	
		R 3/8	
		R 1/4	KKA4
	1/4	R 3/8	
N NA N NUMBER OF		R 1/2	
	1/2	R 3/8	KKA6
With check valve		R 1/2	
		R 3/4	
_		R 1/2	KKA7
	3/4	R 3/4	
A HERE COM COME IN		R 1	
		R 3/4	KKA8
Without check valve	1	R 1	
		D 4 4/4	

Body	Port size	Part	no.
size	Port size	With check valve	Without check valve
	R 1/8	KKA3P-01M	KKA3P-01M-1
1/8	R 1/4	-02M	-02M-1
	R 3/8	-03M	-03M-1
	R 1/4	KKA4P-02M	KKA4P-02M-1
1/4	R 3/8	-03M	-03M-1
	R 1/2	-04M	-04M-1
	R 3/8	KKA6P-03M	KKA6P-03M-1
1/2	R 1/2	-04M	-04M-1
	R 3/4	-06M	-06M-1
	R 1/2	KKA7P-04M	_
3/4	R 3/4	-06M	—
	R 1	-10M	_
	R 3/4	KKA8P-06M	_
1	R 1	-10M	_
	R 1 1/4	-12M	_
	R 1	KKA9P-10M	_
1 1/4	R 1 1/4	-12M	_
. 1/4	R 1 1/2	-14M	_

Female thread type


	-			
	Body	Port size	Part no.	
	size	size Wi	With check valve	Without check valve
		Rc 1/8	KKA3P-01F	KKA3P-01F-1
	1/8	Rc 1/4	-02F	-02F-1
		Rc 3/8	-03F	-03F-1
		Rc 1/4	KKA4P-02F	KKA4P-02F-1
	1/4	Rc 3/8	-03F	-03F-1
With check valve		Rc 1/2 -04F	-04F	-04F-1
		Rc 3/8	KKA6P-03F	KKA6P-03F-1
	1/2	1/2 Rc 1/2 -04F Rc 3/4 -06F	-04F	-04F-1
			-06F-1	
	3/4	Rc 1/2	KKA7P-04F	_
		Rc 3/4	-06F	_
		Rc 1	-10F	_
		Rc 3/4	KKA8P-06F	—
	1	Rc 1	-10F	_
Without check valve		Rc 1 1/4	-12F	_
		Rc 1	KKA9P-10F	_

1 1/4 Rc 1 1/4

Rc 1 1/2

Socket (S)

Male thread type



Female thread type

-12F -14F

, ,				
	Body	Port size	Part	t no.
	size	Port size	With check valve	Without check valve
		Rc 1/8	KKA3S-01F	KKA3S-01F-1
	1/8	Rc 1/4	-02F	-02F-1
		Rc 3/8	-03F	-03F-1
		Rc 1/4	KKA4S-02F	KKA4S-02F-1
	1/4	Rc 3/8	-03F	-03F-1
		Rc 1/2	-04F	-04F-1
		Rc 3/8	KKA6S-03F	KKA6S-03F-1
	1/2	Rc 1/2	-04F	-04F-1
		Rc 3/4	-06F	-06F-1
		Rc 1/2	KKA7S-04F	_
	3/4	Rc 3/4	-06F	—
		Rc 1	-10F	_
		Rc 3/4	KKA8S-06F	_
	1	Rc 1	-10F	_
		Rc 1 1/4	-12F	_
		Rc 1	KKA9S-10F	_
	1 1/4	Rc 1 1/4	-12F	_
		Rc 1 1/2	-14F	_

S Couplers Series KKA Stainless steel type

adificationa

S

K□

M

H

KK

MS

LQ

MQR

TΠ



JIS Symbol		
With check valve	Single plug	Single socket
Without check valve		
	Connected	plug and socket
Check valve on both sides:	O>	+<0
Check valve on single side:	\rightarrow	+ <0
No check valve on either side:	\rightarrow	+ <

Characteristics with check valve on both sides

Body size	Liquid dripping cm ³ at each removal	Aeration cm ³ at each removal
KKA3	0.02	0.1
KKA4	0.04	0.1
KKA6	0.06	0.2
KKA7	0.14	0.5
KKA8	0.27	0.9
KKA9	0.77	2.7

Liquid dripping:

Volume of water leakage at the time when the plug and socket are uncoupled.

Aeration:

Volume of external air entrained when the plug and socket are connected.

specifications	
Fluid	Water, Air
Operating Note 1) pressure range	KKA3: -100 kPa to 1 MPa KKA4/6/7/8/9: 0 to 1 MPa
Proof pressure	10 MPa
Ambient and fluid temperature	-5 to 150°C (No freezing) Note) This product should not be used with steam.
Non-greased specification	No grease is used. Rubber: Fluorine coated, (Metal sliding parts: Plated with fluorine-contained material)
Material	Metal part: Stainless steel 304, Rubber material: Fluoro rubber (Special FKM)
Seal	With male thread sealant

Note 1) Do not use the S couplers with a leak tester or for vacuum retention because they are not guaranteed for zero leakage. Note 2) When fluid contains copper ions, please use KKAD-X70. (p. 275)

Performance


Plug and socket connection	One-touch connection and release	
Check valve	Check valve on both sides, Without check valve	
Note) Series KKA connected with Series KK or Series KKH		

annot be connected with Series KK or Series KKH

Effective Area

Duilt in check uch a	Dlug	Cooket	
Built-in check valve	Plug	Socket	Effective area mm ²
	KKA3P-01F	KKA3S-01F	17.4
	KKA4P-02F	KKA4S-02F	26.4
Plug: With check valve	KKA6P-04F	KKA6S-04F	54.2
Socket: With check valve	KKA7P-06F	KKA7S-06F	99.6
	KKA8P-10F	KKA8S-10F	168.3
	KKA9P-12F	KKA9S-12F	332.1
	KKA3P-01M-1	KKA3S-01M	18.5
Plug: Without check valve Socket: With check valve	KKA4P-02M-1	KKA4S-02M	31.8
	KKA6P-04M-1	KKA6S-04M	55.3
Diver Without sheal walks	KKA3P-01M-1	KKA3S-01M-1	22.6
Plug: Without check valve Socket: Without check valve	KKA4P-02M-1	KKA4S-02M-1	40.2
	KKA6P-04M-1	KKA6S-04M-1	76.0

How to Order




with a socket with check valve. If a socket without check valve is used, the check

valve of the plug will not open.




Series KKA

Flow Characteristics




Pressure Loss

Water




SMC


Construction



Plug







Plug

No.	Description	Material	Note
1	Stem	Stainless steel 304	Plated with fluorine-contained material
2	Rear stem	Stainless steel 304	
3	Plug valve	Stainless steel 304	
4	Valve O-ring	Special FKM	Fluorine coated
5	Stem O-ring	Special FKM	Fluorine coated
6	Plug valve spring	Stainless steel 304	

Socket

No.	Description	Material	Note
1	Body	Stainless steel 304	Plated with fluorine-contained material
2	Rear body	Stainless steel 304	
3	Socket valve	Stainless steel 304	
4	Collar	Stainless steel 304	Plated with fluorine-contained material
5	Sleeve	Stainless steel 304	Plated with fluorine-contained material
6	Valve O-ring	Special FKM	Fluorine coated
7	Plug O-ring	Special FKM	Fluorine coated
8	Body O-ring	Special FKM	Fluorine coated
9	Collar seal	Special FKM	Fluorine coated
10	Collar spring	Stainless steel 304	
11	Sleeve spring	Stainless steel 304	
12	Steel ball	Stainless steel 304	
13	Stopper ring	Stainless steel 304	

Series KKA Spare Parts

Description	Product no.	No.
Plug O-ring	KKA3S-P01	
	KKA4S-P01	
	KKA6S-P01	Socket (7)
	KKA7S-P01	SOCKEL
	KKA8S-P01	
	KKA9S-P01	


Series KKA

Dimensions/Plug (P)

With check valve

Male thread type


Body size	Model	T Connection port size	H Width across flats	L1	L2	A	Min. bore size	Effective area mm ²	Mass g
	KKA3P-01M	R 1/8	14	35.4		31.4			15.4
1/8	-02M	R 1/4	14	38.4	16.0	32.4	5.6	area	19.8
	-03M	R 3/8		39.4		32.9			32.9
	KKA4P-02M	R 1/4	17	42.2		36.2			28.3
1/4	-03M	R 3/8		43.2	18.9	36.7	6.9	26.4	36.6
	-04M	R 1/2	22	46.2		38.2		area mm² 17.4 26.4 54.2 99.6 168.3 264.9	65.9
	KKA6P-03M	R 3/8	24	47.1		40.6			60.3
1/2	-04M	R 1/2	24	47.9	20.4	39.9	10.0	0 54.2	69.2
	-06M	R 3/4	30	49.9		40.4			119.0
	KKA7P-04M	R 1/2	32	66.3		58.1			173.9
3/4	-06M	R 3/4	52	69.4	27.6	59.9	13.5	99.6	209.6
	-10M	R 1	36	69.9		59.5	1		275.0
	KKA8P-06M	R 3/4	41	82.9		73.4			362.8
1	-10M	R 1	41	85.4	35.6	75.0	17.5	168.3	403.9
	-12M	R 1 1/4	46	85.4		72.7			538.6
	KKA9P-10M	R 1		109.5		99.1	22.0	264.9	824.1
1 1/4	-12M	R 1 1/4	55	109.0	49.1	96.3	24.6	000.1	861.4
	-14M	R 1 1/2		109.0		96.3	24.0	332.1	936.3



Female thread type



Body size	Model	T Connection port size	H Width across flats	L1	L2	Min. bore size	Effective area mm ²	Mass g
	KKA3P-01F	Rc 1/8	14	36.0				20.2
1/8	-02F	Rc 1/4	17	39.6	16.0	5.6	17.4	31.8
	-03F	Rc 3/8	19	40.4				35.8
	KKA4P-02F	Rc 1/4	17	43.4				36.1
1/4	-03F	Rc 3/8	19	44.4	18.9	6.9	26.4	40.2
	-04F	Rc 1/2		48.6				69.7
	KKA6P-03F	Rc 3/8	24	48.7	20.4	10.0	54.2	84.1
1/2	-04F	Rc 1/2		52.9				79.7
	-06F	Rc 3/4	30	54.6				123.8
	KKA7P-04F	Rc 1/2	32	67.7				217.1
3/4	-06F	Rc 3/4	52	69.4	27.6	13.5	99.6	196.8
	-10F	Rc 1		72.4			99.6	325.9
	KKA8P-06F	Rc 3/4	41	82.0		17.5	168.3	420.5
1	-10F	Rc 1		85.0	35.6			391.3
	-12F	Rc 1 1/4	50	87.3				552.8
	KKA9P-10F	Rc 1	55	107.8	49.1	24.6	332.1	986.9
1 1/4	-12F	Rc 1 1/4		110.1				925.6
	-14F	Rc 1 1/2		110.1				848.2




(mm)

(mm)

Dimensions/Socket (S)

With check valve

Male thread type





Body size	Model	T Connection port size	H Width across flats	øD	L	Min. bore size	Effective area mm ²	Mass g
	KKA3S-01F	Rc 1/8	17		37.6			46.9
1/8	-02F	Rc 1/4	17	18.5	41.2	5.9	18.5	47.2
	-03F	Rc 3/8	19		43.1			52.3
	KKA4S-02F	Rc 1/4	00		46.1			97.1
1/4	-03F	Rc 3/8	22	24.2	46.9	7.7	31.8	91.1
	-04F	Rc 1/2	24		52.3			104.3
	KKA6S-03F	Rc 3/8		30.7	50.5	10.2		189.6
1/2	-04F	Rc 1/2	30		56.2		55.3	202.0
	-06F	Rc 3/4			57.9			180.6
	KKA7S-04F	Rc 1/2	36		75.1			477.2
3/4	-06F	Rc 3/4	- 30	42.5	76.5	13.6	101.5	457.4
	-10F	Rc 1	41		82.3		101.5	550.9
	KKA8S-06F	Rc 3/4	46		90.9	17.6		935.2
1	-10F	Rc 1	40	55	93.9		169.9	914.7
	-12F	Rc 1 1/4	50		99.2			1002.1
	KKA9S-10F	Rc 1			121.8	25.1		1919.1
1 1/4	-12F	-12F Rc 1 1/4	63	69	121.8		344.9	1810.0
	-14F	Rc 1 1/2			121.8			1732.6



(mm)

K□

M

H

KK


D

MS

LQ

MQR


TΠ




Dimensions/Plug (P)

Without check valve

Male thread type






(mm)

(mm)

Female thread type

	Body size	Model	T Connection port size	H Width across flats	L1	L2	Min. bore size	Effective area mm ²	Mass g
	1/8	KKA3P-01F-1	Rc 1/8	14	23.2		6.0	22.6	9.6
		-02F-1	Rc 1/4	17	30.3	16.0			20.2
		-03F-1	Rc 3/8	19	32.0				26.2
0	1/4	KKA4P-02F-1	Rc 1/4	17	29.7	18.9	8.0	40.2	20.0
		-03F-1	Rc 3/8	19	34.0				25.8
		-04F-1	Rc 1/2	24	39.4				46.1
		KKA6P-03F-1	Rc 3/8	22	30.9		11.0	76.0	34.3
	1/2	-04F-1	Rc 1/2	24	39.6	20.4			50.0
		-06F-1	Rc 3/4	30	42.8				78.6




Dimensions/Socket (S)

Without check valve

Male thread type											(mm)
	Body size	Model	T Connection port size	H Width across flats	øD	L	A	Min. bore size	Effective area mm ²	Mass g	
		KKA3S-01M-1	R 1/8	17	18.5	38.1	34.1			36.1	
, Intolatala	1/8	-02M-1	R 1/4			41.1	35.1	6.1	23.4	39.4	
		-03M-1	R 3/8			42.1	35.6			43.9	g ++++++++++++++++++++++++++++++++++++
	1/4	KKA4S-02M-1	R 1/4		24.2	46.0	40.0	8.1	41.2	71.9	
		-03M-1	R 3/8	22		47.0	40.5			73.6	
		-04M-1	R 1/2			50.0	42.0			81.7	<u> </u>
		KKA6S-03M-1	R 3/8			51.4	44.9	11.4		138.3	
	1/2	-04M-1	R 1/2	30	30.7	54.4	46.4		81.6	149.6	
		-06M-1	R 3/4			56.4	46.9			174.0	

Female thread type

	Body size	Model	T Connection port size	H Width across flats	øD	L	Min. bore size	Effective area mm ²	Mass g	
		KKA3S-01F-1	Rc 1/8	17	18.5	37.6	6.1	23.4	44.5	
	1/8	-02F-1	Rc 1/4	17		41.2			44.8	
		-03F-1	Rc 3/8	19		43.1			49.9	
		KKA4S-02F-1	Rc 1/4	22	24.2	46.1	8.1	41.2	92.2	
	1/4	-03F-1	Rc 3/8	22		46.9			86.2	
		-04F-1	Rc 1/2			52.3			99.4	
		KKA6S-03F-1	Rc 3/8	30		50.5	11.4	81.6	178.8	
	1/2	-04F-1	Rc 1/2		30.7	56.2			191.2	_
		-06F-1	Rc 3/4			57.9			169.8	





Series KKA Made to Order Specifications

	Symbol	
Specifications without fluorine coating at the liquid-contact part	-X70	
Ex.) KKA3S-01M-<u>X70</u>		
• Without fluorine coating at the liquid contact part		K
		M□
		H□
		KK
		D
		MS
		LQ
		MQR
		T

Refer to pages 182 to 183 for Specific Product Precautions.